

Installation and Maintenance Instructions

CONTENTS

	Page
SAFETY CONSIDERATIONS	1,2
GENERAL	2-6
INSTALLATION	6-11
Step 1 — Unpack and Inspect Units	6
• PROTECTING UNITS FROM DAMAGE	
• PREPARING JOBSITE FOR UNIT INSTALLATION	
• IDENTIFYING AND PREPARING UNITS	
Step 2 — Position the Unit	7
Step 3 — Mount the Unit	7
• INSTALLING HANGER BOLTS	
• MOUNTING UNIT	
• INSTALLING DUCTS	
Step 4 — Connect Piping	8
• CONDENSATE PIPING	
• REFRIGERANT PIPING	
Step 5 — Complete Electrical Connections	8
Step 6 — Position and Connect Controller	11
• WIRED REMOTE CONTROLLER (PROGRAMMABLE)	
• WIRED REMOTE CONTROLLER (NON-PROGRAMMABLE)	
• CENTRAL CONTROLLER	
START-UP	11,12
Pre-Start Check	11
System Operation Check	12
MAINTENANCE	12,13
TROUBLESHOOTING	13,14
Replacement Parts	14
APPENDIX A — CONTROL SETTINGS	15

SAFETY CONSIDERATIONS

Improper installation, adjustment, alteration, service, maintenance, or use can cause explosion, fire, electrical shock, or other conditions which may cause death, personal injury or property damage. The qualified installer or agency must use factory-authorized kits or accessories when modifying this product.

Follow all safety codes. Wear safety glasses, protective clothing, and work gloves. Use quenching cloth for brazing operations. Have fire extinguisher available. Read these instructions thoroughly and follow all warnings or cautions included in literature and attached to the unit. Consult local building codes and the current editions of the National Electrical Code (NEC) ANSI/NFPA (American National Standards Institute/National Fire Protection Association) 70. In Canada, refer to the current editions of the Canadian Electrical Code CSA (Canadian Standards Association) C22.1.

Understand the signal words — DANGER, WARNING, and CAUTION. DANGER identifies the most serious hazards which will result in severe personal injury or death. WARNING signifies hazards that could result in personal injury or death. CAUTION is used to identify unsafe practices,

which would result in minor personal injury or product and property damage.

Recognize safety information. This is the safety-alert symbol (⚠). When this symbol is displayed on the unit and in instructions or manuals, be alert to the potential for personal injury. Installing, starting up, and servicing equipment can be hazardous due to system pressure, electrical components, and equipment location.

⚠ WARNING

Electrical shock can cause personal injury and death. Shut off all power to this equipment during installation. There may be more than one disconnect switch. Tag all disconnect locations to alert others not to restore power until work is completed.

⚠ WARNING

When installing the equipment in a small space, provide adequate measures to avoid refrigerant concentration exceeding safety limits due to refrigerant leak. In case of refrigerant leak during installation, ventilate the space immediately. Failure to follow this procedure may lead to personal injury.

⚠ WARNING

DO NOT USE TORCH to remove any component. System contains oil and refrigerant under pressure.

To remove a component, wear protective gloves and goggles and proceed as follows:

- a. Shut off electrical power to unit.
- b. Recover refrigerant to relieve all pressure from system using both high-pressure and low pressure ports.
- c. Traces of vapor should be displaced with nitrogen and the work area should be well ventilated. Refrigerant in contact with an open flame produces toxic gases.
- d. Cut component connection tubing with tubing cutter and remove component from unit. Use a pan to catch any oil that may come out of the lines and as a gage for how much oil to add to the system.
- e. Carefully unsweat remaining tubing stubs when necessary. Oil can ignite when exposed to torch flame.

Failure to follow these procedures may result in personal injury or death.

⚠ CAUTION


DO NOT re-use compressor oil or any oil that has been exposed to the atmosphere. Dispose of oil per local codes and regulations. DO NOT leave refrigerant system open to air any longer than the actual time required to service the equipment. Seal circuits being serviced and charge with dry nitrogen to prevent oil contamination when timely repairs cannot be completed. Failure to follow these procedures may result in damage to equipment. For information about replacement oil type and viscosity, see the Single-Phase VRF Outdoor Unit installation instructions.

GENERAL

The 40WAH high-static ducted indoor fan coil unit is an appropriate choice for job sites with higher static requirements.

The equipment is initially protected under the manufacturer's standard warranty; however, the warranty is provided under the condition that the steps outlined in this manual for initial inspection, proper installation, regular periodic maintenance, and everyday operation of the unit be followed in detail. This manual should be fully reviewed in advance before initial installation, start-up and any maintenance. Contact your local sales representative or the factory with any questions BEFORE proceeding.

See Fig. 1 for model number nomenclature. Table 1 lists physical data for each unit size. Figures 2 and 3 show unit dimensions. See Fig. 4-7 for fan performance curves.



LEGEND

VRF — Variable Refrigerant Flow


Fig. 1 — Model Number Nomenclature

Table 1 — 40WAH Physical Data

UNIT 40WAH	024	030	036	048
POWER SUPPLY (V-Ph-Hz)	208/230-1-60			
COOLING CAPACITY (Btuh)	24,000	30,000	36,000	48,000
HEATING CAPACITY (Btuh)	27,000	34,000	42,000	54,000
INDOOR FAN MOTOR				
Type	AC Motor			
Input (W)	435	430	430	555
INDOOR COIL				
Number of Rows	2	3	3	4
Fin Spacing (fins/in.)	16			
Fin Type	Aluminum with Hydrophilic Coating			
Tube Diameter, OD (in.)	$\frac{3}{8}$			
Tube Type	Copper Tube with Inner Groove			
Number of Circuits	3	7	7	7
INDOOR AIRFLOW (cfm)				
Low	690	910	1010	1290
Medium	730	970	1140	1500
High	780	1030	1210	1730
INDOOR EXTERNAL STATIC PRESSURE, High (in. wg)	0.1 to 0.8	0.15 to 0.8	0.2 to 0.8	0.2 to 0.8
INDOOR NOISE LEVEL (dBA)				
Low	44.5	47	47	48
Medium	46	49	49	50
High	48	52	52	53
UNIT DIMENSIONS, W x H x D (in.)	37 $\frac{1}{2}$ x 16 $\frac{1}{2}$ x 27 $\frac{1}{4}$			51 $\frac{1}{4}$ x 16 $\frac{1}{2}$ x 27 $\frac{1}{4}$
PACKING DIMENSIONS, W x H x D (in.)	43 x 17 $\frac{3}{4}$ x 30 $\frac{1}{4}$			56 $\frac{1}{2}$ x 17 $\frac{3}{4}$ x 30 $\frac{1}{4}$
NET/GROSS WEIGHT (lb)	95/107	105/118	105/118	150/165
REFRIGERANT TYPE	R-410A			
EXPANSION DEVICE	EXV			
DESIGN PRESSURE, High/Low (psig)	650/250			
REFRIGERANT PIPING (in.)				
Liquid Side, OD	$\frac{3}{8}$			
Suction Side, OD	$\frac{5}{8}$			
CONNECTING WIRING				
Power Wiring	Sized per NEC and Local Codes Based on Nameplate Electrical Data 3 x 13 AWG			
Signal Wiring	3-Core Shielded Wire x 20 AWG			
DRAINAGE WATER PIPE DIAMETER, OD (in.)	1 $\frac{1}{4}$			
CONTROLLER	Wired Controller			


LEGEND

- EXV — Electronic Expansion Valve
 NEC — National Electrical Code



NOTE: All dimensions shown in inches.

Fig. 2 — 40WAH024-036 Dimensions



NOTE: All dimensions shown in inches.

Fig. 3 — 40WAH048 Dimensions




Fig. 4 — 40WAH024 Fan Performance Curves




Fig. 7 — 40WAH048 Fan Performance Curves




Fig. 5 — 40WAH030 Fan Performance Curves




Fig. 6 — 40WAH036 Fan Performance Curves

INSTALLATION

Step 1 — Unpack and Inspect Units — Units are packaged for shipment to avoid damage during normal transit and handling. It is the receiving party's responsibility to inspect the equipment upon arrival. Any obvious damage to the carton and/or its contents should be reported on the bill of lading and a claim should be filed with the transportation company and the factory. Unit should always be stored in a dry place, and in the proper orientation as marked on the carton.

⚠ CAUTION

To avoid equipment damage, do not lift unit by the drain pipe or refrigerant piping. Unit should be lifted using the mounting brackets.

After determining the condition of the carton exterior, carefully remove each unit from the carton and inspect for hidden damage. Check to make sure that items such as thermostats, controller etc. are accounted for whether packaged separately or shipped at a later date. Any hidden damage should be recorded, a claim should be filed with the transportation company, and the factory should be notified. In the event a claim for shipping damage is filed, the unit, shipping carton, and all packing must be retained for physical inspection by the transportation company. All units should be stored in the factory shipping carton with internal packaging in place until installation.

PROTECTING UNITS FROM DAMAGE — Do not apply force or pressure to the coil, piping, or drain stub-outs during handling. All units should be handled by the chassis or as close as possible to the unit mounting point locations.

The unit must always be properly supported. Temporary supports used during installation or service must be adequate to hold the unit securely. To maintain warranty, protect units against hostile environments (such as rain, snow or extreme temperature), theft, vandalism, and debris on jobsite. Equipment covered in this manual is not suitable for outdoor installations. Do not allow foreign material to fall into drain pan. Prevent dust and debris from being deposited on motor, fan wheels and coils. Failure to do so may have serious adverse effects on unit operation and in the case of motor and blower assembly, may result in immediate or premature failure. Failure of any unit caused by deposits of foreign material on the motor or blower wheels will not be covered by the manufacturer's

warranty. Some units and/or job conditions may require some form of temporary covering during construction.

PREPARING JOBSITE FOR UNIT INSTALLATION —

To save time and to reduce the possibility of costly errors, set up a complete sample installation in a typical room at jobsite. Check all critical dimensions such as pipe, wire, and duct connections requirements. Refer to job drawings and product dimension drawings as required. Instruct all trades in their parts of the installation. Units must be installed in compliance with all applicable local code requirements.

IDENTIFYING AND PREPARING UNITS — Be sure power requirements match available power source. Refer to unit nameplate and wiring diagram. In addition:

- Check all tags on unit to determine if shipping screws are to be removed. Remove screws as directed.
- Rotate the fan wheel by hand to ensure that the fan is unrestricted and can rotate freely. Check for shipping damage and fan obstructions. Adjust blower motor as required.

Step 2 — Position the Unit

⚠ DANGER

Units must not be installed where they may be exposed to potentially explosive or flammable atmosphere. If this instruction is not followed exactly, a fire or explosion may result, causing property damage, injury, or loss of life.

Install the unit in a location that meets the following requirements:

- Allow adequate space for installation, service clearance, piping and electrical connections, and necessary ductwork. For specific unit dimensions, refer to Table 1 and Fig. 2 and 3. Allow clearance according to local and national codes.
- Confirm that the ceiling is able to support the weight of the unit. See Table 1 for nominal weight.
- There should be enough room within the false ceiling for installation and maintenance (see Fig. 8).
- The false ceiling should be horizontal and leveled.
- Install the unit in a location within the room that allows uniform air flow in all directions.




Fig. 8 — False Ceiling Installation

Select the unit position with the following points in mind:

- The unit should be installed in a position that is suitable to support the total weight of the unit, refrigerant piping and condensate.
- Proper access should be provided for maintenance for refrigerant piping, EXV (electronic expansion valve), electrical box, and condensate pump. A 2-ft clearance is recommended all around the unit.
- The unit should not be positioned directly above any obstruction.
- The unit must be installed square and level.
- The condensate drain should have sufficient downward slope (1 in. per 100 in.) in any horizontal run between unit and drain. Maximum condensate lift is 29 1/2 inches.

IMPORTANT: Be sure that the ceiling grid is supported separately from the unit. The ceiling grid must not be supported by an part of the unit or any associated wiring or piping work.

Step 3 — Mount the Unit

INSTALLING HANGER BOLTS — Install the hanger bolts at the locations shown in Fig. 2 and 3 (top view). Use 3/8-in. all-threaded rod. For unit weight, see Table 1.

MOUNTING UNIT — The unit can now be lifted on to the hanging rods for mounting.

1. Use rods and fasteners to suspend the unit at the factory-provided mounting holes with rubber grommets.
2. Adjust the height of the unit until the bottom is level with in the false ceiling, with adequate space to provide sufficient pitch for the drain.
3. Secure the unit in position with locknuts and washers on both sides of the mounting bracket. Ensure that the threaded rod does not protrude more than 2 in. below the mounting brackets as shown in Fig. 9.




Fig. 9 — Threaded Rod

INSTALLING DUCTS — Connect the return and supply ducts to the duct collars provided on the unit. Ensure that there is adequate distance between the supply and return diffusers to maintain acceptable air circulation within the space.

The filter is located on rear or bottom of the return side of the unit, depending on the return air inlet arrangement.

Step 4 — Connect Piping

CONDENSATE PIPING — The unit is supplied with a 1 1/4-in. OD drain connection to connect copper or PVC drain piping. When installing condensate piping, follow these recommendations:

- A drain trap may be required by local codes and is recommended for odor control.
- The differential inlet-to-outlet height must be at least 1 in. wg greater than the total static pressure of the unit. The differential height of the outlet to the bottom of the trap must be equal to or greater than the total static pressure of the unit. Provide a trap of at least 2 in. near the end of the drain line to prevent odors. See Fig. 10.




Fig. 10 — Drain Trap

- Condensate piping should slope downward in the direction of condensate flow, with a minimum gradient of 1 in. per 100 inches.
- When multiple units are connected to a common condensate drain, ensure that the drain is large enough to accommodate the volume of condensate from all units. It is also recommended to have an air vent in the condensate piping to prevent air lock.
- Condensate piping must not be installed where it may be exposed to freezing temperatures.

REFRIGERANT PIPING

⚠ CAUTION

When connecting from an indoor unit to an outdoor unit, the isolation valve at the outdoor unit should be in the closed position throughout the refrigerant piping process. Failure to follow this procedure may result in equipment damage.

When connecting from an indoor unit to an outdoor unit, follow these procedures:

- Maximum elevation differential (indoor to outdoor) and length of refrigerant piping is 33 ft. If this is exceeded consider mounting the outdoor unit above the indoor unit.
- Refrigerant piping connection between indoor and outdoor units should be performed once the units are secured at their respective installation locations.

- The refrigeration piping starts at the indoor unit and ends at the outdoor unit.
- The number of bends in the refrigeration piping must be fewer than 15.
- The refrigerant piping should be dry and free of dust and other impurities.
- The bending angle of the refrigerant pipe should not exceed 90 degrees and the bending radius should be as large as possible to prevent any breakage in piping.
- Use proper cutting and flaring tools to avoid leakage.
- Before insulating the suction and liquid refrigeration pipes, perform pressure and leak tests. For details, see the outdoor unit installation manual. Insulating both suction and liquid refrigerant pipes is recommended.
- Vacuuming and charging of the system should be carried out as described in the outdoor unit installation manual.

Step 5 — Complete Electrical Connections —

Installation of wiring must conform with local building codes and with National Electric Code ANSI/NFPA 70, current editions. Units must be electrically grounded in conformance with the code. In Canada, wiring must comply with CSA C22.1, Electrical Code.

⚠ WARNING

Electrical shock can cause personal injury and death. Disconnect power supply before making wiring connections. There may be more than one disconnect switch. Tag all disconnect locations to alert others not to restore power until work is completed.

⚠ WARNING

All units must be wired strictly in accordance with the wiring diagram furnished with the unit. Any wiring different from the wiring diagram could result in personal injury and property damage.

⚠ CAUTION

Any original factory wiring that requires replacement must be replaced with wiring material having a temperature rating of at least 105 C.

Ensure supply voltage to the unit, as indicated on the serial plate, is not more than 10% over the rated voltage or 10% under the rated voltage.

Failure to follow these recommendations may result in equipment damage.

This equipment in its standard form is designed for an electrical supply of 208/230-1-60. Any damage to or failure of units caused by incorrect wiring or voltage is not covered by warranty.


Electric wiring must be sized to carry the full load amp draw of the motor, starter, and any other controls that are used with the unit. See Table 2 for electrical data.

Table 2 — 40WAH Electrical Data

40WAH UNIT SIZE	POWER SUPPLY	
	MCA	MOPD
024	2.4	15
030	2.5	15
036	2.5	15
048	3.0	15

LEGEND

- MCA** — Minimum Circuit Amps
- MOPD** — Maximum Overcurrent Protective Device



LEGEND

- C** — Fan Capacitor
- CS** — Water Level Switch
- EEV** — Electronic Expansion Valve
- FM** — Indoor Fan
- PUMP** — Pump Motor
- T1** — Inlet Air Temperature
- T2** — Coil Temperature
- T2B** — Evap. Outlet Temperature in Cooling Mode
- TR** — Transformer
- XP1-8** — Plug
- XS1-8** — Jack
- XT1-2** — Terminal Block
- Optional Component or Field Wiring


NOTE: Field wiring must use copper conductors only.

After the pipe work is complete, the electrical supply can be connected by routing the cable through the appropriate casing holes or knockouts and connecting the supply and ground cables to the unit's power terminal.

Be sure the power wiring and control wiring do not cross, as this might cause disturbance on the controls side. See Fig. 11 and 12 for wiring diagrams.

NOTE: The indoor unit requires its own power supply. Indoor units are not powered through outdoor units.

Fig. 11 — 40WAH024-036 Typical Wiring Diagram



LEGEND

- C** — Fan Capacitor
- CS** — Water Level Switch
- EEV** — Electronic Expansion Valve
- FM** — Indoor Fan
- PUMP** — Pump Motor
- T1** — Inlet Air Temperature
- T2** — Coil Temperature
- T2B** — Evap. Outlet Temperature in Cooling Mode
- TR** — Transformer
- XP1-8** — Plug
- XS1-8** — Jack
- XT1-2** — Terminal Block
- Optional Component or Field Wiring

NOTE: Field wiring must use copper conductors only.

Fig. 12 — 40WAH048 Typical Wiring Diagram

Step 6 — Position and Connect Controller —

Wired controllers should be installed in a position that maintains good temperature control:

- Position the thermostat approximately 48 in. above floor level.
- Do not position thermostat where it can be directly affected by the unit's discharge airstream.
- Avoid external walls and drafts from windows and doors.
- Avoid positioning near shelves and curtains as these restrict air movement.
- Avoid heat sources such as direct sunlight, heaters, dimmer switches, and other electrical devices.

WIRED REMOTE CONTROLLER (PROGRAMMABLE) — To connect a programmable wired remote controller (thermostat) to the indoor unit, use 4-core shielded cable and 4-pin connector from electrical box of indoor unit (see Fig. 13 and 14). For setup instructions, refer to the controller installation manual.




Fig. 13 — Wired Remote Controller (Programmable) Wiring




Fig. 14 — Wired Remote Controller (Programmable) Wiring

WIRED REMOTE CONTROLLER (NON-PROGRAMMABLE) — To connect non-programmable wired remote controller (thermostat) to the indoor unit, use 5-core shielded cable and 5-pin connector from unit display panel (see Fig. 15). For setup instructions, refer to controller installation manual.




Fig. 15 — Wired Remote Controller (Non-Programmable) Wiring

CENTRAL CONTROLLER — The central controller is connected to the indoor unit through outdoor unit with 3-core shielded cable (see Fig. 16). For setup instructions, refer to the controller installation manual.




Fig. 16 — Central Controller (Back)

START-UP

Pre-Start Check — Once installation is complete, make the following pre-start checks:

1. All indoor and outdoor units are properly installed.
2. All piping and insulation is complete.
3. All electrical connections (both power and control) are properly terminated.
4. All condensate drains are installed correctly.
5. The power supply is of the right voltage and frequency.
6. The units are properly grounded in accordance with current electrical codes.
7. Suction and liquid line service valves are in the open position.

System Operation Check — Once the installation and pre-start checks are completed, follow these steps:

1. Using remote controller, select cooling or heating mode to check the operation of the system.
2. While the system is in operation, check the following on indoor unit:
 - a. Switches or buttons on the remote controller are easy to push.
 - b. Indicator light is showing normal operation and no error is indicated.
 - c. Swing mode of air louvers is working (if applicable to unit).
 - d. Drain pump operation is normal (if applicable).
 - e. No abnormal vibration or noise is noticed.
3. While the system is in operation, check the following on outdoor unit:
 - a. No abnormal vibration or noise is noticed.
 - b. Condenser fan is in operation.
 - c. Indicator light is showing normal operation and no error is indicated.

NOTE: If the unit is turned off or restarted, there is a time delay of 3 minutes for the compressor to start from the time the power is restored.

MAINTENANCE

⚠ CAUTION

When servicing or repairing this unit, use only factory-approved service replacement parts. Refer to the rating plate on the unit for complete unit model number, serial number and company address. Any substitution of parts or controls not approved by the factory will be at the owner's risk and may result in equipment damage.

⚠ CAUTION

To avoid equipment damage, do not attempt to reuse any mechanical or electrical controllers that have been wet. Replace defective controller.

EVERY 3 MONTHS:

- Check the air filter condition. Clean or replace if necessary.

EVERY 6 MONTHS — Follow 3-month maintenance schedule. In addition:

- Clean condensate tray with suitable cleaning agent.
- Clean the grille and panel.

EVERY 12 MONTHS — Follow 6-month maintenance schedule. In addition:

- Be sure all electrical connections are secure.
- Check condensate pump operation.
- Check the heating and cooling action to confirm proper operation.

MOTOR MAINTENANCE (40WAH024-036)

1. Disconnect the safety drain tray connection. Remove the screws holding the safety drain tray as shown in Fig. 17.

2. Remove the screws holding the reinforced panel as shown in Fig. 17.
3. Disconnect the motor wiring from the control box.
4. The fan motor assembly is mounted on the front panel. Remove the screws on the front panel as shown in Fig. 17.




Fig. 17 — Removing Safety Drain Tray and Front Panel (Unit Sizes 024-036)

5. To separate the fan motor assembly from the front panel, push the assembly horizontally about $\frac{3}{4}$ in. as shown in Fig. 18.
6. Slightly lift and push the fan motor assembly downwards to detach it from the front panel. See Fig. 18.
7. When maintenance is complete, reverse the above procedure to re-assemble the motor assembly, front panel, and safety drain tray.




Fig. 18 — Detaching Fan Motor Assembly from Front Panel (Unit Sizes 024-036)

MOTOR MAINTENANCE (40WAH048)

1. Disconnect the safety drain tray connection. Remove the screws holding the safety drain tray as shown in Fig. 19.
2. Disconnect the motor wiring from the control box.
3. The fan motor assembly is mounted on the front panel. Remove the screws on the front panel as shown in Fig. 19.





Fig. 19 — Removing Safety Drain Tray and Front Panel (Unit Size 048)

4. To separate the fan motor assembly from the front panel, push the assembly horizontally about $\frac{3}{4}$ in. as shown in Fig. 20.
5. Slightly lift and push the fan motor assembly downwards to detach it from the front panel. See Fig. 20.
6. When maintenance is complete, reverse the above procedure to re-assemble the motor assembly, front panel, and safety drain tray.



PUSH HORIZONTALLY ABOUT $\frac{3}{4}$ in.




Fig. 20 — Detaching Fan Motor Assembly from Front Panel (Unit Size 048)

TROUBLESHOOTING

Figure 21 shows the LED display panel on the indoor unit. See Table 3 for a summary of display indicators. Table 4 lists problems, possible causes, and possible solutions.




Fig. 21 — LED Display Panel

Table 3 — LED Display Indicators

ERROR CODE	LED DISPLAY	MODE/STATUS
[NO ERROR]	Operation Light ON	Starting
	Operation Light OFF	Shutdown
	Operation Light Flashing Slow*	Standby
	Timer Light ON	Timing ON
	Timer Light OFF	Timing OFF
	Defrost / Fan Light ON	System Defrost ON
	Defrost / Fan Light OFF	System Defrost OFF
E0	Defrost / Fan Light Flashing Fast†	Heating / Cooling Mode Conflict Error
E1	Timer Light Flashing Fast	Communication Error Between Indoor and Outdoor Unit
E2	Operation Light Flashing Fast	Check Indoor Ambient Temperature Sensor (T1)
E3		Check Evaporator Temperature Sensor (T2)
E4		Check Evaporator Outlet Temperature Sensor (T2B)
E7	Defrost / Fan Light Flashing Slow	EEPROM Error (Data Storage)
Ed	Alarm Light Flashing Slow	Outdoor Unit Error
EE	Alarm Light Flashing Fast	Water Level Error
FE	Operation and Timer Lights Flashing Fast	Indoor Unit Turned ON but does not have an Address
F0	Wired Remote Controller Only (40WA900023)	Communication Error between Indoor Unit and Wired Remote Controller

*Flashing Slow = Flashing once per second.
 †Flashing Fast = Flashing twice per second.

Table 4 — Troubleshooting

ERROR	DISPLAY	POSSIBLE CAUSES	POSSIBLE SOLUTIONS
E0	Defrost Light Flashing Fast (Heating/Cooling Mode Conflict Error)	System is in cooling or fan only mode and heating signal is received from a unit on the system.	All units should be in cooling mode for system to stay in cooling mode.
		System is in heating mode and cooling signal is received from a unit on the system.	All units should be in heating mode.
E1	Timer Light Flashing Fast (Communication Error)	Signal wires are short-circuited or disconnected.	Check or reconnect signal wire.
		Signal wire order is incorrect.	Correct signal wire order.
		Signal wires crossing over high voltage power wires.	Separate and distance the signal wire from high voltage power wires.
		Signal wire close to electromagnetic source.	Distance signal wires from electromagnetic source.
		Signal wire length exceeds 360 ft. PC board fault.	Reduce the signal wire length. Replace PC board.
E2, E3, E4	Operation Light Flashing Fast (Sensor Error)	Loose connection at port on PC board.	Tighten the connection at port on PC board.
		Sensor is short-circuited.	Using multi-meter, measure resistance of the sensor. If the resistance is ≤ 100 ohms, change the sensor.
		PC board fault.	Replace PC board.
E7	Defrost Light Flashing Slow (EEPROM Error)	Chip or PC board fault.	Replace PC board.
Ed	Alarm Light Flashing Slow (Outdoor Unit Error)	Outdoor unit fault.	Refer to outdoor unit troubleshooting guide.
EE	Alarm Light Flashing Fast (Water Level Error)	Loose connection or disconnected at port on PC board.	Tighten the connection or reconnect at port on PC board.
		Water level float is stuck.	Inspect the float.
		Trap slope is too steep.	Adjust the trap slope.
		Drain pipe is too long.	Adjust the length of drain pipe.
		Drain pump faulty.	Replace the drain pump.
FE	Operation and Timer Lights Flashing Fast Together (Address Error)	Indoor unit without address.	Run automatic addressing option at the outdoor unit. Use remote wireless or wired controller to re-address indoor unit.
F0	Wired Remote Controller Screen	Incorrect signal wiring between indoor unit and wired remote controller.	Correct signal wiring between indoor unit and wired remote controller, as per the wiring diagram provided in the installation manual.

Replacement Parts — Quote the unit model number and unit serial number when ordering replacement parts or contacting the factory about the unit. This information can be found on the serial plate attached to the unit. See Fig. 22.




Fig. 22 — Unit Serial Plate (Example)

APPENDIX A — CONTROL SETTINGS

There are 4 DIP switches on the main board. Figures A-D show the settings for each parameter controlled by a switch. Switches are shown in the default settings.



POSITION 1 — START-UP

- OFF — Auto Addressing Mode (Default)
- ON — Factory Test Mode



POSITION 2 — FAN

- OFF — AC Fan (Default)
- ON — Do not set switch to ON



POSITION 3, 4 — Not Used

Fig. A — SW1 Settings



POSITION 1, 2 — COIL TEMPERATURE, HEATING MODE

- OFF, OFF — Coil Temperature < 59 F, No Heat (Default)
- OFF, ON — Coil Temperature < 68 F, No Heat
- ON, OFF — Coil Temperature < 75.2 F, No Heat
- ON, ON — Coil Temperature < 78.8 F, No Heat



POSITION 3, 4 — MODE, FAN STATUS, SP REACHED

- OFF, OFF — Cooling Mode/Fan On/SP Reached, Heating Mode/Fan On/SP Reached (Default)
- OFF, ON — Cooling Mode/Fan On/SP Reached, Heating Mode/Fan Off/SP Reached
- ON, OFF — Cooling Mode/Fan Off/SP Reached, Heating Mode/Fan On/SP Reached
- ON, ON — Cooling Mode/Fan Off/SP Reached, Heating Mode/Fan Off/SP Reached

SP — Set Point

Fig. B — SW2 Settings



POSITION 1, 2 — HEATING TEMPERATURE OFFSET

- OFF, OFF — Temperature Offset is 1.8 F (Default)
- OFF, ON — Temperature Offset is 3.6 F
- ON, OFF — Temperature Offset is 7.2 F
- ON, ON — Temperature Offset is 10.8 F

Fig. C — SW5 Settings



POSITION 1 — CONTROLS

- OFF — Display Board (Default)
- ON — Control Interface Module



POSITION 2, 3 — Not Used

Fig. D — SW6 Settings

Terminal J1 is located on the main control board. The default setting for J1 is no jumper and the Power Off Memory function is enabled. When J1 jumper is in place, the Power Off Memory function will be disabled.

The manual button is located on the display board. The default display is Fahrenheit. To change from Fahrenheit to Celsius, press the button and hold for 5 seconds.

