



# Installation Instructions

**IMPORTANT:** This installation instruction contains basic unit installation information including installation of field control devices. For information on unit start-up, service, and operation, refer to the unit Controls, Start-Up, Operation, Service, and Troubleshooting Instructions also enclosed in the unit literature packet.

## TABLE OF CONTENTS


SAFETY CONSIDERATIONS .....	1
INSTALLATION .....	2
Step 1 - Provide Unit Support .....	2
Step 2 - Rig and Place Unit .....	2
Step 3 - Field Fabricate Ductwork .....	8
Step 4 - Make Unit Duct Connections .....	8
Step 5 - Install Flue Hood and Inlet Hood .....	8
Step 6 - Install External Trap for Condensate Drain .....	9
Step 7 -Orifice Change .....	10
Step 8 - Install Gas Piping .....	10
Step 9 - Make Electrical Connections .....	11
Step 10 - Install Outdoor-Air Hoods (Units with Economizer) .....	16
Step 11 - Install All Accessories .....	16
Step 12 - Configure Controls .....	16

## SAFETY CONSIDERATIONS


Installation and servicing of air-conditioning equipment can be hazardous due to system pressure and electrical components. Only trained and qualified service personnel should install, repair, or service air-conditioning equipment.

Untrained personnel can perform the basic maintenance functions of cleaning coils and filters and replacing filters. All other operations should be performed by trained service personnel. When working on air-conditioning equipment, observe precautions in the literature, tags and labels attached to the unit, and other safety precautions that may apply.

Follow all safety codes. Wear safety glasses and work gloves.

Recognize safety information. This is the safety-alert symbol . When you see this symbol on the unit and in instructions or manuals, be alert to the potential for personal injury.


Understand the signal words DANGER, WARNING, and CAUTION. These words are used with the safety-alert symbol. DANGER identifies the most serious hazards which **will** result in severe personal injury or death. WARNING signifies a hazard which **could** result in personal injury or death. CAUTION is used to identify unsafe practices which **may** result in minor personal injury or product and property damage. NOTE is used to highlight suggestions which **will** result in enhanced installation, reliability, or operation.

** WARNING**

**ELECTRICAL SHOCK HAZARD**

Failure to follow this warning could result in personal injury or death.

Before performing service or maintenance operations on unit, turn off main power switch to unit.

** WARNING**

**UNIT OPERATION AND SAFETY HAZARD**

Failure to follow this warning could result in personal injury or equipment damage.

Puron refrigerant systems operate at higher pressures than standard R-22 systems. Do not use R-22 service equipment or components on Puron refrigerant equipment.

**⚠ WARNING****FIRE, EXPLOSION HAZARD**

Failure to follow this warning could result in personal injury, death and/or property damage.

1. Improper installation, adjustment, alteration, service, or maintenance can cause property damage, personal injury, or loss of life. Refer to the User's Information Manual provided with this unit for more details.
2. Do not store or use gasoline or other flammable vapors and liquids in the vicinity of this or any other appliance.

**What to do if you smell gas:**

1. DO NOT try to light any appliance.
2. DO NOT touch any electrical switch, or use any phone in your building.
3. IMMEDIATELY call your gas supplier from a neighbor's phone. Follow the gas supplier's instructions.
4. If you cannot reach your gas supplier, call the fire department.

**⚠ WARNING****FIRE, EXPLOSION HAZARD**

Failure to follow this warning could result in personal injury or death.

Disconnect gas piping from unit when pressure testing at pressure greater than 0.5 psig. Pressures greater than 0.5 psig will cause gas valve damage resulting in hazardous condition. If gas valve is subjected to pressure greater than 0.5 psig, it *must* be replaced before use. When pressure testing field-supplied gas piping at pressures of 0.5 psig or less, a unit connected to such piping must be isolated by closing the manual gas valve(s).

**IMPORTANT:** Units have high ambient operating limits. If limits are exceeded, the units will automatically lock the compressor out of operation. Manual reset will be required to restart the compressor.

**INSTALLATION****Step 1 — Provide Unit Support****Roof Curb**

Assemble or install accessory roof curb in accordance with instructions shipped with this accessory. (See Fig. 1.) Install insulation, cant strips, roofing, and counter flashing as shown. Ductwork can be installed to roof curb before unit is set in place. Ductwork must be attached to curb and not to the unit. Curb must be level. This is necessary to permit unit drain to function properly. Unit leveling tolerance is  $\pm 1/16$ -in. per linear ft in any direction. Refer to Accessory Roof Curb Installation Instructions for additional information as required. When accessory roof curb is used, unit may be installed on class A, B, or C roof covering material. Carrier roof curb accessories are for flat roofs or slab mounting.

**IMPORTANT:** The gasketing of the unit to the roof curb is critical for a watertight seal. Install gasket with the roof curb as shown in Fig. 1. Improperly applied gasket can also result in air leaks and poor unit performance. Do not slide unit to position on roof curb.

**Alternate Unit Support**

When a curb cannot be used, install unit on a noncombustible surface. Support unit with sleepers, using unit curb support area. If sleepers cannot be used, support long sides of unit with a minimum of 3 equally spaced 4-in. x 4-in. pads on each side.

**Step 2 — Rig and Place Unit**

Inspect unit for transportation damage. See Table 1 for physical data. File any claim with transportation agency.

**⚠ CAUTION****UNIT DAMAGE HAZARD**

Failure to follow this caution may result in equipment damage.

All panels must be in place when rigging. Unit is not designed for handling by fork truck.




Do not drop unit; keep upright. Use spreader bars over unit to prevent sling or cable damage. Rollers may be used to move unit across a roof. Level by using unit rail as a reference; leveling tolerance is  $\pm 1/16$ -in. per linear ft in any direction. See Fig. 3 for additional information. Unit rigging weight is shown in Fig. 3

Rigging holes are provided in the unit base rails as shown in Fig. 3. Refer to rigging instructions on unit.

UNIT SIZE 48 PG	"C"	CONNECTOR ACCESSORY PACKAGE
03-07	1/2" NPT	CR6ASPL1005A00

UNIT SIZE 48 PG	"A"	ROOF CURB ACCESSORY
03-07	1'-2" [356] 2'-0" [610]	CRRFCURB020A00 CRRFCURB032A00

- NOTES:
1. ROOF CURB ACCESSORY IS SHIPPED UNASSEMBLED.
  2. INSULATED PANELS.
  3. DIMENSIONS IN ( ) ARE IN MILLIMETERS.
  4. ROOF CURB GALVANIZED STEEL.
  5. ATTACH DUCTWORK TO CURB (FLANGES ON DUCT REST ON CURB).
  6. SERVICE CLEARANCE 4 FT ON EACH SIDE.
  7. GAS SERVICE PLATE IS PART OF A SEPARATELY SHIPPED ACCESSORY PACKAGE.
  8. GAS SERVICE PLATE CAN BE USED WITH EITHER ACCESSORY ROOF CURB.
  9. BOLT HEADS TO BE ON INSIDE OF FLANGE. CLEARANCE IS (11) 0-7/16" TYP ALL CORNERS.



TYPICAL 4 SIDES






Fig. 1 - Roof Curb Details

C07310

UNIT 48PG	STD UNIT WEIGHT		CORNER WEIGHT (A)		CORNER WEIGHT (B)		CORNER WEIGHT (C)		CORNER WEIGHT (D)	
	lb	kg	lb	kg	lb	kg	lb	kg	lb	kg
03	774	351	170.1	77.1	142.3	64.5	210.3	95.4	251.3	114.0
04	786	357	172.7	78.3	144.5	65.5	213.5	96.8	255.2	115.8
05	901	409	198.0	89.8	165.7	75.2	244.8	111.0	292.5	132.7
06	921	418	202.4	91.8	169.4	76.8	250.2	113.5	299.0	135.6
07	961	436	211.2	95.8	176.7	80.2	261.1	118.4	312.0	141.5

**NOTES:**

- Do not locate adjacent units with flue discharge facing economizer inlet.  
Minimum clearances to be:  
  - Front, 48 in. to combustible surfaces (18 in. to combustible surfaces when using accessory flue discharge deflector.) When not using roof curb (discharge deflector), when not using roof curb (1 in.) bottom or base pan to combustible surfaces. When not using roof curb (0 in.) bottom of base rail to combustible surfaces.
  - Right side, front and back sides (36 in.) for proper condenser airflow.
  - Overhead (60 in.) to assure proper condenser airflow between unit and control box (42 in. per NEC [National Electrical Code]).
  - Between units and ungrounded surface control box side (36 in. per NEC).
  - Between unit and block or concrete wall and other grounded surfaces control box side (42 in.).
  - Horizontal supply and return, (0 in.).
  - Downshot ducts designed to be attached to accessory roof curb only. If unit is mounted side supply, it is recommended the ducts must be supported by cross braces as done on accessory roof curb.
  - With the exception of clearance for the condenser coil, combustible surfaces, and the damper/power exhaust as stated in Note 1, a removable fence or barricade requires no clearance.
  - Dimensions are from outside of base rail. Allow 0-7/16 [8] on each side for top cover drip edge.
- Units may be installed on combustible floors made from Class A, B, C roof covering material if set on base rails.





Fig. 2 - Base Unit Dimensions

**⚠ CAUTION - NOTICE TO RIGGERS:  
ACCESS PANEL MUST BE IN PLACE WHEN RIGGING.**

**Hook rigging shackles through holes in base rail, as shown in Detail A. Holes in base rails are centered around the unit center of gravity. Use wooden top skid, when rigging, to prevent rigging straps from damaging unit.**

UNIT SIZE	A		B		C		D		E		MAX. WEIGHT	
	in.	mm	in.	mm	in.	mm	in.	mm	in.	mm	lb	kg
03-07	77.9	1978	36-54	914-1371	44.8	1139	42.0	1067	23.5	597	1156	525



**Fig. 3 - 48PG Rigging Label**

C07270

**Positioning**

Maintain clearance, per Fig. 2, around and above unit to provide minimum distance from combustible materials, proper airflow, and service access.

Do not install unit in an indoor location. Do not locate air inlets near exhaust vents or other sources of contaminated air. For proper unit operation, adequate combustion and ventilation air must be provided in accordance with Section 5.3 (Air for Combustion and Ventilation) of the National Fuel Gas Code, ANSI Z223.1 (American National Standards Institute).

Although unit is weatherproof, guard against water from higher level runoff and overhangs.

Locate mechanical draft system flue assembly at least 4 ft from any opening through which combustion products could enter the building, and at least 4 ft from any adjacent building (or per local codes). Locate unit at least 10 ft away from any adjacent unit. When unit is located adjacent to public walkways, flue assembly must be at least 7 ft above grade.

**Roof Mount**

Check building codes for weight distribution requirements. Unit operating weight is shown in Table 1.

**Installation Onto Curb**

The 48PG units are designed to fit on the accessory full perimeter curb. Correct placement of the unit onto the curb is critical to operating performance. To aid in correct positioning, place unit on roof curb to maintain 1/4-in. gap between the inside of rail and roof curb on long sides and a 1/2-in. gap between the inside of rail and roof curb on both duct and condenser ends. Refer to Fig. 1 and 2, to assure proper duct opening alignment.

**NOTE:** Before positioning unit onto curb, refer to Step 6 - Install External Trap for Condensate Drain concerning bottom drain connection plug.

**⚠ CAUTION**

**EQUIPMENT DAMAGE HAZARD**

Failure to follow this caution may result in damage to unit.

Do not slide unit into position when it is sitting on the curb. Curb gasketing material may be damaged and leaks may result.

**Slab Mount (Horizontal Units Only)**

Provide a level concrete slab that extends a minimum of 6-in. beyond unit cabinet. Install a gravel apron in front of condenser-coil air inlet to prevent grass and foliage from obstructing airflow.

**NOTE:** Horizontal units may be installed on a roof curb if required.

**48PG03-07**

Table 1 – Physical Data

BASE UNIT 48PG	03	04	05	06	07
NOMINAL CAPACITY (Tons)	2	3	4	5	6
OPERATING WEIGHT (lb)					
Unit*	774	786	901	921	961
Economizer					
Vertical	40	40	40	40	40
Horizontal	50	50	50	50	50
Humidi-MiZer™ System	22	22	31	27	26
Roof Curb					
14-in.	122	122	122	122	122
24-in.	184	184	184	184	184
COMPRESSOR			Fully Hermetic Scroll		
Quantity	1	1	1	1	1
Oil Type			Copeland 3MA		
Number of Refrigerant Circuits	1	1	1	1	1
Oil (oz)	38	42	42	66	56
REFRIGERANT TYPE			R-410A (Puron® Refrigerant)		
Expansion Device	TXV	TXV	TXV	TXV	TXV
Operating Charge (lb) — Standard Unit	7.3	9.0	15.7	16.6	19.0
Operating Charge (lb) — Humidi-MiZer Unit	11.75	13.50	25.00	22.00	22.70
CONDENSER COIL			Enhanced Copper Tubes, Aluminum Lanced Fins		
Condenser A (Outer)					
Rows...Fins/in.	1...17	1...17	2...17	2...17	2...17
Face Area (sq ft)	12.6	12.6	12.6	12.6	12.6
Condenser B (Inner)					
Rows...Fins/in.	—	1...17	2...17	2...17	2...17
Face Area (sq ft)	—	12.6	12.6	12.6	12.6
Humidi-MiZer Coil			Enhanced Copper Tubes and Aluminum Lanced Fins		
Rows...Fins/in.	1...17	1...17	1...17	1...17	1...17
Face Area (sq ft)	6.4	6.4	9.3	9.3	9.3
CONDENSER FAN			Propeller		
Quantity...Diameter (in.)	1...24	1...24	1...24	1...24	1...24
Nominal Cfm (Total, all fans)	3500	3500	3500	4500	4500
Motor Hp	1/8	1/8	1/8	1/4	1/4
Nominal Rpm — High Speed	825	825	825	1100	1100
Nominal Rpm — Low Speed	300	300	300	300	300
EVAPORATOR COIL			Enhanced Copper Tubes, Aluminum Double-Wavy Fins, Face Split		
Rows...Fins/in.	2...15	2...15	2...15	3...15	4...15
Face Area (sq ft)	9.3	9.3	9.3	9.3	9.3
EVAPORATOR FAN			Centrifugal Type, Belt Drive		
Quantity...Size (in.)	Low 1...12 x 9	Low 1...12 x 9	Low 1...12 x 9	Low 1...12 x 9	Low 1...12 x 9
Type Drive	High Belt	High Belt	High Belt	High Belt	High Belt
Nominal Cfm	800	1200	1600	2000	2400
Maximum Continuous Bhp	Low 0.85	Low 0.85	Low 0.85	Low 0.85/2.40†	Low 2.40
Motor Nominal Rpm	High 1620	High 1620	High 1620	High 1620	High 1725
Motor Frame Size	Low 48Y	Low 48Y	Low 48Y	Low 56Y	Low 56Y
Fan Rpm Range	High 48Y	High 48Y	High 56Y	High 56Y	High 56Y
Motor Bearing Type	Low 482-736	Low 482-736	Low 596-910	Low 690-978	Low 796-1128
Maximum Fan Rpm	High 656-1001	High 796-1128	High 828-1173	High 929-1261	High 1150-1438
Motor Pulley Pitch Diameter Range (in.)	Ball	Ball	Ball	Ball	Ball
Fan Pulley Pitch Diameter (in.)	Low 2000	Low 2000	Low 2000	Low 2000	Low 2000
Nominal Motor Shaft Diameter (in.)	High 1.9-2.9	High 1.9-2.9	High 1.9-2.9	High 2.4-3.4	High 2.4-3.4
Belt...Pitch Length (in.)	Low 1.9-2.9	Low 2.4-3.4	Low 2.4-3.4	Low 2.8-3.8	Low 4.0-5.0
Belt...Type	Low 6.8	Low 6.8	Low 5.5	Low 6.0	Low 5.2
Pulley Center Line Distance Min. (in.)	High 5.0	High 5.2	High 5.0	High 5.2	High 6.0
Pulley Center Line Distance Max. (in.)	Low 1/2	Low 1/2	Low 1/2	Low 5/8	Low 5/8
Speed Change per Full Turn of Movable Pulley Flange (rpm)	High 1/2	High 1/2	High 5/8	High 5/8	High 7/8
Movable Pulley Maximum Full Turns from Closed Position	Low 49.3	Low 49.3	Low 49.3	Low 49.3	Low 49.3
Factory Pulley Setting (rpm)	High 49.3	High 49.3	High 49.3	High 49.3	High 52.3
Fan Shaft Diameter at Pulley (in.)	Low AX	Low AX	Low AX	Low AX	Low AX
	High AX	High AX	High AX	High AX	High AX
	Low 16.2	Low 16.2	Low 16.2	Low 16.2	Low 16.2
	High 16.2	High 16.2	High 16.2	High 16.2	High 16.2
	Low 20.2	Low 20.2	Low 20.2	Low 20.2	Low 20.2
	High 48	High 48	High 59	High 58	High 66
	Low 65	Low 62	Low 69	Low 66	Low 58
	High 5	High 5	High 5	High 5	High 5
	Low 5	Low 5	Low 5	Low 5	Low 5
	High 736	High 736	High 910	High 978	High 1128
	Low 794	Low 929	Low 1035	Low 1128	Low 1323
	High 3/4	High 3/4	High 3/4	High 3/4	High 3/4

\*See Legend on next page.

48PG03--07

**Table 1 - Physical Data (cont)**

BASE UNIT 48PG			03	04	05	06	07
<b>GAS HEAT SECTION</b>							
<b>Rollout Switch</b>							
Open Temperature (F)	Low		N/A	195	195	195	195
	Med		N/A	195	195	225	225
	High		195	225	225	195	195
Closed Temperature (F)	Low		N/A	115	115	115	115
	Med		N/A	115	115	175	175
	High		115	175	175	115	115
<b>Standard Units</b>							
Gas Input (Btuh)	Stage 1/Stage 2	PGD/L	—	39,200/ 56,000	39,200/ 56,000	52,500/ 75,000	52,500/ 75,000
		PGE/M	—	52,500/ 75,000	52,500/ 75,000	79,100/113,000	79,100/113,000
	PGF/N	56,000	79,100/113,000	79,100/113,000	105,700/151,000	105,700/151,000	
Low NOx Units		PGD/L	—	56,000	56,000	75,000	—
		PGE/M	—	75,000	75,000	113,000	—
		PGF/N	56,000	113,000	113,000	151,000	—
<b>Burner Orifice Diameter (in. ...drill size)**</b>							
Natural Gas			0.0820...45	0.0820...45	0.0820...45	0.0820...45	0.0820...45
Liquid Propane			0.0650...52	0.0650...52	0.0650...52	0.065...52	0.065...52
<b>Thermostat Heat Anticipator Setting (amps)</b>							
First Stage			0.3	0.3	0.3	0.3	0.3
Second Stage			0.4	0.4	0.4	0.4	0.4
<b>Manifold Pressure (in. wg)</b>							
Natural Gas			3.5	3.5	3.5	3.5	3.5
Liquid Propane			3.5	3.5	3.5	3.5	3.5
Gas Valve Quantity			1	1	1	1	1
Gas Supply Pressure Range (in. wg)			5.0-13.0	5.0-13.0	5.0-13.0	5.0-13.0	5.0-13.0
Field Gas Connection Size (in.)			1/2	1/2	1/2	1/2	1/2
<b>HIGH-PRESSURE SWITCH (psig)</b>							
Cutout			660 ± 10	660 ± 10	660 ± 10	660 ± 10	660 ± 10
Reset (Auto.)			505 ± 20	505 ± 20	505 ± 20	505 ± 20	505 ± 20
<b>RETURN-AIR FILTERS</b>							
Quantity...Size (in.)			4...16 x 20 x 2	4...16 x 20 x 2	4...16 x 20 x 2	4...16 x 20 x 2	4...16 x 20 x 2

**LEGEND**

**TXV** – Thermostatic Expansion Valve

\* Aluminum Evaporator Coil/Aluminum Condenser Coil.

† Single phase/three phase.

\*\* For applications less than 2000 ft elevation.

**48PG03-07**

### Step 3 — Field Fabricate Ductwork

On vertical units, secure all ducts to roof curb and building structure. Do not connect ductwork to unit. For horizontal applications, field-supplied flanges should be attached to horizontal discharge openings and all ductwork secured to the flanges. Insulate and weatherproof all external ductwork, joints, and roof openings with counter flashing and mastic in accordance with applicable codes.

Ducts passing through an unconditioned space must be insulated and covered with a vapor barrier.

If a plenum return is used on a vertical unit, the return should be ducted through the roof deck to comply with applicable fire codes.

A minimum clearance is not required around ductwork. Cabinet return-air static pressure (a negative condition) shall not exceed 0.35-in. wg with economizer or 0.45-in. wg without economizer.

These units are designed for a minimum continuous return air temperature in heating of 50°F (dry bulb), or an intermittent operation down to 45°F (dry bulb), such as when used with a night set-back thermostat.

To operate at lower return-air temperatures, a field-supplied outdoor-air temperature control must be used to initiate both stages of heat when the temperature is below 45°F. Indoor comfort may be compromised when these lower air temperatures are used with insufficient heating temperature rise.

### Step 4 — Make Unit Duct Connections

#### Vertical Supply/Return Configuration

Unit is shipped in vertical supply/return configuration. Ductwork openings are shown in Fig. 1 and 2. Attach the ductwork to the roof curb. Do not attach duct directly to the unit.

## ⚠ WARNING

### PERSONAL INJURY HAZARD

Failure to follow this warning could result in personal injury.

For vertical supply and return units, tools or parts could drop into ductwork and cause an injury. Install a 90-degree turn in the return ductwork between the unit and the conditioned space. If a 90-degree elbow cannot be installed, then a grille of sufficient strength and density should be installed to prevent objects from falling into the conditioned space.




Fig. 5 - Panel and Filter Locations

### Horizontal Supply/Return Applications

Unit can be field-converted from vertical supply/return to horizontal supply/return. Remove all screws securing horizontal duct covers to duct panel. Save panels. Install duct covers in the vertical duct openings in the basepan with the insulation side up. Covers will drop into openings and can be secured using field-supplied self-tapping screws. Ductwork can be attached to duct flanges provided on unit. When securing ductwork to unit, do not drill in area below bead or above top edge of duct opening.

### Step 5 — Install Flue Hood and Inlet Hood

Flue hood (smaller hood), inlet hood (larger hood), and screens are shipped inside the unit in the gas section. To install, open the heat section door. The flue hood is attached to the heat section panel from the outside using the screws provided. (See Fig. 4 and 5.)

The inlet hood is installed by inserting the hood through the back of the heat panel. Attach the hood by inserting the screws provided through the clearance holes in the heat panel and into the intake hood.

**NOTE:** When properly installed, the flue hood will line up with the combustion fan housing. (See Fig. 6.)





Fig. 4 - Flue and Inlet Hood

C06257

C06255





**Fig. 6 - Typical Gas Heating Section**

C06258

## Step 6 — Install External Trap for Condensate Drain


The unit's 3/4-in. condensate drain connections are located on the bottom and side of the unit. If the down drain is used, drill a minimum of 5/8-in. diameter hole but not larger than a 3/4-in. diameter hole through the drain pan. A dimple of 2 mm in diameter and 1.5 mm deep will be provided in the drain pan to help locate the drill bit and to start the hole. Do not cut through the PVC pipe threads. Unit discharge connections do not determine the use of drain connections; either drain connection can be used with vertical or horizontal applications. See Fig. 2 for locations.

When using the standard side drain connection, make sure the plug (red) in the alternate bottom connection is tight before installing the unit. (See Fig. 7.)

To use the bottom drain connection for a roof curb installation, relocate the factory-installed plug (red) from the bottom connection to the side connection. A 1/2-in. socket extension can be used to remove the plug. (See Fig. 7.) The piping for the condensate drain and external trap can be completed after the unit is in place.


All units must have an external trap for condensate drainage. Install a trap at least 4-in. deep and protect against freezeup. If drain line is installed downstream from the external trap, pitch the line away from the unit at 1-in. per 10 ft of run. Do not use a pipe size smaller than the unit connection (3/4-in.). (See Fig. 8 and 9.)

The 48PG units are provided with a removable condensate pan for ease of cleaning. Refer to Maintenance section in Controls and Troubleshooting book for more information. It is recommended that a union be placed between the unit and condensate drainage to ease the removal of the pan during servicing. Adequate clearance should be allowed if removal of condensate pan is required. Allow 54-in. between condensate pan access panel and any obstruction for complete removal.




**Fig. 7 - Condensate Drain Pan**

C10321



**Fig. 8 - External Trap for Condensate Drain**

C06234



NOTE: Trap should be deep enough to offset maximum unit static difference. A 4-in. trap is recommended.

C06291

**Fig. 9 - Condensate Drain Piping Details**

### Step 7 — Orifice Change

This unit is factory assembled for heating operation using natural gas at an elevation from sea level to 2000 ft. This unit uses orifice type LH32RFnnn, where “nnn” indicates the orifice size based on drill size diameter in thousands of an inch.

#### High Elevation (Above 2000 Ft)

Use accessory high altitude kit when installing this unit at an elevation of 2000 to 7000 ft. For elevations above 7000 ft, refer to Table 2 to identify the correct orifice size for the elevation. See Table 3 for the number of orifices required for each unit size. Purchase these orifices from your local Carrier dealer. Follow instructions in accessory Installation Instructions to install the correct orifices.

**Table 2 – Altitude Compensation\***

ELEVATION (ft)	NATURAL GAS ORIFICE†
0-1,999	45
2,000	47
3,000	47
4,000	47
5,000	48
6,000	48
7,000	48
8,000	49
9,000	49
10,000	50
11,000	51
12,000	51
13,000	52
14,000	52

\*As the height above sea level increases, there is less oxygen per cubic foot of air. Therefore, heat input rate should be reduced at higher altitudes. Includes a 4% input reduction per each 1000 ft.

†Orifices available through your Carrier dealer.

**Table 3 – Orifice Quantity**

UNIT	03	04	05	06	07
Low Heat (48PGD/L)	—	3	3	4	4
Medium Heat (48PGE/M)	—	4	4	6	6
High Heat (48PGF/N)	3	6	6	8	8

### Conversion to LP Gas

Use accessory LP gas conversion kit when converting this unit for use with LP fuel usage for elevations up to 7000 ft. For elevations above 7000 ft, refer to Table 4 to identify the correct orifice size for the elevation. See Table 3 for the number of orifices required for each unit size. Purchase these orifices from your local Carrier dealer. Follow instructions in accessory Installation Instructions to install the correct orifices.

**Table 4 – LP Gas Conversion\***

ELEVATION (ft)	LP GAS ORIFICE†
0-1,999	52
2,000	52
3,000	53
4,000	53
5,000	53
6,000	53
7,000	53
8,000	54
9,000	54
10,000	54
11,000	54
12,000	55
13,000	55
14,000	56

\*As the height above sea level increases, there is less oxygen per cubic foot of air. Therefore, heat input rate should be reduced at higher altitudes.

Includes a 4% input reduction per each 1000 ft.

†Orifices available through your Carrier dealer.

### Step 8 — Install Gas Piping

Unit is equipped for use with natural gas. Refer to local building codes, or in the absence of local codes, to ANSI Z223.1-latest year and addendum Z223.1A-latest year entitled HFGC. In Canada, installation must be in accordance with the CAN1.B149.1 and CAN1.B149.2 installation codes for gas burning appliances.

Support gas piping as shown in the table in Fig. 10. For example, a 3/4-in. gas piping must have one field-fabricated support beam every 8 ft. Therefore, an 18-ft long gas pipe would have a minimum of 3 support beams. See Fig. 10 for typical pipe guide and locations of external manual gas shutoff valve.

Install field-supplied manual gas shutoff valve with a 1/8-in. NPT pressure tap for test gauge connection at unit. The pressure tap is located on the gas manifold, adjacent to the gas valve. Field gas piping must include sediment trap and union. (See Fig. 11.) Install a field-supplied gas regulator.

**⚠ WARNING**


**FIRE, EXPLOSION HAZARD**

Failure to follow this warning could result in personal injury or death.

Do not pressure test gas supply while connected to unit. Always disconnect before servicing.

**IMPORTANT:** Natural gas pressure at unit gas connection must not be less than 5.0-in. wg or greater than 13.0-in.wg for all heat sizes.

Size gas-supply piping for 0.5-in. wg maximum pressure drop. Do not use supply pipe smaller than unit gas connection.




LEGEND  
 NFGC — National Fuel Gas Code  
 \*Field supplied.  
 NOTE: Follow all local codes.

SPACING OF SUPPORTS

STEEL PIPE NOMINAL DIAMETER (in.)	SPACING OF SUPPORTS X DIMENSION (ft)
1/2	6
3/4 or 1	8
1 1/4 or larger	10

**Fig. 10 - Gas Piping Guide (With Accessory Thru-the-Cab Service Connections)**

C06115



**Fig. 11 - Field Gas Piping**

C06236

**Step 9 — Make Electrical Connections**

**Field Power Supply**

(For more details, refer to the Controls, Start-Up, Operation, and Troubleshooting manual).

All 208/230-v units are factory wired for 230-v power supply. If the 208/230-v unit is to be connected to a 208-v power supply, the transformers (TRAN1 and TRAN2) must be rewired by moving the black wire with the 1/4-in. female quick connector from the 230-volt connection and moving to the 200-volt 1/4-in. male terminal on the primary side of the transformer.

Refer to unit label diagram for additional information. Leads are provided for field wire connections. Use UL (Underwriters Laboratories) approved copper/aluminum connector.

When installing units, provide safety disconnect per NEC (National Electrical Code) Article 440 or local codes. For non-fused disconnects, size the disconnect according to the sizing data provided in the electrical data tables. If a fused disconnect is used, determine the minimum size for the switch based on the disconnect sizing data provided in the electrical data tables and then coordinate the disconnect housing size to accommodate the Maximum Overcurrent Protection (MOCP) device size as marked on the unit informative plate. (See Table 5 and 6.) All field wiring must comply with NEC and local codes. Size wire based on MCA (Minimum Circuit Amps) on the unit informative plate. See Fig. 12 for power wiring connection to the unit leads and equipment ground.

Route power and ground lines through control box end panel or unit basepan (see Fig. 2) to connections as shown on unit wiring diagram and Fig. 12. Factory leads may be wired directly to the disconnect.

⚠ CAUTION

UNIT DAMAGE HAZARD

Failure to follow this caution may result in equipment damage.

The correct power phasing is critical to the operation of the scroll compressors. An incorrect phasing will result in alarm being generated and compressor operation lockout. Should this occur, power phase correction must be made to the incoming power.

⚠ WARNING

ELECTRICAL SHOCK HAZARD

Failure to follow this warning could result in personal injury or death.

Unit cabinet must have an uninterrupted, unbroken electrical ground to minimize the possibility of personal injury if an electrical fault should occur. This ground may consist of electrical wire connected to unit ground lug in control compartment, or conduit approved for electrical ground when installed in accordance with NEC; ANSI (American National Standards Institute)/NFPA (National Fire Protection Association), latest edition, and local electrical codes. *Do not use gas piping as an electrical ground.*


Field wiring must conform to temperature limitations for type “T” wire. All field wiring must comply with NEC and local requirements.

Operating voltage to compressor must be within voltage range indicated on unit nameplate. On 3-phase units, voltages between phases must be balanced within 2%.

Unit failure as a result of operation on improper line voltage or excessive phase imbalance constitutes abuse and may cause damage to electrical components.

**Field Control Wiring (Units Without Optional Humidi-MiZer™ Adaptive Dehumidification System)**

Unit can be controlled with either a Carrier-approved accessory thermostat or a Carrier-approved space temperature sensor. Install thermostat according to the installation instructions included with accessory. Locate thermostat assembly or space temperature sensor on a solid interior wall in the conditioned space to sense average temperature.



**Fig. 12 - Field Power Wiring Connections**

C06237

Route thermostat or space temperature sensor cable or equivalent single leads of colored wire from subbase terminals through conduit into unit to low-voltage connections as shown on unit label wiring diagram and in Fig. 13 or 14.

**NOTE:** For wire runs up to 50 ft, use no. 18 AWG (American Wire Gauge) insulated wire (35°C minimum). For 50 to 75 ft, use no. 16 AWG insulated wire (35°C minimum). For over 75 ft, use no. 14 AWG insulated wire (35°C minimum). All wire larger than no. 18 AWG cannot be directly connected at the thermostat and will require a junction box and splice at the thermostat.

Set heat anticipator settings as follows:

VOLTAGE	STAGE 1 (W1) ON	STAGE 1 AND 2 (W1 AND W2) ON
All	0.3	0.4

Settings may be changed slightly to provide a greater degree of comfort for a particular installation.

**Field Control Wiring (Units With Optional Humidi-MiZer™ Adaptive Dehumidification System)**

Units require temperature control inputs for cooling and heating operation and humidity control inputs for Humidi-MiZer operation.

**Temperature Control**

The unit can be controlled with either a Carrier-approved space temperature sensor, a Carrier accessory Thermidistat™ device, or a Carrier-approved accessory thermostat. Install the temperature control device according to the installation instructions included with the accessory. Locate the device on a solid interior wall in the conditioned space to sense average temperature. Carrier space temperature sensor wiring connections are shown in Fig. 14. General thermostat field control wiring connections are shown in Fig. 13. Carrier Thermidistat device wiring connections are shown in Fig. 15. Configuration of the unit control is required to specify the control input type before unit operation.

Route thermostat or space temperature sensor cable or equivalent single leads of colored wire from subbase terminals through conduit into unit to low-voltage connections as shown on unit label wiring diagram and in Fig. 13-15.

**NOTE:** For wire runs up to 50 ft, use no. 18 AWG (American Wire Gauge) insulated wire (35°C minimum). For 50 to 75 ft, use no. 16 AWG insulated wire (35°C minimum). For over 75 ft, use no. 14 AWG insulated wire (35°C minimum). All wire larger than no. 18 AWG cannot be directly connected at the thermostat and will require a junction box and splice at the thermostat.


Set heat anticipator settings as follows:

VOLTAGE	STAGE 1 (W1) ON	STAGE 1 AND 2 (W1 AND W2) ON
All	0.2	0.4

Settings may be changed slightly to provide a greater degree of comfort for a particular installation.


**Humidity Control**

Unit can be controlled with either a Carrier accessory Thermidistat device or a Carrier-approved accessory humidistat (switch output). The input for an accessory humidity sensor with 4 to 20 mA output is another option available when an economizer board is installed. Install the humidity control device according to the installation instructions included with the accessory. Locate the device on a solid interior wall in the conditioned space to sense average humidity. Carrier Thermidistat device wiring connections are shown in Fig. 15. General humidistat wiring connections are shown in Fig. 16. Configuration of the unit control is required to specify the control input type before unit operation. Refer to the Controls, Start-Up, Operation and Troubleshooting manual for configuration.




**Fig. 13 - Field Control Thermostat Wiring**

C06292



**Fig. 14 - Field Control Space Temperature Sensor Wiring**

C06239



**Fig. 15 - Field Control Thermidistat Wiring**

C07055

Units with the Humidi-MiZer option receive a discrete input from a field-installed device (such as from the Carrier humidistat or Thermidistat device). The discrete input is connected to the TB1 terminal strip points labeled Humidistat 1 and 2. As this is a discrete input, one of the connection points is for power to the switch and the other is the return path. (See Fig. 16.)

A space relative humidity sensor input (SP.RH) is only available if an economizer board (ECB) is installed in the unit and then the sensor can be connected to the OAQ point TB1-4. (See Fig. 16.) This input is used instead of the discrete humidistat or thermidistat inputs. The input controls the Humidi-MiZer using the 4 to 20 mA as percent humidity. The relative humidity value (measured by the relative humidity sensor) can be displayed on the Scrolling Marquee, in the space through a System Pilot™ device, or can be read by other CCN devices where it can be used to perform more advanced functions. The humidity sensor must be configured correctly; refer to the Controls, Start-Up, Operation, and Troubleshooting manual for details.

If the customer also wishes to install a smoke detector into a Humidi-MiZer equipped 48PG unit, the fire shutdown connection points are on Plug PL-19, located in the economizer section. See the unit wiring schematic for wiring. For third-party smoke detector, refer to Fig. 17.

Point 19-3 is the 24 vac power source for the detector. Point 19-4 is 24 vac power for the indoor fan contactor control. Point 19-5 is the 24 vac signal input for fire shutdown. If an immediate fan shutdown is desired, install a normally closed contactor between 19-3 and 19-4. More information is available in the third party control section of the Controls, Start-Up, Operation, and Troubleshooting manual.




Fig. 16 - Humidi-MiZer™ Low-Voltage Terminal Strip - Humidity Sensor/Humidistat Wiring

C07045




Fig. 17 - Third-Party Smoke Detector on Humidi-MiZer Units

C07238

Table 5 – Electrical Data - Units Without Optional Convenience Outlet

UNIT 48PG	NOMINAL POWER SUPPLY Volts-Ph-Hz	VOLTAGE RANGE		COMPRESSOR		OFM		COMBUSTION FAN MOTOR FLA	POWER EXHAUST FLA (ea)	IFM TYPE	IFM FLA	POWER SUPPLY		DISCONNECT SIZE				
		Min	Max	RLA	LRA	Qty	FLA (ea)					MCA	Fuse or HACR Brkr	FLA	LRA			
												Low	High	Low	High			
03	208/230-1-60	187	253	12.8	60	1	1.0	0.52	—	—	4.9	21.9/21.9	25/25	22/22	74/74			
												1.4	Low	21.9/21.9	25/25	22/22	74/74	
													High	23.3/23.3	25/25	23/23	76/76	
												Low	23.3/23.3	25/25	23/23	76/76		
04	208/230-1-60	187	253	15.4	83	1	1.0	0.52	—	—	4.9	25.2/25.2	30/30	24/24	97/97			
												1.4	Low	25.2/25.2	30/30	24/24	97/97	
													High	26.6/26.6	30/30	26/26	99/99	
												Low	26.6/26.6	30/30	26/26	99/99		
	208/230-3-60	187	253	11.5	77	1	1.0	0.52	—	—	4.9	20.3/20.3	25/25	20/20	91/91			
												1.4	Low	20.3/20.3	25/25	20/20	91/91	
													High	21.7/21.7	25/25	22/22	93/93	
												Low	21.7/21.7	25/25	22/22	93/93		
	460-3-60	414	506	5.1	35	1	0.5	0.30	—	—	2.1	9.0	15	9	42			
												0.6	Low	9.0	15	9	42	
													High	9.6	15	10	43	
												Low	9.6	15	10	43		
	575-3-60	518	633	4.3	31	1	0.5	0.24	—	—	2.1	8.0	15	8	37			
												1.4	Low	8.0	15	8	37	
													High	9.4	15	10	39	
												Low	9.4	15	10	39		
05	208/230-1-60	187	253	20.5	109	1	1.0	0.52	—	—	4.9	31.5/31.5	35/35	30/30	123/123			
												1.4	Low	31.5/31.5	35/35	33/33	148/148	
													High	33.6/33.6	35/35	32/32	125/125	
												Low	33.6/33.6	35/35	32/32	125/125		
	208/230-3-60	187	253	14.6	91	1	1.0	0.52	—	—	4.9	24.2/24.2	25/25	24/24	105/105			
												1.4	Low	24.2/24.2	25/25	24/24	123/123	
													High	24.5/24.5	25/25	24/24	107/107	
												Low	24.5/24.5	25/25	24/24	107/107		
	460-3-60	414	506	7.1	46	1	0.5	0.30	—	—	2.1	11.5	15	11	53			
												0.6	Low	11.5	15	12	62	
													High	12.0	15	12	54	
												Low	12.0	15	12	54		
	575-3-60	518	633	5.1	34	1	0.5	0.24	—	—	2.1	9.0	15	9	40			
												1.4	Low	9.0	15	9	46	
													High	8.9	15	9	46	
												Low	8.9	15	9	46		
06	208/230-1-60	187	253	26.9	145	1	1.5	0.52	—	—	4.9	40.0/40.0	45/45	38/38	160/160			
												1.4	Low	40.0/40.0	45/45	41/41	185/185	
													High	42.1/42.1	45/45	40/40	162/162	
												Low	42.1/42.1	45/45	40/40	162/162		
	208/230-3-60	187	253	17.6	123	1	1.5	0.52	—	—	5.2	28.7/28.7	30/30	28/28	156/156			
												1.4	Low	28.7/28.7	30/30	28/28	156/156	
													High	28.7/28.7	30/30	30/30	158/158	
												Low	28.7/28.7	30/30	30/30	158/158		
	460-3-60	414	506	7.7	50	1	0.8	0.30	—	—	2.6	13.0	15	13	67			
												0.6	Low	13.0	15	13	67	
													High	13.6	15	13	68	
												Low	13.6	15	13	68		
	575-3-60	518	633	6.1	40	1	0.8	0.24	—	—	2.0	10.4	15	10	53			
												1.4	Low	10.4	15	10	53	
													High	10.4	15	10	53	
												Low	10.4	15	10	53		
07	208/230-3-60	187	253	20.5	149	1	1.5	0.52	—	—	5.2	32.3/32.3	35/35	31/31	182/182			
												1.4	Low	32.3/32.3	35/35	34/34	208/208	
													High	34.6/34.6	35/35	33/33	184/184	
												Low	34.6/34.6	35/35	33/33	184/184		
	460-3-60	414	506	9.6	75	1	0.8	0.30	—	—	2.6	15.4	20	15	92			
												0.6	Low	15.4	20	16	105	
													High	16.2	20	16	93	
												Low	16.2	20	16	93		
	575-3-60	518	633	7.6	54	1	0.8	0.24	—	—	2.0	12.3	15	12	67			
												1.4	Low	12.3	15	13	78	
													High	13.1	15	13	78	
												Low	13.1	15	13	78		
													13.7	15	14	69		
														Low	13.7	15	14	69
														High	14.5	15	14	80
													Low	14.5	15	14	80	

48PG03--07

LEGEND

- FLA - Full Load Amps
- HACR - Heating, Air Conditioning and Refrigeration
- IFM - Indoor (Evaporator) Fan Motor
- LRA - Locked Rotor Amps
- MCA - Minimum Circuit Amps
- MOCP - Maximum Overcurrent Protection
- NEC - National Electrical Code
- OFM - Outdoor (Condenser) Fan Motor
- RLA - Rated Load Amps



Example: Supply voltage is 230-3-60



AB = 224 v  
 BC = 231 v  
 AC = 226 v  

$$\text{Average Voltage} = \frac{224 + 231 + 226}{3}$$

$$= \frac{681}{3}$$

$$= 227$$

Determine maximum deviation from average voltage.

- (AB) 227 - 224 = 3 v
  - (BC) 231 - 227 = 4 v
  - (AC) 227 - 226 = 1 v
- Maximum deviation is 4 v.

Determine percent of voltage imbalance.

$$\% \text{ Voltage Imbalance} = 100 \times \frac{4}{227}$$

$$= 1.76\%$$

This amount of phase imbalance is satisfactory as it is below the maximum allowable 2%.

**IMPORTANT:** If the supply voltage phase imbalance is more than 2%, contact your local electric utility company immediately.

$$\% \text{ Voltage Imbalance} = 100 \times \frac{\text{max voltage deviation from average voltage}}{\text{average voltage}}$$

**Table 6 – Electrical Data — Units With Optional Convenience Outlet**

UNIT 48PG	NOMINAL POWER SUPPLY Volts-Ph-Hz	VOLTAGE RANGE		COMPRESSOR		OFM		COMBUSTION FAN MOTOR FLA	POWER EXHAUST FLA (ea)	IFM TYPE	IFM FLA	POWER SUPPLY		DISCONNECT SIZE		
		Min	Max	RLA	LRA	Qty	FLA (ea)					MCA	Fuse or HACR Brkr	FLA	LRA	
03	208/230-1-60	187	253	12.8	60	1	1.0	0.52	—	Low	4.9	26.7/26.7	30/30	27/27	79/ 79	
										High	4.9	26.7/26.7	30/30	27/27	79/ 79	
									1.4	Low	4.9	28.1/28.1	30/30	29/29	81/ 81	
										High	4.9	28.1/28.1	30/30	29/29	81/ 81	
04	208/230-1-60	187	253	15.4	83	1	1.0	0.52	—	Low	4.9	30.0/30.0	30/30	30/30	102/102	
										High	4.9	30.0/30.0	30/30	30/30	102/102	
										1.4	Low	4.9	31.4/31.4	35/35	32/32	104/104
											High	4.9	31.4/31.4	35/35	32/32	104/104
	208/230-3-60	187	253	11.5	77	1	1.0	0.52	—	Low	4.9	25.1/25.1	30/30	26/26	96/ 96	
										High	4.9	25.1/25.1	30/30	26/26	96/ 96	
										1.4	Low	4.9	26.5/26.5	30/30	27/27	98/ 98
											High	4.9	26.5/26.5	30/30	27/27	98/ 98
	460-3-60	414	506	5.1	35	1	0.5	0.30	—	Low	2.1	11.2	15	11	44	
										High	2.1	11.2	15	11	44	
										0.6	Low	2.1	11.8	15	12	45
											High	2.1	11.8	15	12	45
575-3-60	518	633	4.3	31	1	0.5	0.24	—	Low	2.1	9.7	15	10	39		
									High	2.1	9.7	15	10	39		
									1.4	Low	2.1	11.1	15	12	41	
										High	2.1	11.1	15	12	41	
05	208/230-1-60	187	253	20.5	109	1	1.0	0.52	—	Low	4.9	36.3/36.3	40/40	36/36	128/128	
										High	7.0	38.4/38.4	40/40	38/38	153/153	
										1.4	Low	4.9	37.7/37.7	40/40	37/37	130/130
											High	7.0	39.8/39.8	40/40	40/40	155/155
	208/230-3-60	187	253	14.6	91	1	1.0	0.52	—	Low	4.9	29.0/29.0	30/30	29/29	110/110	
										High	5.2	29.3/29.3	30/30	29/29	128/128	
										1.4	Low	4.9	30.4/30.4	35/35	31/31	112/112
											High	5.2	30.7/30.7	35/35	31/31	130/130
	460-3-60	414	506	7.1	46	1	0.5	0.30	—	Low	2.1	13.7	15	14	55	
										High	2.6	14.2	15	14	64	
										0.6	Low	2.1	14.3	15	14	56
											High	2.6	14.8	15	15	65
575-3-60	518	633	5.1	34	1	0.5	0.24	—	Low	2.1	10.7	15	11	42		
									High	2.0	10.6	15	11	48		
									1.4	Low	2.1	12.1	15	12	44	
										High	2.0	12.0	15	12	50	
06	208/230-1-60	187	253	26.9	145	1	1.5	0.52	—	Low	4.9	44.8/44.8	50/50	44/44	165/165	
										High	7.0	46.9/46.9	50/50	46/46	190/190	
										1.4	Low	4.9	46.2/46.2	50/50	45/45	167/167
											High	7.0	48.3/48.3	50/50	48/48	192/192
	208/230-3-60	187	253	17.6	123	1	1.5	0.52	—	Low	5.2	33.5/33.5	35/35	33/33	161/161	
										High	5.2	33.5/33.5	35/35	33/33	161/161	
										1.4	Low	5.2	34.9/34.9	35/35	35/35	163/163
											High	5.2	34.9/34.9	35/35	35/35	163/163
	460-3-60	414	506	7.7	50	1	0.8	0.30	—	Low	2.6	15.2	20	15	69	
										High	2.6	15.2	20	15	69	
										0.6	Low	2.6	15.8	20	16	70
											High	2.6	15.8	20	16	70
575-3-60	518	633	6.1	40	1	0.8	0.24	—	Low	2.0	12.1	15	12	55		
									High	2.0	12.1	15	12	55		
									1.4	Low	2.0	13.5	15	14	57	
										High	2.0	13.5	15	14	57	
07	208/230-3-60	187	253	20.5	149	1	1.5	0.52	—	Low	5.2	37.1/37.1	40/40	37/37	187/187	
										High	7.5	39.4/39.4	40/40	39/39	213/213	
										1.4	Low	5.2	38.5/38.5	40/40	38/38	189/189
											High	7.5	40.8/40.8	45/45	41/41	215/215
	460-3-60	414	506	9.6	75	1	0.8	0.30	—	Low	2.6	17.6	20	17	94	
										High	3.4	18.4	20	18	107	
										0.6	Low	2.6	18.2	20	18	95
											High	3.4	19.0	20	19	108
575-3-60	518	633	7.6	54	1	0.8	0.24	—	Low	2.0	14.0	15	14	69		
									High	2.8	14.8	15	15	80		
									1.4	Low	2.0	15.4	20	16	71	
										High	2.8	16.2	20	16	82	

48PG03-07

**LEGEND**

- FLA – Full Load Amps
- HACR – Heating, Air Conditioning and Refrigeration
- IFM – Indoor (Evaporator) Fan Motor
- LRA – Locked Rotor Amps
- MCA – Minimum Circuit Amps
- MOCP – Maximum Overcurrent Protection
- NEC – National Electrical Code
- OFM – Outdoor (Condenser) Fan Motor
- RLA – Rated Load Amps



Example: Supply voltage is 230-3-60



AB = 224 v  
 BC = 231 v  
 AC = 226 v  
 Average Voltage =  $\frac{224 + 231 + 226}{3}$   
 =  $\frac{681}{3}$   
 = 227

Determine maximum deviation from average voltage.

- (AB) 227 - 224 = 3 v
  - (BC) 231 - 227 = 4 v
  - (AC) 227 - 226 = 1 v
- Maximum deviation is 4 v.

Determine percent of voltage imbalance.

% Voltage Imbalance =  $100 \times \frac{4}{227}$   
 = 1.76%

This amount of phase imbalance is satisfactory as it is below the maximum allowable 2%.

**IMPORTANT:** If the supply voltage phase imbalance is more than 2%, contact your local electric utility company immediately.

**NOTES:**

1. In compliance with NEC requirements for multimotor and combination load equipment (refer to NEC Articles 430 and 440), the overcurrent protective device for the unit shall be fuse or HACR breaker. Canadian units may be fuse or circuit breaker.

**2. Unbalanced 3-Phase Supply Voltage**

*Never operate a motor where a phase imbalance in supply voltage is greater than 2%. Use the following formula to determine the percentage of voltage imbalance.*

% Voltage Imbalance =  $100 \times \frac{\text{max voltage deviation from average voltage}}{\text{average voltage}}$

### Step 10 — Install Outdoor Air Hoods (Units Without Economizer)

Perform the following procedure to install the outdoor-air hoods:

1. Economizer and barometric relief hoods are located in the condenser section under the slanted coil for shipping. (See Fig. 18.) Barometric relief/power exhaust hood is shipped inside of economizer hood. Remove screws that secure the wooden rails of the hood assemblies to the unit. Save screws. Slide complete assembly from condenser section.
2. Remove the screws that secure the economizer and barometric relief/power exhaust hoods to the wooden railing. Discard or recycle wooden rails. Save screws.
3. The barometric relief damper is secured to the economizer panel for shipping. Remove the screw holding the barometric relief damper to the panel. Damper should be free to swing open during operation. (See Fig. 19.)
4. Hang the barometric relief/power exhaust hood on the mounting flange on the economizer panel. Secure hood to panel with screws saved from Step 2. (See Fig. 19 and 20.)
5. Align hole in flange of economizer panel with left edge of hood. Hang economizer hood on the top flange of the economizer panel by rotating hood until top flange of the economizer hood engages the bent flange on the economizer panel. Rotate hood until hood is flush with the economizer panel. Hood will support itself from flange. Align holes in hood with holes in panel and secure hood to panel with screws saved from Step 2. (See Fig. 19 and 21.)




Fig. 19 - Hood Installation

C06260

### Step 11 — Install All Accessories

After all of the factory-installed options have been adjusted, install all field-installed accessories. Refer to the accessory installation instructions included with each accessory.

### Step 12 — Configure Controls

Refer to unit controls and Troubleshooting book for information on configuring controls.




Fig. 20 - Barometric Relief/Power Exhaust Hood Flange

C06262




Fig. 18 - Economizer and Barometric Relief/Power Exhaust Hoods Shipping Positions

C06290




Fig. 21 - Economizer Flange

C06263