



Installation Instructions

IMPORTANT: This installation instruction contains basic unit installation information including installation of field control devices. For information on unit start-up, service, and operation, refer to the unit Controls, Start-Up, Operation, Service, and Troubleshooting Instructions also enclosed in the unit literature packet.

TABLE OF CONTENTS


SAFETY CONSIDERATIONS	1
INSTALLATION	2
Step 1 - Provide Unit Support	2
Step 2 - Rig and Place Unit	2
Step 3 - Field Fabricate Ductwork	7
Step 4 - Make Unit Duct Connections	8
Step 5 - Install Flue Hood and Inlet Hood	8
Step 6 - Install External Trap for Condensate Drain	9
Step 7 - Orifice Change	10
Step 8 - Install Gas Piping	10
Step 9 - Make Electrical Connections	11
Step 10 - Install Outdoor-Air Hoods	16
Step 11 - Install All Accessories	16
Step 12 - Configure Controls	16

SAFETY CONSIDERATIONS


Installation and servicing of air-conditioning equipment can be hazardous due to system pressure and electrical components. Only trained and qualified service personnel should install, repair, or service air-conditioning equipment.

Untrained personnel can perform the basic maintenance functions of cleaning coils and filters and replacing filters. All other operations should be performed by trained service personnel. When working on air-conditioning equipment, observe precautions in the literature, tags and labels attached to the unit, and other safety precautions that may apply.

Follow all safety codes. Wear safety glasses and work gloves.

Recognize safety information. This is the safety-alert symbol . When you see this symbol on the unit and in instructions or manuals, be alert to the potential for personal injury.


Understand the signal words DANGER, WARNING, and CAUTION. These words are used with the safety-alert symbol. DANGER identifies the most serious hazards which **will** result in severe personal injury or death. WARNING signifies a hazard which **could** result in personal injury or death. CAUTION is used to identify unsafe practices which **may** result in minor personal injury or product and property damage. NOTE is used to highlight suggestions which **will** result in enhanced installation, reliability, or operation.

 WARNING

ELECTRICAL SHOCK HAZARD

Failure to follow this warning could result in personal injury or death.

Before performing service or maintenance operations on unit, turn off main power switch to unit.

 WARNING

UNIT OPERATION AND SAFETY HAZARD

Failure to follow this warning could result in personal injury or equipment damage.

Puron® refrigerant systems operate at higher pressures than standard R-22 systems. Do not use R-22 service equipment or components on Puron refrigerant equipment.

⚠ WARNING

FIRE, EXPLOSION HAZARD

Failure to follow this warning could result in personal injury, death and/or property damage.

1. Improper installation, adjustment, alteration, service, or maintenance can cause property damage, personal injury, or loss of life. Refer to the User's Information Manual provided with this unit for more details.
2. Do not store or use gasoline or other flammable vapors and liquids in the vicinity of this or any other appliance.

What to do if you smell gas:

1. DO NOT try to light any appliance.
2. DO NOT touch any electrical switch, or use any phone in your building.
3. IMMEDIATELY call your gas supplier from a neighbor's phone. Follow the gas supplier's instructions.
4. If you cannot reach your gas supplier, call the fire department.

⚠ WARNING

FIRE, EXPLOSION HAZARD

Failure to follow this warning could result in personal injury or death.

Disconnect gas piping from unit when pressure testing at pressure greater than 0.5 psig. Pressures greater than 0.5 psig will cause gas valve damage resulting in hazardous condition. If gas valve is subjected to pressure greater than 0.5 psig, it *must* be replaced before use. When pressure testing field-supplied gas piping at pressures of 0.5 psig or less, a unit connected to such piping must be isolated by closing the manual gas valve(s).

IMPORTANT: Units have high ambient operating limits. If limits are exceeded, the units will automatically lock the compressor out of operation. Manual reset will be required to restart the compressor.

INSTALLATION

Step 1 — Provide Unit Support

Roof Curb

Assemble or install accessory roof curb in accordance with instructions shipped with this accessory. (See Fig. 1.) Install insulation, cant strips, roofing, and counter flashing as shown. Ductwork can be installed to roof curb before unit is set in place. Ductwork must be attached to curb and not to the unit. Curb must be level. This is necessary to permit unit drain to function properly. Unit leveling tolerance is $\pm 1/16$ -in. per linear ft in any direction. Refer to Accessory Roof Curb Installation Instructions for additional information as required. When accessory roof curb is used, unit may be installed on class A, B, or C roof covering material. Carrier roof curb accessories are for flat roofs or slab mounting.

IMPORTANT: The gasketing of the unit to the roof curb is critical for a watertight seal. Install gasket with the roof curb as shown in Fig. 1 and 3. Improperly applied gasket can also result in air leaks and poor unit performance. Do not slide unit to position on roof curb.

Alternate Unit Support

When a curb cannot be used, install unit on a noncombustible surface. Support unit with sleepers, using unit curb support area. If sleepers cannot be used, support long sides of unit with a minimum of 3 equally spaced 4-in. x 4-in. pads on each side.

Step 2 — Rig and Place Unit

Inspect unit for transportation damage. See Table 1 for physical data. File any claim with transportation agency.

⚠ CAUTION

UNIT DAMAGE HAZARD

Failure to follow this caution may result in equipment damage.

All panels must be in place when rigging. Unit is not designed for handling by fork truck.

Do not drop unit; keep upright. Use wooden top skid or spreader bars over unit to prevent sling or cable damage. Rollers may be used to move unit across a roof. Level by using unit rail as a reference; leveling tolerance is $\pm 1/16$ -in. per linear ft in any direction. See Fig. 3 for additional information. Unit rigging weight is shown in Fig. 3.

Rigging holes are provided in the unit base rails as shown in Fig. 2. Refer to rigging instructions on unit.

Although unit is weatherproof, guard against water from higher level runoff and overhangs.

Positioning

Maintain clearance, per Fig. 2, around and above unit to provide minimum distance from combustible materials, proper airflow, and service access. See Fig. 4 for panel and filter location.

Do not install unit in an indoor location. Do not locate air inlets near exhaust vents or other sources of contaminated air. For proper unit operation, adequate combustion and ventilation air must be provided in accordance with Section 5.3 (Air for Combustion and Ventilation) of the National Fuel Gas Code, ANSI Z223.1 (American National Standards Institute).




Fig. 1 - Roof Curb Details

- NOTES: DIMENSIONS SHOWN ARE FOR 48PG (HT HEAT) UNIT WITH ALUMINUM COILS AND STANDARD DRIVE FOR WEIGHTS OF OPTIONAL EQUIPMENT CONSULT PRODUCT DATA BOOK.
- DO NOT LOCATE ADJACENT UNITS WITH FLUE DISCHARGE MIN. CLEARANCES TO BE:
 - FRONT 48 INCHES TO COMBUSTIBLE SURFACES (18 INCHES WHEN USING ACCESSORY FLUE DISCHARGE DEFLECTOR WHEN NOT USING REMOVAL 5/4" MIN. CLEARANCE FOR COMPLETE CONDENSATE PAN REMOVAL FOR SERVICE ACCESS TO ECONOMIZER ALLOW 4' 0" FROM LEFT SIDE
 - CONDENSER AIRFLOW (6 INCHES) TO ASSURE PROPER CONDENSER OPERATION BETWEEN UNIT AND CONTROL BOX (42 INCHES PER NEC)
 - BETWEEN UNIT AND UNGROUNDED SURFACE CONTROL BOX SIDE (45 INCHES PER NEC)
 - GROUND SURFACES CONTROL BOX SIDE (42 INCHES) PER NEC. CLEARANCE IN FRONT OF INDOOR MOTOR ACCESS FOR BLOWER SELED
 - REMOVAL 5/4" MIN. CLEARANCE FOR COMPLETE CONDENSATE PAN REMOVAL FOR SERVICE ACCESS TO ECONOMIZER ALLOW 4' 0" FROM LEFT SIDE
 - HORIZONTAL SUPPLY AND RETURN (10 INCHES)
 - DO NOT SHOT DUCTS DESIGNED TO BE ATTACHED TO ACCESSORY CONDENSATE DRAIN (SEE NOTE #1)
 - CROSS BRACES AS DONE ON ACCESSORY ROOF CURB
 - DIMENSIONS IN 1. ARE IN MILLIMETERS OR KILOGRAMS
 - 2. WHEREVER THERE IS A CLEARANCE OR BRIDGE OVER THE CONDENSER COIL, STATED IN NOTE #5, A REMOVABLE FENCE OR BARRICADE REQUIRES NO CLEARANCE.
 - DIMENSIONS ARE FROM OUTSIDE OF BASE RAIL COVER TOP EDGE. UNITS MAY BE INSTALLED ON COMBUSTIBLE FLOORS MADE FROM CLASS A, B, C ROOF COVERING MATERIAL IF SET ON BASE RAILS.

UNIT	S.D. UNIT WEIGHT (A)		CORNER WEIGHT (B)		CORNER WEIGHT (C)		CORNER WEIGHT (D)	
	LB	KG	LB	KG	LB	KG	LB	KG
48PG08	127.7	58.2	269	122	237	108	333	151
48PG09	122.4	55.5	271	123	238	108	333	152
48PG12	132.4	60.1	293	133	258	117	362	164
48PG14	140.0	63.5	310	140	273	124	363	174
								435




Fig. 2 - Base Unit Dimensions

**⚠ CAUTION - NOTICE TO RIGGERS:
ACCESS PANEL MUST BE IN PLACE WHEN RIGGING.**

Hook rigging shackles through holes in base rail, as shown in Detail A. Holes in base rails are centered around the unit center of gravity. Use wooden top skid, when rigging, to prevent rigging straps from damaging unit.

UNIT SIZE	A		B		C		D		E		MAX. WEIGHT	
	in.	mm	in.	mm	in.	mm	in.	mm	in.	mm	lb	kg
08-14	90.4	2296	36-54	914-1371	52.4	1331	48.0	1219	26.3	668	1617	735




Fig. 3 - 48PG Rigging Label

C07192

Table 1 – Physical Data

BASE UNIT 48PG		08	09	12	14
NOMINAL CAPACITY (Tons)		7 ¹ / ₂	8 ¹ / ₂	10	12 ¹ / ₂
OPERATING WEIGHT (lb)					
Unit*		1217	1224	1324	1400
Economizer					
Vertical		57	57	57	57
Horizontal		59	59	59	59
Humidi-MiZer™ System		45	45	44	45
Roof Curb					
14-in.		180	180	180	180
24-in.		268	268	268	268
COMPRESSOR		Fully Hermetic Scroll			
Quantity		2	2	2	2
Oil Type Sys A		Copeland 3MA	Copeland 3MA	Copeland 3MA	Copeland 3MA
Sys B		Copeland 3MA	Copeland 3MA	Copeland 3MA	Copeland 3MA
Number of Refrigerant Circuits		2	2	2	2
Oil (oz) Sys A		42	42	66	56
Sys B		42	42	66	56
REFRIGERANT TYPE		R-410A (Puron® Refrigerant)			
Expansion Device		TXV	TXV	TXV	TXV
Operating Charge (lb) Sys A		11.8	11.3	13.7	17.2
Sys B		11.8	11.3	13.7	17.2
Operating Charge Total All Systems (lb)		23.5	22.6	27.4	34.4
Unit with Humidi-MiZer System					
Operating Charge (lb) Sys A		16.5	16.25	17.7	22.5
Sys B		16.7	16.25	18.2	21.8
Total All Systems (lb)		33.2	32.5	35.9	44.3
CONDENSER COIL		Enhanced Copper Tubes, Aluminum Lanced Fins, Face Split			
Condenser A (Outer)					
Rows...Fins/in.		2...17	2...17	2...17	3...17
Face Area (sq ft)		17.4	17.4	17.4	17.4
Condenser B (Inner)					
Rows...Fins/in.		2...17	2...17	2...17	3...17
Face Area (sq ft)		17.4	17.4	17.4	17.4
Humidi-MiZer Coil					
Rows...Fins/in.		1...17	1...17	1...17	1...17
Face Area (sq ft)		14.9	14.9	14.9	14.9
CONDENSER FAN		Propeller			
Quantity...Diameter (in.)		2...24	2...24	2...24	2...24
Nominal Cfm (Total, all fans)		7204	7204	8241	7300
Motor Hp		1/4	1/4	1/3	1/3
Nominal Rpm		1100	1100	1100	1100
EVAPORATOR COIL		Enhanced Copper Tubes, Aluminum Double-Wavy Fins, Face Split			
Rows...Fins/in.		3...15	3...15	4...15	4...15
Face Area (sq ft)		14.9	14.9	14.9	14.9
EVAPORATOR FAN		Centrifugal Type, Belt Drive			
Quantity...Size (in.)		Low 1...15 x 15	1...15 x 15	1...15 x 15	1...15 x 15
High		1...15 x 15	1...15 x 15	1...15 x 15	1...15 x 15
Type Drive		Low Belt	Belt	Belt	Belt
High		Belt	Belt	Belt	Belt
Nominal Cfm		3000	3400	4000	5000
Maximum Continuous Bhp		Low 2.4	2.4	3.1	3.7
High		3.1	3.7	3.7	5.25
Motor Nominal Rpm		1725	1725	1725	1725
Motor Frame Size		Low 56Y	56Y	56Y	56Y
High		56Y	56Y	56Y	56Y
Fan Rpm Range		Low 568-771	568-771	690-893	690-893
High		812-1015	812-1015	852-1055	852-1055
Motor Bearing Type		Ball	Ball	Ball	Ball
Maximum Fan Rpm		1600	1600	1600	1600
Motor Pulley Pitch Diameter Range (in.)		Low 2.8-3.8	2.8-3.8	3.4-4.4	3.4-4.4
High		4.0-5.0	4.0-5.0	4.6-5.6	4.6-5.6
Fan Pulley Pitch Diameter		Low 8.5	8.5	8.5	8.5
High		8.5	8.5	8.5	8.5
Nominal Motor Shaft Diameter (in.)		Low 5/8	5/8	7/8	7/8
High		7/8	7/8	7/8	7/8
Belt...Pitch Length (in.)		Low 63.3	63.3	63.3	63.3
High		65.3	65.3	65.3	65.3
Belt...Type		Low AX	AX	AX	AX
High		AX	AX	AX	AX
Pulley Center Line Distance Min. (in.)		Low 21.0	21.0	21.0	21.0
High		21.0	21.0	21.0	21.0
Pulley Center Line Distance Max. (in.)		Low 23.4	23.4	23.4	23.4
High		23.4	23.4	23.4	23.4
Speed Change per Full Turn of Movable Pulley Flange (rpm)		Low 41	41	41	41
High		41	41	41	41
Movable Pulley Maximum Full Turns from Closed Position		Low 5	5	5	5
High		5	5	5	5
Factory Pulley Setting (rpm)		Low 568	568	690	690
High		812	812	852	852
Fan Shaft Diameter at Pulley (in.)		1	1	1	1

48PG08--14

See Legend on next page.

Table 1 — Physical Data (cont)

BASE UNIT 48PG		08	09	12	14
GAS HEAT SECTION					
Rollout Switch					
Open Temperature (F)	Low	225	225	225	225
	Med	225	225	225	225
	High	225	225	225	225
Closed Temperature (F)	Low	175	175	175	175
	Med	175	175	175	175
	High	175	175	175	175
Gas Input (Btuh) Stage 1 /Stage 2	PGD/L	95,200/136,000	95,200/136,000	126,700/181,000	126,700/181,000
	PGE/M	126,700/181,000	126,700/181,000	158,200/226,000	158,200/226,000
	PGF/N	158,200/226,000	158,200/226,000	174,300/249,000	174,300/249,000
Burner Orifice Diameter (in. ...drill size)†					
Natural Gas		0.089...43	0.089...43	0.089...43	0.089...43
Liquid Propane		0.070...50	0.070...50	0.070...50	0.070...50
Thermostat Heat Anticipator Setting (amps)					
First Stage		.14	.14	.14	.14
Second Stage		.20	.20	.20	.20
Manifold Pressure (in. wg)					
Natural Gas		3.5	3.5	3.5	3.5
Liquid Propane		3.5	3.5	3.5	3.5
Gas Valve Quantity		1	1	1	1
Gas Supply Pressure Range (in. wg)		5.0-13.0	5.0-13.0	5.0-13.0	5.0-13.0
Field Gas Connection Size (in.)		3/4	3/4	3/4	3/4
HIGH-PRESSURE SWITCH (psig)					
Cutout		660 ± 10	660 ± 10	660 ± 10	660 ± 10
Reset (Auto.)		505 ± 20	505 ± 20	505 ± 20	505 ± 20
RETURN-AIR FILTERS					
Quantity...Size (in.)		Throwaway			
		4...20 x 25 x 2	4...20 x 25 x 2	4...20 x 25 x 2	4...20 x 25 x 2

48PG08-14

LEGEND

- TXV – Thermostatic Expansion Valve
- * Aluminum Evaporator Coil/Aluminum Condenser Coil.
- † For applications less than 2000 ft elevation.

Locate mechanical draft system flue assembly at least 4 ft from any opening through which combustion products could enter the building, and at least 4 ft from any adjacent building (or per local codes). When unit is located adjacent to public walkways, flue assembly must be at least 7 ft above grade. Locate unit at least 10 ft away from adjacent units.

Roof Mount

Check building codes for weight distribution requirements. Unit operating weight is shown in Table 1.

Installation Onto Curb

The 48PG units are designed to fit on the accessory full perimeter curb. Correct placement of the unit onto the curb is critical to operating performance. To aid in correct positioning, place unit on roof curb to maintain 1/4-in. gap between the inside of rail and roof curb on long sides and a 1/2-in. gap between the inside of rail and roof curb on both duct and condenser ends. Refer to Fig. 1 and 3, to assure proper duct opening alignment.

NOTE: Before positioning unit on curb, make sure bottom drain connection plug is tight. See Step 6-Install External Trap for Condensate Drain concerning bottom drain connection plug.

CAUTION

EQUIPMENT DAMAGE HAZARD

Failure to follow this caution may result in damage to unit.

Do not slide unit into position when it is sitting on the curb. Curb gasketing material may be damaged and leaks may result.

Slab Mount (Horizontal Units Only)

Provide a level concrete slab that extends a minimum of 6-in. beyond unit cabinet. Install a gravel apron in front of condenser-coil air inlet to prevent grass and foliage from obstructing airflow.

NOTE: Horizontal units may be installed on a roof curb if required.

Step 3 — Field Fabricate Ductwork

On vertical units, secure all ducts to roof curb and building structure. *Do not connect ductwork to unit.* For horizontal applications, field-supplied flanges should be attached to horizontal discharge openings and all ductwork secured to the flanges. Insulate and weatherproof all external ductwork, joints, and roof openings with counter flashing and mastic in accordance with applicable codes.

Ducts passing through an unconditioned space must be insulated and covered with a vapor barrier.

If a plenum return is used on a vertical unit, the return should be ducted through the roof deck to comply with applicable fire codes.

A minimum clearance is not required around ductwork. Cabinet return-air static pressure (a negative condition) shall not exceed 0.35-in. wg with economizer or 0.45-in. wg without economizer.

These units are designed for a minimum continuous return-air temperature in heating of 50°F (dry bulb), or an intermittent operation down to 45°F (dry bulb), such as when used with a night set-back thermostat.

To operate at lower return-air temperatures, a field-supplied outdoor-air temperature control must be used to initiate both stages of heat when the temperature is below 45°F. Indoor comfort may be compromised when these lower air temperatures are used with insufficient heating temperature rise.

Step 4 — Make Unit Duct Connections

Vertical Supply/Return Configuration

Unit is shipped in vertical supply/return configuration. Ductwork openings are shown in Fig. 1 and 2. Attach the ductwork to the roof curb. Do not attach duct directly to the unit.

⚠ WARNING

PERSONAL INJURY HAZARD

Failure to follow this warning could result in personal injury.

For vertical supply and return units, tools or parts could drop into ductwork and cause an injury. Install a 90-degree turn in the return ductwork between the unit and the conditioned space. If a 90-degree elbow cannot be installed, then a grille of sufficient strength and density should be installed to prevent objects from falling into the conditioned space.

Horizontal Supply/Return Applications

Unit can be field-converted from vertical supply/return to horizontal supply/return. Remove all screws securing horizontal duct covers to duct panel. Save panels. Install duct covers in the vertical duct openings in the basepan with the insulation side up. Covers will drop into openings and can be secured using field-supplied self-tapping screws. Ductwork can be attached to duct flanges provided on unit. When securing ductwork to unit, do


not drill in area below bead or above top edge of duct opening. Duct openings are shown in Fig. 1 and 3.

Step 5 — Install Flue Hood and Inlet Hood

Flue hood (smaller hood), inlet hood (larger hood), and screens are shipped inside the unit in the gas section. To install, open the gas section access door. The flue hood is attached to the gas section access door from the outside using the screws provided. See Fig. 4 and 5.


The inlet hood is installed by inserting the hood through the back of the gas section access door. Attach the hood by inserting the screws provided through the clearance holes in the gas section access door and into the intake hood.

NOTE: When properly installed, the flue hood will line up with the combustion fan housing exhaust. (See Fig. 6.)



C06257

Fig. 4 - Flue and Inlet Hood Locations



C06255

Fig. 5 - Panel and Filter Locations




Fig. 6 - Typical Gas Heating Section

C06258

Step 6 — Install External Trap for Condensate Drain

The unit's 3/4-in. condensate drain connections are located on the bottom and side of the unit. If the down drain is used, drill a minimum of a 5/8-in. diameter hole but not larger than a 3/4-in. diameter hole through the drain pan. A dimple of 2 mm in diameter and 1.5 mm deep will be provided in the drain pan to help locate the drill bit and to start the hole. Do not cut through the PVC pipe threads. Unit discharge connections do not determine the use of drain connections; either drain connection can be used with vertical or horizontal applications. See Fig. 3 for locations.

When using the standard side drain connection, make sure the plug (red) covering the alternate bottom connection is tight before installing the unit. (See Fig. 7.)

To use the bottom drain connection for a roof curb installation, relocate the factory-installed plug (red) from the bottom connection to the side connection. A 1/2-in. socket extension can be used to remove the plug. (See Fig. 7.) The piping for the condensate drain and external trap can be completed after the unit is in place.

All units must have an external trap for condensate drainage. Install a trap at least 4-in. deep and protect against freeze-up. If drain line is installed downstream from the external trap, pitch the line away from the unit at 1-in. per 10 ft of run. Do not use a pipe size smaller than the unit connection (3/4-in.). (See Fig. 8 and 9.)

The 48PG units are provided with a removable condensate pan for ease of cleaning. It is recommended that a union be placed between the unit and condensate drainage to ease the removal of the pan during servicing. Adequate clearance should be allowed if removal of condensate pan is required. Allow 54-in. between condensate pan access panel and any obstruction for complete removal.




Fig. 7 - Condensate Drain Pan

C10321





Fig. 8 - External Trap for Condensate Drain

C06234



NOTE: Trap should be deep enough to offset maximum unit static difference. A 4-in. trap is recommended.

C06291

Fig. 9 - Condensate Drain Piping Details

Step 7 — Orifice Change

This unit is factory assembled for heating operation using natural gas at an elevation from sea level to 2000 ft. This unit uses orifice type LH32RFnnn, where “nnn” indicates the orifice size based on drill size diameter in thousands of an inch.

High Elevation

Use accessory high altitude kit when installing this unit at an elevation of 2000 to 7000 ft. For elevations above 2000 ft, refer to Table 2 to identify the correct orifice size for the elevation. See Table 3 for the number of orifices required for each unit size. Purchase these orifices from your local Carrier dealer. Follow instructions in accessory Installation Instructions to install the correct orifices.

Table 2 – Altitude Compensation*

ELEVATION (ft)	NATURAL GAS ORIFICE†
0-1,999	43
2,000	44
3,000	44
4,000	44
5,000	45
6,000	45
7,000	47
8,000	47
9,000	47
10,000	48
11,000	49
12,000	50
13,000	50
14,000	51

*As the height above sea level increases, there is less oxygen per cubic foot of air. Therefore, heat input rate should be reduced at higher altitudes. Includes a 4% input reduction per each 1000 ft.

† Orifices available through your Carrier dealer.

Table 3 – Orifice Quantity

UNIT	08	09	12	14
Low Heat (48PGD/L)	6	6	8	8
Medium Heat (48PGE/M)	8	8	10	10
High Heat (48PGF/N)	10	10	11	11

Conversion to LP (Liquid Propane)

Use accessory LP gas conversion kit when converting this unit for use with LP fuel usage for elevations up to 7000 ft. Refer to Table 4 to identify the correct orifice size for the elevation. See Table 3 for the number of orifices required for each unit size. For elevations above 7000 ft, orifices are not included in accessory and must be purchased from your local Carrier dealer. Follow instructions in accessory Installation Instructions to install the correct orifices.

Table 4 – LP Gas Conversion*

ELEVATION (ft)	LP GAS ORIFICE†
0-1,999	50
2,000	51
3,000	51
4,000	51
5,000	51
6,000	52
7,000	52
8,000	52
9,000	53
10,000	53
11,000	53
12,000	54
13,000	54
14,000	55

*As the height above sea level increases, there is less oxygen per cubic foot of air. Therefore, heat input rate should be reduced at higher altitudes. Includes a 4% input reduction per each 1000 ft.

†Orifices available through your Carrier dealer.

Step 8 — Install Gas Piping

Unit is equipped for use with natural gas. Refer to local building codes, or in the absence of local codes, to ANSI Z223.1-latest year and addendum Z223.1A-latest year entitled HFGC. In Canada, installation must be in accordance with the CAN1.B149.1 and CAN1.B149.2 installation codes for gas burning appliances.

Support gas piping as shown in the table in Fig. 10. For example, a 3/4-in. gas pipe must have one field-fabricated support beam every 8 ft. Therefore, an 18-ft long gas pipe would have a minimum of 3 support beams. See Fig. 10 for typical pipe guide and locations of external manual gas shutoff valve.

Install field-supplied manual gas shutoff valve with a 1/8-in. NPT pressure tap for test gauge connection at unit. The pressure tap is located on the gas manifold, adjacent to the gas valve. Field gas piping must include sediment trap and union. (See Fig. 11.) Install a field-supplied gas regulator.


⚠ WARNING

FIRE, EXPLOSION HAZARD

Failure to follow this warning could result in personal injury or death.

Do not pressure test gas supply while connected to unit. Always disconnect union before servicing. High pressures can cause gas valve damage resulting in a hazardous condition.

IMPORTANT: Natural gas pressure at unit gas connection must not be less than 5.0-in. wg or greater than 13.0-in. wg for all heat sizes.



NFGC — National Fuel Gas Code

*Field supplied.


NOTE: Follow all local codes.

SPACING OF SUPPORTS

STEEL PIPE NOMINAL DIAMETER (in.)	SPACING OF SUPPORTS X DIMENSION (ft)
1/2	6
3/4 or 1	8
1 1/4 or larger	10

C06115

Fig. 10 - Gas Piping Guide (With Accessory Thru-the-Cab Service Connections)



C06236

Fig. 11 - Field Gas Piping

Size gas-supply piping for 0.5-in. wg maximum pressure drop. Do not use supply pipe smaller than unit gas connection.

Step 9 — Make Electrical Connections

(For more details, refer to the Controls, Start-Up, Operation and Troubleshooting Manual)

Field Power Supply

All 208/230-v units are factory wired for 230-v power supply. If the 208/230-v unit is to be connected to a 208-v power supply, the transformers (TRAN1 and TRAN2) must be rewired by moving the black wire with the 1/4-in. female quick connect from the 230-volt connection and moving to the 200-volt 1/4-in. male terminal on the primary side of the transformer.

Refer to unit label diagram for additional information. Leads are provided for field wire connections. Use UL (Underwriters Laboratories) approved copper/aluminum connector.

When installing units, provide safety disconnect per NEC (National Electrical Code) Article 440 or local codes. For non-fused disconnects, size the disconnect according to the sizing data provided in the electrical data tables. If a fused disconnect is used, determine the minimum size for the switch based on the disconnect sizing data provided in the electrical data tables and then coordinate the disconnect housing size to accommodate the Maximum Overcurrent Protection (MOCP) device size as marked on the unit informative plate. (See Table 5 and 6.) All field wiring must comply with NEC and local codes. Size wire based on MCA (Minimum Circuit Amps) on the unit informative plate. See Fig. 12 for power wiring connection to the unit leads and equipment ground.


Route power and ground lines through control box end panel or unit basepan (see Fig. 3) to connections as shown on unit wiring diagram and Fig. 12. Factory leads may be wired directly to the disconnect.

⚠ CAUTION

UNIT DAMAGE HAZARD

Failure to follow this caution may result in equipment damage.

The correct power phasing is critical to the operation of the scroll compressors. An incorrect phasing will result in compressor shutdown on thermal overload and possible damage to compressor. Should this occur, power phase correction must be made to the incoming power.



C06237

Fig. 12 - Field Power Wiring Connections

⚠ WARNING

ELECTRICAL SHOCK HAZARD

Failure to follow this warning could result in personal injury or death.

Unit cabinet must have an uninterrupted, unbroken electrical ground to minimize the possibility of personal injury if an electrical fault should occur. This ground may consist of electrical wire connected to unit ground lug in control compartment, or conduit approved for electrical ground when installed in accordance with NEC; ANSI (American National Standards Institute)/NFPA (National Fire Protection Association), latest edition, and local electrical codes. *Do not use gas piping as an electrical ground.*

Field wiring must conform to temperature limitations for type “T” wire. All field wiring must comply with NEC and local requirements.

Operating voltage to compressor must be within voltage range indicated on unit nameplate. Voltages between phases must be balanced within 2%.

Unit failure as a result of operation on improper line voltage or excessive phase imbalance constitutes abuse and may cause damage to electrical components.

Field Control Wiring (Units Without Optional Humidi-MiZer™ Adaptive Dehumidification System)

Unit can be controlled with either a Carrier-approved accessory thermostat or a Carrier-approved space temperature sensor. Install thermostat according to the installation instructions included with accessory. Locate thermostat assembly or space temperature sensor on a solid interior wall in the conditioned space to sense average temperature.

Route thermostat or space temperature sensor cable or equivalent single leads of colored wire from subbase terminals through conduit into unit to low-voltage connections as shown on unit label wiring diagram and in Fig. 13 or 14.




Fig. 13 - Field Control Thermostat Wiring

C06292

Temperature Control

The unit can be controlled with either a Carrier-approved space temperature sensor, a Carrier accessory Thermidstat device, or a Carrier-approved accessory thermostat. Install the temperature control device according to the installation instructions included with the accessory. Locate the device on a solid interior wall in the conditioned space to sense average temperature. Carrier space temperature sensor wiring connections are shown in Fig. 14. General thermostat field control wiring connections are shown in Fig. 13. Carrier Thermidstat device wiring connections are shown in Fig. 15. Configuration of the unit control is required to specify the control input type before unit operation.

Route thermostat or space temperature sensor cable or equivalent single leads of colored wire from subbase terminals through conduit into unit to low-voltage connections as shown on unit label wiring diagram and in Fig. 13-15.

NOTE: For wire runs up to 50 ft, use no. 18 AWG (American Wire Gauge) insulated wire (35°C minimum). For 50 to 75 ft, use no. 16 AWG insulated wire (35°C minimum). For over 75 ft, use no. 14 AWG insulated wire (35°C minimum). All wire larger than no. 18 AWG cannot be directly connected at the thermostat and will require a junction box and splice at the thermostat.




Fig. 15 - Field Control Thermidstat Wiring

C07055




Fig. 14 - Field Control Space Temperature Sensor Wiring

C06239

NOTE: For wire runs up to 50 ft, use no. 18 AWG (American Wire Gauge) insulated wire (35°C minimum). For 50 to 75 ft, use no. 16 AWG insulated wire (35°C minimum). For over 75 ft, use no. 14 AWG insulated wire (35°C minimum). All wires larger than no. 18 AWG cannot be directly connected at the thermostat and will require a junction box and splice at the thermostat.

Set heat anticipator settings as follows:

VOLTAGE	STAGE 1 (W1) ON	STAGE 1 AND 2 (W1 AND W2) ON
All	0.14	0.20

Settings may be changed slightly to provide a greater degree of comfort for a particular installation.

Field Control Wiring (Units with Optional Humidi-MiZer Adaptive Dehumidification System)

Units require temperature control inputs for cooling and heating operation and humidity control inputs for Humidi-MiZer operation.

Set heat anticipator settings as follows:

VOLTAGE	STAGE 1 (W1) ON	STAGE 1 AND 2 (W1 AND W2) ON
All	0.14	0.20

Settings may be changed slightly to provide a greater degree of comfort for a particular installation.

Humidity Control

Unit can be controlled with either a Carrier accessory Thermidstat device or a Carrier-approved accessory humidistat (switch output). The input for an accessory humidity sensor with 4 to 20 mA output is another option available when an economizer board is installed. Install the humidity control device according to the installation instructions included with the accessory. Locate the device on a solid interior wall in the conditioned space to sense average humidity. Carrier Thermidstat device wiring connections are shown in Fig. 15. General humidistat wiring connections are shown in Fig. 16. Configuration of the unit control is required to specify the control input type before unit operation. Refer to the Controls, Start-up, Operation and Troubleshooting manual for configuration.

Units with the Humidi-MiZer option receive a discrete input from a field-installed device (such as from the Carrier humidistat or Thermidstat device). The discrete input is connected to the TB1 terminal strip points labeled Humidistat 1 and 2. As this is a discrete input, one of the connection points is for power to the switch and the other is the return path. (See Fig. 16.)

A space relative humidity sensor input (SPRH) is only available if an economizer board (ECB) is installed in the unit and then the sensor can be connected to the OAQ point TB1-4. (See Fig. 16.) This input is used instead of the discrete humidistat or thermidstat inputs. The input controls the Humidi-MiZer™ using the 4 to 20 mA as percent humidity. The relative humidity value (measured by the relative humidity sensor) can be displayed on the Scrolling Marquee, in the space through a System Pilot™ device, or can be read by other CCN devices where it can be used to perform more advanced functions. The humidity sensor must be configured correctly. Refer to the Controls, Start-up, Operation, and Troubleshooting manual for details.

If the customer also wishes to install a smoke detector into a Humidi-MiZer equipped 48PG unit, the fire shutdown connection points are on Plug PL-19, located in the economizer section. See the unit wiring schematic for wiring. For third-party smoke detector, refer to Fig. 17.

Point 19-3 is the 24 vac power source for the detector. Point 19-4 is 24 vac power for the indoor fan contactor control. Point 19-5 is the 24 vac signal input for fire shutdown. If an immediate fan shutdown is desired, install a normally closed contactor between 19-3 and 19-4.

More information is available in the third party control section of the Controls, Start-up, Operation, and Troubleshooting manual.




Fig. 16 - Humidi-MiZer Low-Voltage Terminal Strip - Humidity Sensor/Humidistat Wiring

C07045




Fig. 17 - Third-Party Smoke Detector on Humidi-MiZer Units

C07238

Table 5 – Electrical Data — Units Without Optional Powered Convenience Outlet

UNIT 48PG	NOMINAL POWER SUPPLY (V-Ph-Hz)	VOLTAGE RANGE		COMPRESSOR (Each)		OFM		COMBUSTION FAN MOTOR FLA	PWR EXH FLA (ea)	IFM TYPE	IFM FLA	POWER SUPPLY		DISCONNECT SIZE	
		Min	Max	RLA	LRA	Qty	FLA (ea)					MCA	MOCP	FLA	LRA
08	208/230-3-60	187	253	13.5	88	2	1.5	0.52	—	Low	5.2	38.6/38.6	40/40	40/40	212/212
										High	7.5	40.9/40.9	45/45	43/43	238/238
										3.0	Low	5.2	41.6/41.6	45/45	44/44
	460-3-60	414	506	6.4	39	2	0.8	0.30	—	Low	2.6	18.6	20	20	97
										High	3.4	19.4	20	20	110
										1.2	Low	2.6	19.8	20	21
	575-3-60	518	633	5.1	34	2	0.8	0.24	—	Low	2.0	15.1	20	16	83
										High	2.8	15.9	20	17	94
										3.0	Low	2.0	18.1	20	19
09	208/230-3-60	187	253	16.0	91	2	1.5	0.52	—	Low	5.2	44.2/44.2	45/45	46/46	218/218
										High	10.2	49.2/49.2	50/50	52/52	261/261
										3.0	Low	5.2	47.2/47.2	50/50	50/50
	460-3-600	414	506	7.1	46	2	0.8	0.30	—	Low	2.6	20.2	25	21	111
										High	4.8	22.4	25	24	133
										1.2	Low	2.6	21.4	25	23
	575-3-60	518	633	5.6	37	2	0.8	0.24	—	Low	2.0	16.2	20	17	89
										High	2.8	17	20	18	100
										3.0	Low	2.0	19.2	20	20
12	208/230-3-60	187	253	17.6	123	2	1.9	0.52	—	Low	7.5	50.9/50.9	60/60	53/53	310/310
										High	10.2	53.6/53.6	60/60	57/57	327/327
										3.0	Low	7.5	53.9/53.9	60/60	57/57
	460-3-60	414	506	7.7	50	2	1.0	0.30	—	Low	3.4	22.7	25	24	132
										High	4.8	24.1	25	26	141
										1.2	Low	3.4	23.9	25	25
	575-3-60	518	633	6.1	40	2	0.8	0.24	—	Low	2.8	18.1	20	19	106
										High	2.8	18.1	20	19	106
										3.0	Low	2.8	21.1	25	23
14	208/230-3-60	187	253	22.4	149	2	1.9	0.52	—	Low	10.2	64.4/64.4	70/70	68/68	379/379
										High	15.0	69.2/69.2	70/70	73/73	388/388
										3.0	Low	10.2	67.4/67.4	70/70	71/71
	460-3-60	414	506	10.6	75	2	1.0	0.30	—	Low	4.8	30.7	35	32	191
										High	7.4	33.3	35	35	195
										1.2	Low	4.8	31.9	35	34
	575-3-60	518	633	7.7	54	2	0.8	0.24	—	Low	2.8	21.7	25	23	134
										High	5.6	24.5	25	26	148
										3.0	Low	2.8	24.7	25	26
High	5.6	27.5	30	29	152										

48PG08--14

LEGEND

- FLA – Full Load Amps
- HACR – Heating, Air Conditioning and Refrigeration
- IFM – Indoor (Evaporator) Fan Motor
- LRA – Locked Rotor Amps
- MCA – Minimum Circuit Amps
- MOCP – Maximum Overcurrent Protection
- NEC – National Electrical Code
- OFM – Outdoor (Condenser) Fan Motor
- RLA – Rated Load Amps



Example: Supply voltage is 230–3–60



AB = 224 v
 BC = 231 v
 AC = 226 v
 Average Voltage = $\frac{224 + 231 + 226}{3}$
 = $\frac{681}{3}$
 = 227

Determine maximum deviation from average voltage.

- (AB) 227 – 224 = 3 v
 - (BC) 231 – 227 = 4 v
 - (AC) 227 – 226 = 1 v
- Maximum deviation is 4 v.

Determine percent of voltage imbalance.

% Voltage Imbalance = $100 \times \frac{4}{227}$
 = 1.76%

This amount of phase imbalance is satisfactory as it is below the maximum allowable 2%.

IMPORTANT: If the supply voltage phase imbalance is more than 2%, contact your local electric utility company immediately.

NOTES:

1. In compliance with NEC requirements for multimotor and combination load equipment (refer to NEC Articles 430 and 440), the overcurrent protective device for the unit shall be fuse or HACR breaker. Canadian units may be fuse or circuit breaker.
2. **Unbalanced 3-Phase Supply Voltage**
Never operate a motor where a phase imbalance in supply voltage is greater than 2%. Use the following formula to determine the percentage of voltage imbalance.

% Voltage Imbalance = $100 \times \frac{\text{max voltage deviation from average voltage}}{\text{average voltage}}$

Table 6 – Electrical Data — Units With Optional Convenience Outlet

UNIT 48PG	NOMINAL POWER SUPPLY (V-Ph-Hz)	VOLTAGE RANGE		COMPRESSOR (Each)		OFM		COMBUSTION FAN MOTOR FLA	PWR EXH FLA (ea)	IFM TYPE	IFM FLA	POWER SUPPLY		DISCONNECT SIZE	
		Min	Max	RLA	LRA	Qty	FLA (ea)					MCA	MOCP	FLA	LRA
08	208/230-3-60	187	253	13.5	88	2	1.5	0.52	—	Low	5.2	43.4/43.4	45/45	46/46	217/217
									High	7.5	45.7/45.7	50/50	49/49	243/243	
		3.0	Low	5.2	46.4/46.4	50/50	49/49	221/221							
			High	7.5	48.7/48.7	50/50	52/52	247/247							
	460-3-60	414	506	6.4	39	2	0.8	0.30	—	Low	2.6	20.8	25	22	99
									High	3.4	21.6	25	23	112	
		1.2	Low	2.6	22	25	23	102							
			High	3.4	22.8	25	24	115							
	575-3-60	518	633	5.1	34	2	0.8	0.24	—	Low	2.0	16.8	20	18	85
									High	2.8	17.6	20	19	96	
		3.0	Low	2.0	19.8	20	21	89							
			High	2.8	20.6	25	22	100							
09	208/230-3-60	187	253	16.0	91	2	1.5	0.52	—	Low	5.2	49.0/49.0	50/50	52/52	223/223
									High	10.2	54.0/54.0	60/60	58/58	266/266	
		3.0	Low	5.2	52.0/52.0	60/60	55/55	227/227							
			High	10.2	57.0/57.0	60/60	61/61	270/270							
	460-3-60	414	506	7.1	46	2	0.8	0.30	—	Low	2.6	22.4	25	24	113
									High	4.8	24.6	25	26	135	
		1.2	Low	2.6	23.6	25	25	116							
			High	4.8	25.8	30	28	138							
	575-3-60	518	633	5.6	37	2	0.8	0.24	—	Low	2.0	17.9	20	19	91
									High	2.8	18.7	20	20	102	
		3.0	Low	2.0	20.9	25	22	95							
			High	2.8	21.7	25	23	106							
12	208/230-3-60	187	253	17.6	123	2	1.9	0.52	—	Low	7.5	55.7/55.7	60/60	59/59	315/315
									High	10.2	58.4/58.4	60/60	62/62	332/332	
		3.0	Low	7.5	58.7/58.7	60/60	62/62	319/319							
			High	10.2	61.4/61.4	70/70	66/66	336/336							
	460-3-60	414	506	7.7	50	2	1.0	0.30	—	Low	3.4	24.9	25	26	134
									High	4.8	26.3	30	28	143	
		1.2	Low	3.4	26.1	30	28	137							
			High	4.8	27.5	30	29	146							
	575-3-60	518	633	6.1	40	2	0.8	0.24	—	Low	2.8	19.8	20	21	108
									High	2.8	19.8	20	21	108	
		3.0	Low	2.8	22.8	25	24	112							
			High	2.8	22.8	25	24	112							
14	208/230-3-60	187	253	22.4	149	2	1.9	0.52	—	Low	10.2	69.2/69.2	70/70	73/73	384/384
									High	15.0	74.0/74.0	80/80	79/79	393/393	
		3.0	Low	10.2	72.2/72.2	80/80	77/77	388/388							
			High	15.0	77.0/77.0	80/80	82/82	397/397							
	460-3-60	414	506	10.6	75	2	1.0	0.30	—	Low	4.8	32.9	35	35	193
									High	7.4	35.5	40	38	197	
		1.2	Low	4.8	34.1	35	36	196							
			High	7.4	36.7	40	39	200							
	575-3-60	518	633	7.7	54	2	0.8	0.24	—	Low	2.8	23.4	25	25	136
									High	5.6	26.2	30	28	150	
		3.0	Low	2.8	26.4	30	28	140							
			High	5.6	29.2	30	31	154							

48PG08-14

LEGEND

- FLA – Full Load Amps
- HACR – Heating, Air Conditioning and Refrigeration
- IFM – Indoor (Evaporator) Fan Motor
- LRA – Locked Rotor Amps
- MCA – Minimum Circuit Amps
- MOCP – Maximum Overcurrent Protection
- NEC – National Electrical Code
- OFM – Outdoor (Condenser) Fan Motor
- RLA – Rated Load Amps



Example: Supply voltage is 230-3-60



AB = 224 v
 BC = 231 v
 AC = 226 v
 Average Voltage = $\frac{224 + 231 + 226}{3}$
 $= \frac{681}{3}$
 $= 227$

Determine maximum deviation from average voltage.

- (AB) 227 – 224 = 3 v
 - (BC) 231 – 227 = 4 v
 - (AC) 227 – 226 = 1 v
- Maximum deviation is 4 v.

Determine percent of voltage imbalance.

% Voltage Imbalance = $100 \times \frac{4}{227}$
 $= 1.76\%$

This amount of phase imbalance is satisfactory as it is below the maximum allowable 2%.

IMPORTANT: If the supply voltage phase imbalance is more than 2%, contact your local electric utility company immediately.

NOTES:

1. In compliance with NEC requirements for multimotor and combination load equipment (refer to NEC Articles 430 and 440), the overcurrent protective device for the unit shall be fuse or HACR breaker. Canadian units may be fuse or circuit breaker.

2. Unbalanced 3-Phase Supply Voltage

Never operate a motor where a phase imbalance in supply voltage is greater than 2%. Use the following formula to determine the percentage of voltage imbalance.

% Voltage Imbalance = $100 \times \frac{\text{max voltage deviation from average voltage}}{\text{average voltage}}$

Step 10 — Install Outdoor-Air Hoods (Units with Economizer)

Perform the following procedure to install the outdoor-air hoods:

1. Economizer and barometric relief hoods are stored in the condenser section under the slanted coil for shipping. (See Fig. 18.) Barometric relief/power exhaust hood is shipped inside of economizer hood. Remove screws that secure the wooden rails of the hood assemblies to the unit. Save the screws. Slide complete assembly from condenser section.
2. Remove the screws that secure the economizer and barometric relief/power exhaust hoods to the wooden railing. Discard or recycle wooden rails. Save the screws.
3. The barometric relief damper is secured to the economizer panel for shipping. Remove the screw holding the barometric relief damper to the economizer panel. Damper should be free to swing open during operation. (See Fig. 19.)
4. Hang the barometric relief/power exhaust hood on the mounting flange on the economizer panel. Secure hood to panel with screws saved from Step 2. (See Fig. 19 and 20.)
5. Align hole in flange of economizer panel with left edge of hood. Hang economizer hood on the top flange of the economizer panel by rotating hood until top flange of the economizer hood engages the bent flange on the economizer panel. Rotate hood until hood is flush with the economizer panel. Hood will support itself from flange. Align holes in hood with holes in panel and secure hood to panel with screws saved from Step 2. (See Fig. 19 and 21.)

Step 11 — Install All Accessories

After all of the factory-installed options have been adjusted, install all field-installed accessories. Refer to the accessory installation instructions included with each accessory.

Step 12 — Configure Controls

Refer to unit Controls and Troubleshooting book for information on configuring unit controls.




Fig. 19 - Hood Installation

C06260




Fig. 20 - Barometric Relief/Power Exhaust Hood Flange

C06262




Fig. 18 - Economizer and Barometric Relief/Power Exhaust Hoods Shipping Positions

C06290




Fig. 21 - Economizer Flange

C06263