

50LC

**Single Package Rooftop
Cooling Only
with Puron® (R-410A) Refrigerant
Sizes: 04, 05, 06**



Installation Instructions

NOTE: Read the entire instruction manual before starting the installation

TABLE OF CONTENTS


SAFETY CONSIDERATIONS	2	All Units	19
Rated Indoor Airflow (cfm)	3	Convenience Outlets	20
INSTALLATION	6	HACR	21
Jobsite Survey	6	Factory-Option Thru-Base Connections	21
Step 1 - Plan for Unit Location	6	Units without Thru-Base Connections	22
Roof Mount	6	Field Control Wiring	22
Step 2 - Plan for Sequence of Unit Installation	6	Thermostat	22
Curb-Mount Installation	6	Unit without Thru-Base Connection Kit	22
Pad-Mount Installation	7	Heat Anticipator Settings	23
Frame-Mount Installation	7	Electric Heaters	23
Step 3 - Inspect Unit	7	Single Point Boxes & Supplementary Fuses	24
Step 4 - Provide Unit Support	7	Single Point Boxes without Fuses	24
Roof Curb Mount	7	Low-Voltage Control Connections	24
Slab Mount (Horizontal Units Only)	7	Humidi-MiZer® Control Connections	25
Alternate Unit Support (In Lieu of Curb or Slab Mount)	7	Humidi-MiZer - Space RH Controller	25
Step 5 - Field Fabricate Ductwork	9	EconoMi\$er X (Factory-Installed Option)	27
For Units with Accessory Electric Heaters	9	SystemVu™ Controller (Factor-Installed Option) .	27
Step 6 - Rig and Place Unit	9	ComfortLINK (Factory-Installed Option)	27
Positioning on Curb	10	RTU Open Control System	29
Step 7 - Convert to Horizontal and Connect Ductwork	11	Supply Air Temperature (SAT) Sensor	32
Step 8 - Install Outside Air Hood	11	Outdoor Air Temperature (OAT) Sensor	33
Economizer Hood Package Removal and Setup — Factory Option	11	EconoMi\$er2	33
Economizer Hood Hood	12	Field Connections	33
Step 9 - Units with Hinged Panels Only	12	Space Temperature (SPT) Sensors	33
Step 10 - Install External Condensate Trap & Line ...	13	Indoor Air Quality (CO ₂) Sensor	34
Step 11 - Make Electrical Connections	13	Outdoor Air Quality Sensor	35
Field Power Supply	13	Space Relative Humidity Sensor or Humidistat ...	35
Units with Factory-Installed Non-Fused Disconnect or HACR	18	Smoke Detector/Fire Shutdown (FSD)	36
Units without Factory-Installed Non-Fused Disconnect or HACR	19	Connecting Discrete Inputs	36
		Communication Wiring - Protocols	37
		General	37
		Local Access	38
		RTU Open Troubleshooting	38

Outdoor Air Enthalpy Control 39
 Differential Enthalpy Control 39
 Return Air Enthalpy Sensor 39
 Smoke Detectors 40
 Step 12 - Adjust Factory-Installed Options 47
 Step 13 - Install Accessories 47
 APPENDIX - VFD Operation with Remote Keypad .. 48
 START-UP CHECKLIST 59


SAFETY CONSIDERATIONS

Improper installation, adjustment, alteration, service, maintenance, or use can cause explosion, fire, electrical shock or other conditions which may cause personal injury or property damage. Consult a qualified installer, service agency, or your distributor or branch for information or assistance. The qualified installer or agency must use factory-authorized kits or accessories when modifying this product. Refer to the individual instructions packaged with the kits or accessories when installing.

Follow all safety codes. Wear safety glasses and work gloves. Use quenching cloths for brazing operations and have a fire extinguisher available. Read these instructions thoroughly and follow all warnings or cautions attached to the unit. Consult local building codes and appropriate national electrical codes (in USA, ANSI/NFPA 70, National Electrical Code (NEC); in Canada, CSA C22.1) for special requirements.

It is important to recognize safety information. This is the safety-alert symbol . When you see this symbol on the unit and in instructions or manuals, be alert to the potential for personal injury.


Understand the signal words DANGER, WARNING, CAUTION, and NOTE. These words are used with the safety-alert symbol. DANGER identifies the most serious hazards which **will** result in severe personal injury or death. WARNING signifies hazards which **could** result in personal injury or death. CAUTION is used to identify unsafe practices, which **may** result in minor personal injury or product and property damage. NOTE is used to highlight suggestions which **will** result in enhanced installation, reliability, or operation.

 **WARNING**

ELECTRICAL SHOCK HAZARD

Failure to follow this warning could cause personal injury or death.


Before performing service or maintenance operations on unit, turn off main power switch to unit and install lock(s) and lockout tag(s). Ensure electrical service to rooftop unit agrees with voltage and amperage listed on the unit rating plate. Unit may have more than one power switch.

 **WARNING**

UNIT OPERATION AND SAFETY HAZARD

Failure to follow this warning could cause personal injury, death and/or equipment damage.

Puron® (R-410A) refrigerant systems operate at higher pressures than standard R-22 systems. Do not use R-22 service equipment or components on Puron refrigerant equipment.


 **WARNING**

PERSONAL INJURY AND ENVIRONMENTAL HAZARD

Failure to follow this warning could cause personal injury or death.

Relieve pressure and recover all refrigerant before system repair or final unit disposal.

Wear safety glasses and gloves when handling refrigerants. Keep torches and other ignition sources away from refrigerants and oils.

 **CAUTION**

CUT HAZARD

Failure to follow this caution may result in personal injury.

Sheet metal parts may have sharp edges or burrs. Use care and wear appropriate protective clothing, safety glasses and gloves when handling parts and servicing air conditioning equipment.

Rated Indoor Airflow (cfm)

The table to the right lists the rated indoor airflow used for the AHRI efficiency rating for the units covered in this document.

Model Number	Full Load Airflow (cfm)
50LC**04	1050
50LC**05	1400
50LC**06	1750

Position:	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18
Example:	5	0	L	C	D	0	0	6	A	1	A	5	-	0	A	0	A	0



<p>Unit Heat Type 50 - Electric Cooling/Heating Packaged Rooftop</p>	<p>Packaging 0 = Standard 1 = LTL</p>
<p>Model Series - WeatherExpert™ LC - Ultra High Efficiency</p>	<p>Electrical Options A = None B = HACR Circuit Breaker C = Non-Fused Disconnect D = Thru-The-Base Connections E = HACR Circuit Breaker and Thru-The Base Connections F = Non-Fused Disconnect and Thru-The-Base Connections</p>
<p>Heat Options 0 = Standard, No Electric Heat D = Low Electric Heat E = Medium Electric Heat F = High Electric Heat</p>	<p>Service Options 0 = None 1 = Unpowered Convenience Outlet 2 = Powered Convenience Outlet 3 = Hinged Panels 4 = Hinged Panels and Unpowered Convenience Outlet 5 = Hinged Panels and Powered Convenience Outlet</p>
<p>Refrig. Systems Options 0 = Two stage cooling capacity A = Two stage cooling capacity with Humidi-MiZer System (not available with ComfortLink controls)</p>	<p>Air Intake / Exhaust Options A = None B = Temperature Economizer with Barometric Relief E = Enthalpy Economizer with Barometric Relief N = Ultra Low Leak Temperature Economizer with Barometric Relief R = Ultra Low Leak Enthalpy Economizer with Barometric Relief</p>
<p>Cooling Tons 04 - 3 ton 05 - 4 ton 06 - 5 ton</p>	<p>Base Unit Controls 0 = Base Electromechanical Controls 1 = RTU Open Multi-Protocol Controller 2 = ComfortLink Controls (not available for units equipped with Humidi-MiZer option)</p>
<p>Sensor Options A = None B = RA Smoke Detector C = SA Smoke Detector D = RA + SA Smoke Detector E = CO₂ F = RA Smoke Detector and CO₂ G = SA Smoke Detector and CO₂ H = RA + SA Smoke Detector and CO₂</p>	<p>Design Revision - = Factory Design Revision</p>
<p>Indoor Fan Options 0 = Standard Electrical (Direct) Drive x13 ECM Motor 2 = Medium Static Belt Drive with VFD controller 3 = High Static Belt Drive with VFD controller</p>	<p>Voltage 1 = 575/3/60 5 = 208-230/3/60 6 = 460/3/60</p>
<p>Coil Options: Fin/Tube (Condenser- Evaporator - Hail Guard) A = Al/Cu - Al/Cu B = Precoat Al/Cu - Al/Cu C = E-coat Al/Cu - Al/Cu D = E-coat Al/Cu - E-coat Al/Cu E = Cu/Cu - Al/Cu F = Cu/Cu - Cu/Cu M = Al/Cu -Al/Cu — Louvered Hail Guard N = Precoat Al/Cu - Al/Cu — Louvered Hail Guard P = E-coat Al/Cu - Al/Cu — Louvered Hail Guard Q = E-coat Al/Cu - E-coat Al/Cu — Louvered Hail Guard R = Cu/Cu - Al/Cu — Louvered Hail Guard S = Cu/Cu - Cu/Cu — Louvered Hail Guard</p>	






50LC

Fig. 1 - 50LC 04-06 Model Number Nomenclature (Example)



C13385

NOTES:

1. DIMENSIONS ARE IN INCHES, DIMENSIONS IN [] ARE IN MILLIMETERS.
2.  CENTER OF GRAVITY
3.  DIRECTION OF AIR FLOW



Vertical Connections / Economizer



Horizontal Connections / Economizer

CONNECTION SIZES	
A	1 3/8" [35] DIA. FIELD POWER SUPPLY HOLE
B	2" [51] DIA. POWER SUPPLY KNOCKOUT
C	1 3/4" [44] DIA. GAUGE ACCESS PLUG
D	7/8" [22] DIA. FIELD CONTROL WIRING HOLE
E	3/4"-14 NPT CONDENSATE DRAIN
G	2 1/2" [64] DIA. POWER SUPPLY KNOCK-OUT

THRU-THE-BASE CHART THESE HOLES REQUIRED FOR USE CRBTMPWR001A01			
	THREADED CONDUIT SIZE	WIRE USE	REQ'D HOLE SIZES (MAX.)
	1/2"	ACC.	7/8" [22.2]
W	1/2"	24V	7/8" [22.2]
Y *	3/4" (001)	POWER	1 1/8" [28.4]
FOR "THRU-THE-BASEPAN" FACTORY OPTION, FITTINGS FOR ONLY X & Y ARE PROVIDED			
* SELECT EITHER 3/4" OR 1/2" FOR POWER, DEPENDING ON WIRE SIZE			

UNIT	J	K
50LC-004	33 3/8 [847]	18 5/8 [472]
50LC-005	41 3/8 [1051]	14 7/8 [377]
50LC-006	41 3/8 [1051]	14 7/8 [377]

Fig. 2 - Dimensional Drawing

50LC

UNIT	STD. UNIT WEIGHT*		CORNER WEIGHT (A)		CORNER WEIGHT (B)		CORNER WEIGHT (C)		CORNER WEIGHT (D)		C. G.		HEIGHT
	LBS.	KG.	LBS.	KG.	LBS.	KG.	LBS.	KG.	LBS.	KG.	X	Y	Z
50LC-004	458	208	128	58	109	49	101	46	120	54	34 1/8 [867]	22 1/2 [572]	19 3/4 [502]
50LC-005	545	247	156	71	135	61	118	54	136	62	34 5/8 [879]	21 3/4 [552]	20 7/8 [530]
50LC-006	550	249	160	73	136	62	117	53	138	63	34 1/8 [867]	21 5/8 [549]	20 1/4 [514]

*- STANDARD UNIT WEIGHT IS WITHOUT ELECTRIC HEAT AND WITHOUT PACKAGING.
FOR OTHER OPTIONS AND ACCESSORIES REFER TO THE PRODUCT DATA CATALOG.





Fig. 2 - Unit Dimensional Drawing (cont.)

C12099

50LC



C08337

LOCATION	DIMENSION	CONDITION
A	48-in (1219 mm) 18-in (457 mm) 18-in (457 mm) 12-in (305 mm)	Unit disconnect is mounted on panel No disconnect, convenience outlet option Recommended service clearance Minimum clearance
B	42-in (1067 mm) 36-in (914 mm) Special	Surface behind servicer is grounded (e.g., metal, masonry wall) Surface behind servicer is electrically non-conductive (e.g., wood, fiberglass) Check sources of flue products within 10-ft of unit fresh air intake hood
C	36-in (914 mm) 18-in (457 mm)	Side condensate drain is used Minimum clearance
D	48-in (1219 mm) 42-in (1067 mm) 36-in (914 mm) Special	No flue discharge accessory installed, surface is combustible material Surface behind servicer is grounded (e.g., metal, masonry wall, another unit) Surface behind servicer is electrically non-conductive (e.g., wood, fiberglass) Check for adjacent units or building fresh air intakes within 10-ft (3 m) of this unit's flue outlet

NOTE: Unit not designed to have overhead obstruction. Contact Application Engineering for guidance on any application planning overhead obstruction or for vertical clearances.

Fig. 3 - Service Clearance Dimensional Drawing

INSTALLATION

Jobsite Survey

Complete the following checks before installation.

1. Consult local building codes and the NEC (National Electrical Code) (ANSI/NFPA 70) for special installation requirements.
2. Determine unit location (from project plans) or select unit location.
3. Check for possible overhead obstructions which may interfere with unit lifting or rigging.

Step 1 — Plan for Unit Location

Select a location for the unit and its support system (curb or other) that provides for minimum clearances required for safety (including clearance to combustible surfaces), unit performance and service access below and around unit as specified in Fig. 3.

NOTE: Consider also the effect of adjacent units.

Unit may be installed directly on wood flooring or on Class A, B, or C roof-covering material when roof curb is used.

Do not install unit in an indoor location. Do not locate air inlets near exhaust vents or other sources of contaminated air.

Although unit is weatherproof, avoid locations that permit water from higher level runoff and overhangs to fall onto unit.

Select a unit mounting system that provides adequate height to allow installation of condensate trap per

requirements. Refer to Step 10 — Install External Condensate Trap and Line – for required trap dimensions.

Roof Mount —

Check building codes for weight distribution requirements. Unit operating weight is shown in Table 1.

Step 2 — Plan for Sequence of Unit Installation

The support method used for this unit will dictate different sequences for the steps of unit installation. For example, on curb-mounted units, some accessories must be installed on the unit before the unit is placed on the curb. Review the following for recommended sequences for installation steps.

Curb-mounted Installation —

Install curb

Install field-fabricated ductwork inside curb

Install accessory thru-base service connection package (affects curb and unit) (refer to accessory installation instructions for details)

Prepare bottom condensate drain connection to suit planned condensate line routing (refer to Step 10 for details)

Rig and place unit

Install outdoor air hood

Install condensate line trap and piping

Make electrical connections

Install other accessories

Table 1 – Operating Weights

50LC – *	UNITS LB (KG)		
	04	05	06
Base Unit	458 (208)	545 (247)	550 (249)
Economizer			
Vertical	50 (23)	50 (23)	50 (23)
Horizontal	80 (36)	80 (36)	80 (36)
Humidi – MiZer® System	50 (23)	55 (25)	55 (25)
Cu Fins	25 (11)	43 (20)	56 (25)
Powered Outlet	35 (16)	35 (16)	35 (16)
Curb			
14 – in/356 mm	115 (52)	115 (52)	115 (52)
24 – in/610 mm	197 (89)	197 (89)	197 (89)

Pad-mounted Installation —

- Prepare pad and unit supports
- Check and tighten the bottom condensate drain connection plug
- Rig and place unit
- Convert unit to side duct connection arrangement
- Install field-fabricated ductwork at unit duct openings
- Install outdoor air hood
- Install condensate line trap and piping
- Make electrical connections
- Install other accessories

Frame-mounted installation —

Frame-mounted applications generally follow the sequence for a curb installation. Adapt as required to suit specific installation plan.

Step 3 — Inspect unit

Inspect unit for transportation damage. File any claim with transportation agency.

Confirm before installation of unit that voltage, amperage and circuit protection requirements listed on unit data plate agree with power supply provided.

On units with hinged panel option, check to be sure all latches are snug and in closed position.

Locate the carton containing the outside air hood parts; see Fig. 9. Do not remove carton until unit has been rigged and located in final position.

Step 4 — Provide Unit Support

Roof Curb Mount —

Accessory roof curb details and dimensions are shown in Fig. 4. Assemble and install accessory roof curb in accordance with instructions shipped with the curb.

Curb should be level. This is necessary for unit drain to function properly. Unit leveling tolerances are shown in Fig. 5. Refer to Accessory Roof Curb Installation Instructions for additional information as required.

Install insulation, cant strips, roofing felt, and counter flashing as shown. *Ductwork must be attached to curb and not to the unit. The accessory thru-the-base power and gas connection package must be installed before the unit is set on the roof curb.*

If electric and control wiring is to be routed through the basepan, attach the accessory thru-the-base service connections to the basepan in accordance with the accessory installation instructions.

NOTE: The gasketing of the unit to the roof curb is critical for a watertight seal. Install gasket supplied with the roof curb as shown in Fig. 4. Improperly applied gasket can also result in air leaks and poor unit performance.

Slab Mount (Horizontal Units Only) —

Provide a level concrete slab that extends a minimum of 6 in. (150 mm) beyond unit cabinet. Install a gravel apron in front of condenser coil air inlet to prevent grass and foliage from obstructing airflow.

NOTE: Horizontal units may be installed on a roof curb if required.

Alternate Unit Support (In Lieu of Curb or Slab Mount) —

A non-combustible sleeper rail can be used in the unit curb support area. If sleeper rails cannot be used, support the long sides of the unit with a minimum of 3 equally spaced 4-in. x 4-in. (102 mm x 102 mm) pads on each side.





Fig. 4 - Roof Curb Details



MAXIMUM ALLOWABLE DIFFERENCE IN. (MM)

A-B	B-C	A-C
0.5" (13)	1.0" (25)	1.0" (25)

C06110

Fig. 5 - Unit Leveling Tolerances

Step 5 — Field Fabricate Ductwork

Cabinet return-air static pressure (a negative condition) shall not exceed 0.35 in. wg (87 Pa) with economizer or 0.45 in. wg (112 Pa) without economizer.

For vertical ducted applications, secure all ducts to roof curb and building structure. *Do not connect ductwork to unit.*

Fabricate supply ductwork so that the cross sectional dimensions are equal to or greater than the unit supply duct opening dimensions for the first 18 in. (458 mm) of duct length from the unit basepan.

Insulate and weatherproof all external ductwork, joints, and roof openings with counter flashing and mastic in accordance with applicable codes.

Ducts passing through unconditioned spaces must be insulated and covered with a vapor barrier.

If a plenum return is used on a vertical unit, the return should be ducted through the roof deck to comply with applicable fire codes.

⚠ CAUTION

PROPERTY DAMAGE HAZARD

Failure to follow this caution may result in damage to roofing materials.

Membrane roofs can be cut by sharp sheet metal edges. Be careful when placing any sheet metal parts on such roof.

For Units with Accessory or Optional Electric Heaters —

All installations require a minimum clearance to combustible surfaces of 1-in (25 mm) from duct for first 12-in (305 mm) away from unit.

Outlet grilles must not lie directly below unit discharge.

NOTE: A 90-degree elbow must be provided in the ductwork to comply with UL (Underwriters Laboratories) code for use with electric heat.

⚠ WARNING

PERSONAL INJURY HAZARD

Failure to follow this warning could cause personal injury.

For vertical supply and return units, tools or parts could drop into ductwork and cause an injury. Install a 90-degree turn in the return ductwork between the unit and the conditioned space. If a 90-degree elbow cannot be installed, then a grille of sufficient strength and density should be installed to prevent objects from falling into the conditioned space. Due to electric heater, supply duct will require 90-degree elbow.

50LC

Step 6 — Rig and Place Unit

Keep unit upright and do not drop. Spreader bars are not required if top crating is left on unit. Rollers may be used to move unit across a roof. Level by using unit frame as a reference. See Table 1 and Fig. 6 for additional information.

Lifting holes are provided in base rails as shown in Fig. 6. Refer to rigging instructions on unit.

Before setting the unit onto the curb, recheck gasketing on curb.

→ Rigging materials under unit (cardboard or wood) must be removed PRIOR to placing the unit on the roof curb.

When using the standard side drain connection, ensure the red plug in the alternate bottom connection is tight. Do this before setting the unit in place. The red drain pan plug can be tightened with a 1/2-in. square socket drive extension. For further details see “Step 10 - Install External Condensate Trap and Line” on page 13.

⚠ CAUTION

UNIT DAMAGE HAZARD

Failure to follow this caution may result in equipment damage.

All panels must be in place when rigging. Unit is not designed for handling by fork truck when packaging is removed.

If using top crate as spreader bar, once unit is set, carefully lower wooden crate off building roof top to ground. Ensure that no people or obstructions are below prior to lowering the crate.

⚠ CAUTION - NOTICE TO RIGGERS:
⚠ AVERTISSEMENT - REMARQUE À L'ATTENTION DES MONTEURS

ALL PANELS MUST BE IN PLACE WHEN RIGGING.
TOUS LES CAPOTS DOIVENT ÊTRE EN PLACE AVANT LE LEVAGE

- Hook rigging shackles through holes in base rail, as shown in Detail "A".
- Use wooden top skid, when rigging, to prevent rigging straps from damaging unit.
- Max weight includes base unit plus shipping pallet plus all available FIOP's which could be on that size unit.
- "B" dimension is based on base unit (PAC no heat or YAC w/low heat) plus economizer option only. This dimension may vary slightly with units configured with other FIOP options.
- Spreader bars required to lift and transport the unit.
- Accrocher les manilles des élingues de levages dans les trous situés dans le rail de base comme indiqué au Détail « A ».
- Utiliser des cales en bois lors du levage pour éviter que les élingues n'endommagent le haut de l'appareil.
- Le poids maximum inclut la configuration de base, le poids de la palette d'expédition, ainsi que toutes les options pouvant être installées en usine (FIOP) pour la plateforme sélectionnée.
- La dimension de "B" provient de la configuration de base (PAC sans chauffage ou YAC chauffage au gaz naturel) qui inclut l'option economizer seulement. Cette dimension peut varier légèrement en fonction des différentes options sélectionnées, installées en usine (FIOP).
- Barres d'écartement requises pour soulever et transporter l'unité.

PLACE ALL SEAL STRIP IN PLACE BEFORE PLACING UNIT ON ROOF CURB.
 INSTALLER TOUTES LES BANDES D'ISOLATION EN PLACE AVANT DE PLACER L'APPAREIL SUR LE REBORD DE TOIT.

DUCT END PASSAGES CONDUITES

DETAIL A
DÉTAIL « A »

MODEL	MAX WEIGHT		A		B		C	
	LB	KG	IN	MM	IN	MM	IN	MM
50LC_004	700	318	74.5	1890	36.5	925	33.5	850
50LC_005	830	377	74.5	1890	36.5	925	41.5	1055
50LC_006	865	393	74.5	1890	36.0	915	41.5	1055
48LC_004	760	345	74.5	1890	38.0	965	33.5	850
48LC_005	895	407	74.5	1890	38.0	965	41.5	1055
48LC_006	930	423	74.5	1890	37.5	955	41.5	1055

48HC500030 A

C12100

Fig. 6 - Rigging Label

Positioning on Curb —


Position unit on roof curb so that the following clearances are maintained: 1/4 in. (6.4 mm) clearance between the roof curb and the base rail inside the front and rear, 0.0 in. clearance between the roof curb and the base rail inside on the duct end of the unit. This will result in the distance between the roof curb and the base rail inside on the condenser end of the unit being approximately 1/4 in. (6.4 mm).

Although unit is weatherproof, guard against water from higher level runoff and overhangs.

After unit is in position, remove rigging skids and shipping materials.

Step 7 — Convert to Horizontal and Connect Ductwork (when required)

Unit is shipped in the vertical duct configuration. Unit without factory-installed economizer or return air smoke detector option may be field-converted to horizontal ducted configuration. To convert to horizontal configuration, remove screws from side duct opening covers and remove covers. Using the same screws, install covers on vertical duct openings with the insulation-side down. Seals around duct openings must be tight. See Fig. 7.



C06108

Fig. 7 - Horizontal Conversion Panels


Field-supplied flanges should be attached to horizontal duct openings and all ductwork should be secured to the flanges. Insulate and weatherproof all external ductwork, joints, and roof or building openings with counter flashing and mastic in accordance with applicable codes.

Do not cover or obscure visibility to the unit's informative data plate when insulating horizontal ductwork.

Step 8 — Install Outside Air Hood

Economizer Hood Package Removal and Setup - Factory Option


1. The hood is shipped in knock-down form and must be field assembled. The indoor coil access panel is used as the hood top while the hood sides, divider and filter are packaged together, attached to a metal support tray using plastic stretch wrap, and shipped in the return air compartment behind the indoor coil access panel. The hood assembly's metal tray is attached to the basepan and also attached to the damper using two plastic tie-wraps.
2. To gain access to the hood, remove the filter access panel. (See Fig. 8.)



C06023

Fig. 8 - Typical Access Panel Locations

3. Locate the (2) screws holding the metal tray to the basepan and remove. Locate and cut the (2) plastic tie-wraps securing the assembly to the damper. (See Fig. 9) Be careful to not damage any wiring or cut tie-wraps securing any wiring.



C08639

Fig. 9 - Economizer Hood Parts Location

- Carefully lift the hood assembly (with metal tray) through the filter access opening and assemble per the steps outlined in *Economizer Hood*, below.

Economizer Hood —

NOTE: If the power exhaust accessory is to be installed on the unit, the hood shipped with the unit will not be used and must be discarded. Save the aluminum filter for use in the power exhaust hood assembly.

- The indoor coil access panel will be used as the top of the hood. Remove the screws along the sides and bottom of the indoor coil access panel. See Fig. 10.




Fig. 10 - Indoor Coil Access Panel Relocation

C06025

- Swing out indoor coil access panel and insert the hood sides under the panel (hood top). Use the screws provided to attach the hood sides to the hood top. Use screws provided to attach the hood sides to the unit. See Fig. 11.




Fig. 11 - Economizer Hood Construction

C06026

- Remove the shipping tape holding the economizer barometric relief damper in place (economizer only).
- Insert the hood divider between the hood sides. See Fig. 11 and Fig. 12. Secure hood divider with 2 screws on each hood side. The hood divider is also used as the bottom filter rack for the aluminum filter.
- Open the filter clips which are located underneath the hood top. Insert the aluminum filter into the bottom filter rack (hood divider). Push the filter into position past the open filter clips. Close the filter clips to lock the filter into place. See Fig. 12.
- Caulk the ends of the joint between the unit top panel and the hood top.
- Replace the filter access panel.




Fig. 12 - Economizer Filter Installation

C08634

Step 9 — Units with Hinged Panels Only

Relocate latch shipped inside the hinged compressor door to location shown in Fig. 13 after unit installation.

If the unit does not have hinged panels, skip step 9 and continue at step 10.





Fig. 13 - Compressor Door Latch Location

C12101

Step 10 — Install External Condensate Trap & Line

The unit has one $\frac{3}{4}$ -in. condensate drain connection on the end of the condensate pan and an alternate connection on the bottom. See Fig. 14. Unit airflow configuration does not determine which drain connection to use. Either drain connection can be used with vertical or horizontal applications.




C08021

Fig. 14 - Condensate Drain Pan (Side View)

To use the alternate bottom drain connection, remove the red drain plug from the bottom connection (use a $\frac{1}{2}$ -in. square socket drive extension) and install it in the side drain connection.

The piping for the condensate drain and external trap can be completed after the unit is in place. See Fig. 15.



NOTE: Trap should be deep enough to offset maximum unit static difference. A 4" (102) trap is recommended

C08022

Fig. 15 - Condensate Drain Piping Details

All units must have an external trap for condensate drainage. Install a trap at least 4-in. (102 mm) deep and protect against freeze-up. If drain line is installed downstream from the external trap, pitch the line away from the unit at 1-in. per 10 ft (25 mm in 3 m) of run. Do not use a pipe size smaller than the unit connection ($\frac{3}{4}$ -in.).

Step 11 — Make Electrical Connections

⚠ WARNING

ELECTRICAL SHOCK HAZARD

Failure to follow this warning could result in personal injury or death.

Unit cabinet must have an uninterrupted, unbroken electrical ground to minimize the possibility of personal injury if an electrical fault should occur. This ground may consist of electrical wire connected to unit ground lug in control compartment, or conduit approved for electrical ground when installed in accordance with NEC; ANSI/NFPA 70, latest edition (in Canada, Canadian Electrical Code CSA [Canadian Standards Association] C22.1), and local electrical codes.

NOTE: Field-supplied wiring shall conform with the limitations of minimum 63°F (33°C) rise.


Field Power Supply —

If equipped with optional Powered Convenience Outlet: The power source leads to the convenience outlet's transformer primary are not factory connected. Installer must connect these leads according to required operation of the convenience outlet. If an always-energized convenience outlet operation is desired, connect the source leads to the line side of the unit-mounted disconnect. (Check with local codes to ensure this method is acceptable in your area.) If a de-energize via unit disconnect switch operation of the convenience outlet is desired, connect the source leads to the load side of the unit disconnect. On a unit without a unit-mounted disconnect, connect the source leads to compressor contactor C and indoor fan terminal block (IFTB) pressure lugs with unit field power leads.

Refer to Fig. 28 for power transformer connections and the discussion on connecting the convenience outlet on page 20.

Field power wires are connected to the unit at line-side pressure lugs on compressor contactor C and indoor fan terminal block (IFTB) (see wiring diagram label for control box component arrangement) or at factory-installed option non-fused disconnect switch or HACR. Max wire size is #2ga AWG (copper only) per pole on contactors. #2ga AWG per pole on optional disconnect or HACR and 4/0 AWG per pole on terminal or fuse block on units with single point box. See Fig. 20 and unit label diagram for field power wiring connections.

50LC



- NOTES:
1. TERMINAL BOARD SCHEMATIC LAYOUT DOES NOT MATCH ACTUAL TERMINAL BOARD
 2. ENGINE DESIGNATED JUMPERS ON TERMINAL BOARD ARE CUT WHEN ADDING SMOKE DETECTORS, PHASE LOSS RELAY, OCCUPANCY AND REMOTE SHUTDOWN.
 3. RECTIFIER TO CONVERT AC TO DC
 4. FACTORY WIRING FOR SIGNAL CONNECTIONS: LO-1 HEAT; WIRE 5 FROM TDR-VIOLET WIRE TO COIL
 5. MAY BE REQUIRED WHEN USING FIELD INSTALLATION INSTRUCTIONS FOR PROPER SELECTION
 6. AND DDC OPTION THERE WILL BE WIRES IN PINS 6, 7.
 7. FOR SINGLE STAGE ELECTRIC HEAT OPTION, MOVE TBA LOCATED IN HEAT SECTION, TBA GRAY WIRE TO TBA GRAY WIRE.
 8. AND WHITE WIRES DISCONNECT FOR NORMAL OPERATION.

Fig. 16 - 50LC Control Wiring Diagram




Fig. 18 - 50LC Power Wiring Diagram, 208/230V, 460V, 575V 3 Phase






Fig. 21 - Disconnect Switch and Unit

A93033

50LC

Units With Disconnect or HACR Option



Units With Electric Heat Option with Single Point Box and Without Disconnect or HACR Option





Fig. 20 - Power Wiring Connections

C12104

Units With Factory-Installed Non-Fused Disconnect or HACR —

The factory-installed optional non-fused disconnect (NFD) or HACR switch is located in a weatherproof enclosure located under the main control box. The manual switch handle and shaft is shipped in the disconnect or HACR enclosure. Assemble the shaft and handle to the switch at this point.



C12284

Fig. 22 - Location of Non-Fused Disconnect Enclosure

To field install the NFD shaft and handle:

1. Remove the unit front panel (see Fig. 2).
2. Remove (3) hexagon screws on the front cover - (2) on the face of the cover and (1) on the left side cover.
3. Remove the front cover of the NFD enclosure.
4. Make sure the NFD shipped from the factory is at OFF position (the arrow on the black handle knob is at OFF).
5. Insert the shaft with the cross pin on the top of the shaft in the horizontal position.
6. Measure from the tip of the shaft to the top surface of the black pointer; the measurement should be 3.75 - 3.88 in. (95 - 99 mm).
7. Tighten the locking screw to secure the shaft to the NFD.
8. Turn the handle to the OFF position with red arrow pointing at OFF.
9. Install the handle on to the painted cover horizontally with the red arrow pointing to the left.
10. Secure the handle to the painted cover with (2) screws and lock washers supplied.


⚠ WARNING

FIRE HAZARD

Failure to follow this warning could result in intermittent operation or performance satisfaction.


Do not connect aluminum wire between disconnect switch and 50LC unit. Use only copper wire. (See Fig. 21.)

11. Engaging the shaft into the handle socket, re-install (3) hexagon screws on the front cover.
12. Re-install the unit front panel.



C12279

Fig. 23 - Handle and Shaft Assembly for NFD




C12285

Fig. 24 - Location of HACR Enclosure

To field install the HACR shaft and handle:

1. Remove the unit front panel (see Fig. 2).
2. Remove (3) hexagon screws on the front cover - (2) on the face of the cover and (1) on the left side cover.
3. Remove the front cover of the HACR enclosure.
4. Make sure the HACR shipped from the factory is at OFF position (the white arrow pointing at OFF).
5. Insert the shaft all the way with the cross pin on the top of the shaft in the horizontal position.
6. Tighten the locking screw to secure the shaft to the HACR.
7. Turn the handle to the OFF position with red arrow pointing at OFF.
8. Install the handle on to the painted cover horizontally with the red arrow pointing to the left.
9. Secure the handle to the painted cover with (2) screws and lock washers supplied.
10. Engaging the shaft into the handle socket, re-install (3) hexagon screws on the front cover.
11. Re-install the unit front panel.



C12281

Fig. 25 - Handle and Shaft Assembly for HACR

Units Without Factory-Installed Disconnect or HACR —

When installing units, provide a disconnect switch per NEC (National Electrical Code) of adequate size. Disconnect sizing data is provided on the unit informative plate. Locate on unit cabinet or within sight of the unit per national or local codes. Do not cover unit informative plate if mounting the disconnect on the unit cabinet.

All Units —

All field wiring must comply with NEC and all local codes. Size wire based on MCA (Minimum Circuit Amps) on the unit informative plate. See Fig. 20 and the unit label diagram for power wiring connections to the unit power terminal blocks and equipment ground. Maximum wire size is #2ga AWG per pole on contactors. #2ga AWG per pole on optional disconnect or HACR and 4/0 AWG per pole on terminal or fuse block on units with single point box. See Fig. 20 and unit label diagram for field power wiring connections.

Provide a ground-fault and short-circuit over-current protection device (fuse or breaker) per NEC Article 440 (or local codes). Refer to unit informative data plate for MOCP (Maximum Over-current Protection) device size.

NOTE: Units ordered with factory installed HACR do not need an additional ground-fault and short-circuit over-current protective device unless required by local codes.

All field wiring must comply with the NEC and local requirements.

All units except 208/230-v units are factory wired for the voltage shown on the nameplate. *If the 208/230-v unit is to be connected to a 208-v power supply, the control transformer must be rewired by moving the black wire with the 1/4-in. female spade connector from the 230-v connection and moving it to the 200-v 1/4-in. male terminal on the primary side of the transformer.* Refer to unit label diagram for additional information.

NOTE: Check all factory and field electrical connections for tightness.

⚠ WARNING

ELECTRICAL OPERATION HAZARD

Failure to follow this warning could result in personal injury or death.

Units with convenience outlet circuits may use multiple disconnects. Check convenience outlet for power status before opening unit for service. Locate its disconnect switch, if appropriate, and switch to off position. Lock-out and tag-out this switch, if necessary.

50LC

Two types of convenience outlets are offered on 50LC models: Non-powered and unit-powered. Both types provide a 125-volt GFCI (ground-fault circuit-interrupter) duplex receptacle rated at 15-A behind a hinged waterproof access cover, located on the end panel of the unit. See Fig. 26.

NOTE: Unit powered convenience outlets are not available as factory installed options for single phase (-3 voltage code) models.




Fig. 26 - Convenience Outlet Location

Installing Weatherproof Cover: A weatherproof while-in-use cover for the factory-installed convenience outlets is now required by UL standards. This cover cannot be factory-mounted due its depth; it must be installed at unit installation. For shipment, the convenience outlet is covered with a blank cover plate.

The weatherproof cover kit is shipped in the unit's control box. The kit includes the hinged cover, a backing plate and gasket.

DISCONNECT ALL POWER TO UNIT AND CONVENIENCE OUTLET. LOCK-OUT AND TAG-OUT ALL POWER.

Remove the blank cover plate at the convenience outlet; discard the blank cover.

Loosen the two screws at the GFCI duplex outlet, until approximately 1/2-in (13 mm) under screw heads are exposed. Press the gasket over the screw heads. Slip the backing plate over the screw heads at the keyhole slots

and align with the gasket; tighten the two screws until snug (do not over-tighten).

Mount the weatherproof cover to the backing plate as shown in Fig. 27. Remove two slot fillers in the bottom of the cover to permit service tool cords to exit the cover. Check for full closing and latching.





Fig. 27 - Weatherproof Cover Installation

Non-powered type: This type requires the field installation of a general-purpose 125-volt 15-A circuit powered from a source elsewhere in the building. Observe national and local codes when selecting wire size, fuse or breaker requirements and disconnect switch size and location. Route 125-v power supply conductors into the bottom of the utility box containing the duplex receptacle.

Unit-powered type: A unit-mounted transformer is factory-installed to stepdown the main power supply voltage to the unit to 115-v at the duplex receptacle. This option also includes a manual switch with fuse, located in a utility box and mounted on a bracket behind the convenience outlet; access is through the unit's control box access panel. See Fig. 26.

The primary leads to the convenience outlet transformer are not factory-connected. Selection of primary power source is a customer-option. If local codes permit, the transformer primary leads can be connected at the line-side terminals on the unit-mounted non-fused disconnect or HACR breaker switch; this will provide service power to the unit when the unit disconnect switch or HACR switch is open. Other connection methods will result in the convenience outlet circuit being de-energized when the unit disconnect or HACR switch is open. See Fig. 28.

Using unit-mounted convenience outlets: Units with unit-mounted convenience outlet circuits will often require that two disconnects be opened to de-energize all power to the unit. Treat all units as electrically energized until the convenience outlet power is also checked and de-energization is confirmed. Observe National Electrical Code Article 210, Branch Circuits, for use of convenience outlets.




C08283

UNIT VOLTAGE	CONNECT AS	PRIMARY CONNECTIONS	TRANSFORMER TERMINALS
208, 230	240	L1: RED +YEL L2: BLU + GRA	H1 + H3 H2 + H4
460	480	L1: RED Splice BLU + YEL L2: GRA	H1 H2 + H3 H4
575	600	L1: RED L2: GRA	H1 H2

Fig. 28 - Powered Convenience Outlet Wiring

Fuse on power type: The factory fuse is a Bussman “Fusetron” T-15, non-renewable screw-in (Edison base) type plug fuse.



C13415

Fig. 29 - Convenience Outlet Utilization Notice Label

Duty Cycle: the unit-powered convenience outlet has a duty cycle limitation. The transformer is intended to provide power on an intermittent basis for service tools, lamps, etc; it is not intended to provide 15-amps loading for continuous duty loads (such as electric heaters for overnight use). Observe a 50% limit on circuit loading above 8-amps.


Convenience outlet usage rating:

Continuous usage: 8 amps maximum

Test the GFCI receptacle by pressing the TEST button on the face of the receptacle to trip and open the receptacle. Check for proper grounding wires and power line phasing if the GFCI receptacle does not trip as required. Press the RESET button to clear the tripped condition.

HACR —

The amp rating of the HACR factory installed option is based on the size, voltage, indoor motor and other electrical options of the unit as shipped from the factory. If field installed accessories are added or changed in the field (i.e. electric heat, power exhaust, ERV), the HACR may no longer be of the proper amp rating and therefore will need to be removed from the unit. See unit nameplate and label on factory installed HACR for the amp rating of the HACR that was shipped with the unit from the factory. See unit nameplates for the proper fuse, HACR or maximum over-current protection device required on the unit with field installed accessories.




C12105

Fig. 30 - HACR Caution Label

Factory-Option Thru-Base Connections —

This service connection kit consists of two 1/2-in electrical bulkhead connectors and a 3/4-in electrical bulkhead connector, all factory-installed in the embossed (raised) section of the unit basepan in the condenser section. The 3/4-in bulkhead connector enables the low-voltage control wires to pass through the basepan. The 1/2-in electrical bulkhead connector allows the high-voltage power wires to pass through the basepan. See Fig. 31.



C13412

Fig. 31 - Thru-Base Connection Fittings

Check tightness of connector lock nuts before connecting electrical conduits.

50LC

Field-supplied and field-installed liquid tight conduit connectors and conduit may be attached to the connectors on the basepan. Pull correctly rated high voltage and low voltage through appropriate conduits. Connect the power conduit to the internal disconnect (if unit is so equipped) or to the external disconnect (through unit side panel). A hole must be field cut in the main control box bottom on the left side so the 24-v control connections can be made. Connect the control power conduit to the unit control box at this hole.

Units without Thru-Base Connections —

1. Install power wiring conduit through side panel openings. Install conduit between disconnect and control box.
2. Install power lines to terminal connections as shown in Fig. 20.

Voltage to compressor terminals during operation must be within voltage range indicated on unit nameplate. See Tables 5 and 6. On 3-phase units, voltages between phases must be balanced within 2% and the current within 10%. Use the formula shown in the legend for Tables 5 and 6, Note 2 to determine the percent of voltage imbalance. Operation on improper line voltage or excessive phase imbalance constitutes abuse and may cause damage to electrical components. Such operation would invalidate any applicable Carrier warranty.

Field Control Wiring —

The 50LC unit requires an external temperature control device. This device can be a thermostat (field-supplied) or, the RTU Open Controller for Building Management Systems using non-CCN protocols (RTU Open is available as a factory-installed option only), or a space temperature sensor (SPT) with factory installed ComfortLINK controller.

Thermostat —

Select a Carrier-approved accessory thermostat. When electric heat is installed in the 50LC unit, the thermostat must be capable of energizing the G terminal (to energize the Indoor Fan Contactor) whenever there is a space call for heat (energizing the W1 terminal). The accessory thermostats listed on the unit price pages can provide this signal but they are not configured to enable this signal as shipped.


Install the accessory thermostat according to installation instructions included with the accessory.

Locate the thermostat accessory on a solid wall in the conditioned space to sense average temperature in accordance with the thermostat installation instructions.

If the thermostat contains a logic circuit requiring 24-v power, use a thermostat cable or equivalent single leads of different colors with minimum of seven leads. If the thermostat does not require a 24-v source (no “C” connection required), use a thermostat cable or equivalent with minimum of six leads. Check the thermostat installation instructions for additional features which might require additional conductors in the cable.

For wire runs up to 50 ft. (15 m), use no. 18 AWG (American Wire Gage) insulated wire [35°C (95°F) minimum]. For 50 to 75 ft. (15 to 23 m), use no. 16 AWG

insulated wire [35°C (95°F) minimum]. For over 75 ft. (23 m), use no. 14 AWG insulated wire [35°C (95°F) minimum]. All wire sizes larger than no. 18 AWG cannot be directly connected to the thermostat and will require a junction box and splice at the thermostat.



- Note 1: Typical multi-function marking. Follow manufacturer's configuration instructions to select Y2.
 - Note 2: Y2 to Y2 connection required for 2 stage cooling operation and when integrated economizer function is desired
 - Note 3: W2 connection not required on units with single-stage heating.
- Field Wiring


C12127

Fig. 32 - Low-Voltage Connections

Unit without Thru-Base Connection Kit —

Pass the thermostat control wires through the hole provided in the corner post; then feed the wires through the raceway built into the corner post to the control box. Pull the wires over to the terminal strip on the upper-left corner of the Controls Connection Board. See Fig. 33.

NOTE: If thru-the-bottom connections accessory is used, refer to the accessory installation instructions for information on routing power and control wiring.



C08027

Fig. 33 - Field Control Wiring Raceway

Heat Anticipator Settings —

Set heat anticipator settings at 0.14 amp for the first stage and 0.14 amp for second-stage heating, when available.

Electric Heaters

50LC units may be equipped with factory or field-installed electric heaters. The heaters are modular in design, with heater frames holding open coil resistance wires strung through ceramic insulators, line-break limit switches and a control contactor. One or two heater modules may be used in a unit.

Heater modules are installed in the compartment below the indoor (supply) fan outlet. Access is through the indoor access panel. Heater modules slide into the compartment on tracks along the bottom of the heater opening. See Fig. 34, Fig. 35 and Fig. 36.

Not all available heater modules may be used in every unit. Use only those heater modules that are UL listed for use in a specific size unit. Refer to the label on the unit cabinet for the list of approved heaters.

Unit heaters are marked with Heater Model Numbers. But heaters are ordered as and shipped in cartons marked with a corresponding heater Sales Package part number. See Table 2 for correlation between heater Model Number and Sales Package part number.

NOTE: The value in position 9 of the part number differs between the sales package part number (value is 1) and a bare heater model number (value is 0).




Fig. 34 - Typical Access Panel Location (3-5 Ton)

C08133




Fig. 35 - Typical Component Location

C08134




Fig. 36 - Typical Module Installation

C08135

50LC

Table 2 – Heater Model Number

Bare Heater Model Number	C	R	H	E	A	T	E	R	0	0	1	A	0	0
Heater Sales Package PNO Includes:														
Bare Heater	C	R	H	E	A	T	E	R	1	0	1	A	0	0
Carton and packing materials														
Installation sheet														


Single Point Boxes and Supplementary Fuses —

When the unit MOCB device value exceeds 60-A, unit-mounted supplementary fuses are required for each heater circuit. These fuses are included in accessory Single Point Boxes, with power distribution and fuse blocks. The single point box will be installed directly under the unit control box, just to the left of the partition separating the indoor section (with electric heaters) from the outdoor section. The Single Point Box has a hinged access cover. See Fig. 37. The Single Point Box also includes a set of power taps and pigtailed to complete the wiring between the Single Point Box and the unit's main control box terminals. Refer to the accessory heater and Single Point Box installation instructions for details on tap connections or field installed electric heat accessory.

All fuses on 50LC units are 60-A. (Note that all heaters are qualified for use with a 60-A fuse, regardless of actual heater ampacity, so only 60-A fuses are necessary.)

Single Point Boxes without Fuses —

Some unit heater applications not requiring supplemental fuses require a special Single Point Box without any fuses. The accessory Single Point Boxes contain a set of power taps and pigtailed to complete the wiring between the Single Point Box and the unit's main control box terminals. Refer to accessory heater and Single Point Box installation instructions for details on tap connections or field installed electric heat accessory.




C14253

Fig. 37 - Typical Single Point Installation

Low-Voltage Control Connections —

All units except size 06, 575V:

Pull the low-voltage control leads from the heater module(s) - VIO and BRN (two of each if two modules are installed; identify for Module #1) - to the 4-pole terminal board TB4 located on the heater bulkhead to the left of Heater #1. Connect the VIO lead from Heater #1 to terminal TB4-1. For 2 stage heating, connect the VIO lead from Heater #2 to terminal TB4-2. For 1 stage heating with 2 heater modules connect the VIO lead from both Heater #1 and #2 to terminal TB4-1. Connect both BRN leads to terminal TB4-3. See Fig. 38.




HR1: On Heater 1 in Position #1
HR2: On Heater 2 in Position #2 (if installed)

C12106

Fig. 38 - Accessory Electric Heater Control Connections (all units except size 06, 575V) - 2 Stage Heat Shown

Size 06, 575V units only:

Pull the low-voltage control leads from the heater module(s) - VIO, WHT and BRN (two of each if two modules are installed; identify for Module #1) - to the 4-pole terminal board TB4 located on the heater bulkhead to the left of Heater #1. Connect the WHT lead from Heater #1 to TB4 where ORN is. For 2 stage heating, connect the VIO lead from Heater #2 to the terminal that has VIO from the unit. For 1 stage heating with 2 heater modules connect the VIO lead from Heater #2 to the same terminal with WHT lead from Heater #1 (see Fig. 39).



C12107

Fig. 39 - Accessory Electric Heater Control Connections (Size 06, 575V only) - 2 Stage Heat Shown

Humidi-MiZer® Control Connections

NOTE: It is suggested to ensure the Auto-Changeover function of an installed thermostat is enabled when used in conjunction with the Humidi-MiZer Adaptive Dehumidification system.

Humidi-MiZer – Space RH Controller —


The Humidi-MiZer dehumidification system requires a field-supplied and -installed space relative humidity control device. This device may be a separate humidistat control (contact closes on rise in space RH above control setpoint) or a combination thermostat-humidistat control device such as Carrier's EDGE® Pro Thermidistat with isolated contact set for dehumidification control. The humidistat is normally used in applications where a temperature control is already provided (units with ComfortLINK or RTU Open controls).

To connect the Carrier humidistat (HL38MG029):

1. Route the humidistat 2-conductor cable (field-supplied) through the hole provided in the unit corner post.
2. Feed wires through the raceway built into the corner post (see Fig. 33) to the 24-v barrier located on the left side of the control box. The raceway provides the UL-required clearance between high-voltage and low-voltage wiring.
3. Use wire nuts to connect humidistat cable to the leads in the low-voltage wiring (as shown in Fig. 42), connecting PKN to PNK and PNK/BLK to PNK/BLK.

To connect the Thermidistat device (33CS2PPRH-03):

1. Route the Thermidistat multi-conductor thermostat cable (field-supplied) through the hole provided in the unit corner post.
2. Feed wires through the raceway built into the corner post (see Fig. 33) to the 24-v barrier located on the left side of the control box. The raceway provides the UL-required clearance between high-voltage and low-voltage wiring.
3. The Thermidistat has dry contacts at terminals D1 and D2 for dehumidification operation (see Fig. 43). The dry contacts must be wired between CTB terminal R and the PNK/BLK lead to the LTLO switch with field-supplied wire nuts. Refer to the installation instructions included with the Carrier Edge Thermidistat device (Form 33CS-74SI or latest) for more information.



C09295

Fig. 40 - Accessory Field-Installed Humidistat



C09296

Fig. 41 - EDGE Pro Thermidistat

50LC

50LC





Fig. 42 - Typical Humidi-MiZer® Adaptive Dehumidification System Humidistat Wiring

C13419




Fig. 43 - Typical Rooftop Unit with Humidi-MiZer Adaptive Dehumidification System with EDGE Pro Thermidistat Device

C13066

EconoMi\$er X (Factory-Installed Option)

For details on operating 50LC units equipped with the factory-installed EconoMi\$er X option, refer to *EconoMi\$er X Factory-Installed Option Low Leak Economizer for 2 Speed SAV™ (Staged Air Volume) Systems* (Catalog No. LLECON-02SI, or later).

→ SystemVu™ Controller (Factory-Installed Option)

For details on operating 50LC units equipped with the factory-installed SystemVu control option refer to *48/50LC 04-26 Single Package Rooftop Units with SystemVu Controls Version 2.X Controls, Start-up, Operation and Troubleshooting manual*.

ComfortLINK (Factory-Installed Option)

For details on operating 50LC units equipped with the factory installed ComfortLINK option, refer to *Controls, Start-Up, Operation and Troubleshooting for 48/50LC 04-06 Single Package Rooftop Unit with ComfortLINK Controls* (Catalog No. 48-50LC-C01T, or later).




Fig. 44 - 50LC Control Box Component Locations with ComfortLINK

C12108

RTU Open Control System

The RTU Open control is factory-mounted in the 50LC unit's main control box, to the left of the CTB. See Fig. 47. Factory wiring is completed through harnesses connected to the CTB. Field connections for RTU Open sensors will be made at the Phoenix connectors on the RTU Open board. The factory-installed RTU Open control includes the supply-air temperature (SAT) sensor. The outdoor air temperature (OAT) sensor is included in the FIOP/accessory EconoMi\$er2 package.

The RTU Open controller is an integrated component of the Carrier rooftop unit. Its internal application programming provides optimum performance and energy efficiency. RTU Open enables the unit to run in 100% stand-alone control mode, Carrier's I-Vu Open network, or a Third Party Building Automation System (BAS). On-board DIP switches allow you to select your protocol (and baud rate) of choice among the four most popular protocols in use today: BACnet, Modbus, Johnson N2 and LonWorks. (See Fig. 46.)

Refer to Table 3, RTU Open Controller Inputs and Outputs for locations of all connections to the RTU Open board.




Fig. 46 - RTU Open Multi-Protocol Control Board

C12751





Fig. 47 - 50LC Control Box Component Locations with RTU Open

C12110

50LC



- NOTES:
1. TERMINAL BOARD SCHEMATIC LAYOUT DOES NOT MATCH ACTUAL TERMINAL BOARD
 2. ENGINE DESIGNATED JUMPS ON TERMINAL BOARD ARE CUT WHEN ADDING SMOKE
 3. COMPRESSOR LAMPS PULSE CONTAINS BRIDGE
 4. RECTIFIER TO CONVERT AC TO DC
 5. FOR SINGLE STAGE ELECTRIC HEAT OPTION:
 - PINS 8, 7, AND 9, THERE WILL BE WIRES IN
 - PINS 8, 7, AND 9, THERE WILL BE WIRES IN
 - WIRE TO 24V CHARGE WIRE.
 - FOR HIGH SPEED BLOWER TESTING, CONNECT FOR
 - NORMAL OPERATION.

Fig. 48 - RTU Open System Control Wiring Diagram

Table 3 – RTU Open Controller Inputs and Outputs

POINT NAME	BACnet OBJECT NAME	TYPE OF I/O	CONNECTION PIN NUMBER(S)
DEDICATED INPUTS			
Space Temp / Zone Temp	zone_temp	AI (10K Thermistor)	J20-1 & 2
Supply Air Temperature	sa_temp	AI (10K Thermistor)	J2-1 & 2
Outdoor Air Temperature	oa_temp	AI (10K Thermistor)	J2-3 & 4
Space Temperature Offset Pot	stpt_adj_offset	AI (100K Potentiometer)	J20-3 & 4
Safety Chain Feedback	safety_status	DI (24 VAC)	J1-9
Compressor Safety Status	comp_status	DI (24 VAC)	J1-2
Fire Shutdown Status	firedown_status	DI (24 VAC)	J1-10
Enthalpy Status	enthalpy_status	DI (24 VAC)	J2-6 & 7
Humidistat Input Status	humstat_status	DI (24 VAC)	J5-7 & 8
Zone Temperature	n/a	n/a	J13-1, 2, 3, 4
CONFIGURABLE INPUTS			
Indoor Air CO2	iaq	AI (4-20 ma)	J4-2 & 3 or J4-5 & 6
Outdoor Air CO2	oaq	AI (4-20 ma)	
Space Relative Humidity	space_rh	AI (4-20 ma)	
Supply Fan Status*	sfan_status	DI (24 VAC)	J5-1 or J5-3 or J5-5
Filter Status*	filter_status	DI (24 VAC)	
Door Contact Input*	door_contact_status	DI (24 VAC)	
Occupancy Contact*	occ_contact_status	DI (24 VAC)	
OUTPUTS			
Economizer Output	econ_output	AO (4-20ma)	J2-5
Supply Fan Relay State	sfan	DO Relay (24VAC , 1A)	J1-4
Compressor 1 Relay State	comp_1	DO Relay (24VAC , 1A)	J1-8
Compressor 2 Relay State	comp_2	DO Relay (24VAC , 1A)	J1-7
Heat Stage 1 Relay State	heat_1	DO Relay (24VAC , 1A)	J1-6
Heat Stage 2 Relay State	heat_2	DO Relay (24VAC , 1A)	J1-5
Power Exhaust Relay State	pexh	DO Relay (24VAC , 1A)	J11-1 & 3
Humidimizer Relay State	dehum	DO Relay (24VAC, 1A)	J11-7, 8

LEGEND

- AI** - Analog Input
- AO** - Analog Output
- DI** - Discrete Input
- DO** - Discrete Output

* These inputs (if installed) take the place of the default input on the specific channel according to schematic. Parallel pins J5-1 = J2-6, J5-3 = J1-10, J5-5 = J1-2 are used for field-installation.

The RTU Open controller requires the use of a Carrier space sensor. A standard thermostat cannot be used with the RTU Open system.

Supply Air Temperature (SAT) Sensor —

On FIOP-equipped 48LC unit, the unit is supplied with a supply-air temperature (SAT) sensor (33ZCSENSAT). This sensor is a tubular probe type, approx 6-inches (152 mm) in length. It is a nominal 10-k ohm thermistor.

The SAT is factory-wired. The SAT probe is wire-tied to the supply-air opening (on the horizontal opening end) in its shipping position. Remove the sensor for installation. Re-position the sensor in the flange of the supply-air opening or in the supply air duct (as required by local codes). Drill or punch a 1/2-in. hole in the flange or duct. Use two field-supplied, self-drilling screws to secure the sensor probe in a horizontal orientation. See Fig. 50.




Fig. 50 - Typical Mounting Location for Supply Air Temperature (SAT) Sensor on Small Rooftop Units

C08200

Outdoor Air Temperature (OAT) Sensor —

The OAT is factory-mounted in the EconoMi\$er2 (FIOP or accessory). It is a nominal 10k ohm thermistor attached to an eyelet mounting ring.

EconoMi\$er2 —

The RTU Open control is used with EconoMi\$er2 (option or accessory) for outdoor air management. The damper position is controlled directly by the RTU Open control; EconoMi\$er2 has no internal logic device.

Outdoor air management functions can be enhanced with field-installation of these accessory control devices:

- Enthalpy control (outdoor air or differential sensors)
- Space CO₂ sensor
- Outdoor air CO₂ sensor

Field Connections

Field connections for accessory sensors and input devices are made at the RTU Open, at plugs J1, J2, J4, J5, J11 and J20. All field control wiring that connects to the RTU Open must be routed through the raceway built into the corner post as shown in Fig. 33. The raceway provides the UL required clearance between high- and low-voltage wiring. Pass the control wires through the hole provided in the corner post, then feed the wires through the raceway to the RTU Open. Connect to the wires to the removable Phoenix connectors and then reconnect the connectors to the board.

Space Temperature (SPT) Sensors —

There are two types of SPT sensors available from Carrier, resistive input non-communicating (T55, T56, and T59) and Rnet communicating (SPS, SPPL, SPP, and SPPF) sensors. Each type has a variety of options consisting of: timed override button, set point adjustment, a LCD screen, and communication tie in. Space temperature can be also be written to from a building network or zoning system. However, it is still recommended that return air duct sensor be installed to allow stand-alone operation for back-up. Refer to the configuration section for details on controller configurations associated with space sensors.

- 33ZCT55SPT, space temperature sensor with override button (T-55)
- 33ZCT56SPT, space temperature sensor with override button and setpoint adjustment (T-56)
- 33ZCT59SPT, space temperature sensor with LCD (liquid crystal display) screen, override button, and setpoint adjustment (T-59)

Use 20 gauge wire to connect the sensor to the controller. The wire is suitable for distances of up to 500 ft. Use a three-conductor shielded cable for the sensor and setpoint adjustment connections. If the setpoint adjustment (slidebar) is not required, then an unshielded, 18 or 20 gauge, two-conductor, twisted pair cable may be used.

Connect T-55: See Fig. 51 for typical T-55 internal connections. Connect the T-55 SEN terminals to RTU Open J20-1 and J20-2. See Fig. 52.




Fig. 51 - T-55 Sensor

C08201




Fig. 52 - RTU Open T-55 Sensor Connections

C08460

Connect T-56: See Fig. 53 for T-56 internal connections. Install a jumper between SEN and SET terminals as illustrated. Connect T-56 terminals to RTU Open J20-1, J20-2 and J20-3 per Fig. 54.




Fig. 53 - T-56 Internal Connections

C08202





Fig. 54 - RTU Open T-56 Sensor Connections

C08461

50LC

Connect T-59: The T-59 space sensor requires a separate, isolated power supply of 24 VAC. See Fig. 55 for internal connections at the T-59. Connect the SEN terminal (BLU) to RTU Open J20-1. Connect the COM terminal (BRN) to J20-2. Connect the SET terminal (STO or BLK) to J20-3.



NOTE: Must use a separate isolated transformer.

Fig. 55 - Space Temperature Sensor Typical Wiring (33ZCT59SPT)

Indoor Air Quality (CO₂) Sensor —

The indoor air quality sensor accessory monitors space carbon dioxide (CO₂) levels. This information is used to monitor IAQ levels. Several types of sensors are available, for wall mounting in the space or in return duct, with and without LCD display, and in combination with space temperature sensors. Sensors use infrared technology to measure the levels of CO₂ present in the space air.

The CO₂ sensors are all factory set for a range of 0 to 2000 ppm and a linear mA output of 4 to 20. Refer to the instructions supplied with the CO₂ sensor for electrical requirements and terminal locations. See Fig. 56 for typical CO₂ sensor wiring schematic.




Fig. 56 - Indoor/Outdoor Air Quality (CO₂) Sensor (33ZCSPTCO2-01 or 33ZCSPTCO2LCD-01) Typical Wiring Diagram

To accurately monitor the quality of the air in the conditioned air space, locate the sensor near a return-air grille (if present) so it senses the concentration of CO₂ leaving the space. The sensor should be mounted in a location to avoid direct breath contact.

Do not mount the IAQ sensor in drafty areas such as near supply ducts, open windows, fans, or over heat sources. Allow at least 3 ft (0.9 m) between the sensor and any corner. Avoid mounting the sensor where it is influenced by the supply air; the sensor gives inaccurate readings if the supply air is blown directly onto the sensor or if the supply air does not have a chance to mix with the room air before it is drawn into the return airstream.

Wiring the Indoor Air Quality Sensor: For each sensor, use two 2-conductor 18 AWG (American Wire Gage) twisted-pair cables (unshielded) to connect the separate isolated 24 vac power source to the sensor and to connect the sensor to the control board terminals.

To connect the sensor to the control, identify the positive (4 to 20 mA) and ground (SIG COM) terminals on the sensor. See Fig. 56. Connect the 4-20 mA terminal to RTU Open J4-2 and connect the SIG COM terminal to RTU Open J4-3. See Fig. 57.

OAQ Sensor





Fig. 57 - RTU Open / Outdoor CO₂ Sensor (33ZCSPTCO2-01 or 33ZCSPTCO2LCD-01) Connections

**Outdoor Air Quality Sensor
(PNO 33ZCSENCO2 plus weatherproof enclosure) —**

The outdoor air CO₂ sensor is designed to monitor carbon dioxide (CO₂) levels in the outside ventilation air and interface with the ventilation damper in an HVAC system. The OAQ sensor is packaged with an outdoor cover. See Fig. 58. The outdoor air CO₂ sensor must be located in the economizer outside air hood.




C07135

Fig. 58 - Outdoor Air Quality Sensor Cover

Wiring the Outdoor Air CO₂ Sensor: A dedicated power supply is required for this sensor. A two-wire cable is required to wire the dedicated power supply for the sensor. The two wires should be connected to the power supply and terminals 1 and 2.

To connect the sensor to the control, identify the positive (4 to 20 mA) and ground (SIG COM) terminals on the OAQ sensor. See Fig. 56. Connect the 4 to 20 mA terminal to RTU Open J4-5. Connect the SIG COM terminal to RTU Open J4-6.

OAQ Sensor



C11086

**Fig. 59 - RTU Open / Outdoor CO₂ Sensor
(33ZCSENCO2) Connections**


Space Relative Humidity Sensor or Humidistat —

Humidi-MiZer® Control Wiring: In units equipped with the Humidi-MiZer option there are two loose wires loose in the control box (one PNK and one PNK/BLK) used to control the dehumidification function of the unit. These wires are meant to be tied to a space humidistat or thermidstat on an electromechanical unit. On RTU Open equipped units these wires must be connected to J11-7 & 8 to allow the Open board to operate the dehumidification function for the unit. Disconnect the J11 Phoenix style connector from the board and use the plug screws to secure the wires as follows: secure the PNK/BLK wires at pin 7 and the PNK wires at pin 8, and then reconnect the plug to the board at J11.

Relative Humidity Sensors (Space or Duct Mounted): The accessory space humidity sensor (33ZCSENSRH-01) or duct humidity sensor (33ZCSENDRH-01) is used to measure the relative humidity of air within the space or return air duct. For wiring distances up to 500 ft (152 m), use a 3-conductor, 18 or 20 AWG shielded cable. The shield must be removed from the sensor end of the cable and grounded at the unit end. The current loop power for sensor is provided by the RTU Open controller as 24vdc. Refer to the instructions supplied with the RH sensor for the electrical requirements and terminal locations. RTU Open configurations must be changed after adding an RH sensor. See Fig. 60 and 61 for typical RH sensor wiring.

- J4-1 or J4-4 = 24vdc loop power
- J4-2 or J4-5 = 4-20mA signal input

NOTE: The factory default for dehumidification control is normally open humidistat.



Vin - J4-1 or J4-4 24Vdc
Io - J4-2 or J4-5 -20mA output

C11087

Fig. 60 - Space Relative humidity Sensor Typical Wiring

50LC




Fig. 61 - Duct Relative Humidity Sensor Typical Wiring

C10839

Humidistat: The accessory humidistat provides the RTU Open insight to the relative humidity in the space. The humidistat reads the RH level in the space and compares it to its setpoint to operate a dry contact. The humidistat is a dedicated input on the configurable input 9 and tells the RTU Open when the RH level is HIGH or LOW. The normal condition for humidity is LOW.

To wire in the field:

- J5-8 = 24 VAC source for dry contact
- J5-7 = Signal input

Smoke Detector/Fire Shutdown (FSD) —

On 48LC units equipped with factory-installed Smoke Detector(s), the smoke detector controller implements the unit shutdown through its NC contact set connected to the unit's CTB input. The FSD function is initiated via the smoke detector's Alarm NO contact set. The RTU Open controller communicates the smoke detector's tripped status to the BAS building control. See Fig. 48 (RTU Open System Control wiring schematic).

The Fire Shutdown Switch configuration, *MENU* → *Config* → *Inputs* → *input 5*, identifies the normally open status of this input when there is no fire alarm.

Connecting Discrete Inputs —

Filter Status: The filter status accessory is a field-installed accessory. This accessory detects plugged filters. When installing this accessory, the unit must be configured for filter status by setting *MENU* → *Config* → *Inputs* → *input 3, 5, 8, or 9* to Filter Status and normally open (N/O) or normally closed (N/C). Input 8 or 9 is recommended for easy of installation. Refer to Fig. 46 and Fig. 48 for wire terminations at J5.

Fan Status: The fan status accessory is a field-installed accessory. This accessory detects when the indoor fan is blowing air. When installing this accessory, the unit must be configured for fan status by setting *MENU* → *Config* → *Inputs* → *input 3, 5, 8, or 9* to Fan Status and normally open (N/O) or normally closed (N/C). Input 8 or 9 is recommended for easy of installation. Refer to Fig. 46 and Fig. 48 for wire terminations at J5.

Remote Occupancy: The remote occupancy accessory is a field-installed accessory. This accessory overrides the unoccupied mode and puts the unit in occupied mode. When installing this accessory, the unit must be configured for remote occupancy by setting *MENU* → *Config* → *Inputs* → *input 3, 5, 8, or 9* to Remote Occupancy and normally open (N/O) or normally closed (N/C).

Also set *MENU* → *Schedules* → *occupancy source* to DI on/off. Input 8 or 9 is recommended for easy of installation. Refer to Fig. 46 and Table 3 for wire terminations at J5.

Power Exhaust (output): The relay used by the RTU Open board to control power exhaust is a dry contact which means it does not have 24vac. This 24vac must be connected to the relay to allow it to operate the power exhaust relay in the PE accessory. A 24vac source must be provided to J11-2 on the RTU Open control board. This can be provided by the unit's transformer from various sources. The "R" terminal on the unit's low voltage terminal board (LVTB) is a logical source. Refer to Fig. 46 and Fig. 48 for wire terminations at J11.

Communication Wiring - Protocols

General —

Protocols are the communication languages spoken by control devices. The main purpose of a protocol is to communicate information in the most efficient method possible. Different protocols exist to provide different kinds of information for different applications. In the BAS application, many different protocols are used, depending on manufacturer. Protocols do not change the function of a controller; just make the front end user different.

The RTU Open can be set to communicate on four different protocols: BACnet, Modbus, N2, and LonWorks. Switch 3 (SW3) on the board is used to set protocol and baud rate. Switches 1 and 2 (SW1 and SW2) are used to set the board's network address. See Fig. 62 and 63 for protocol switch settings and address switches. The 3rd party connection to the RTU Open is through plug J19. See Fig. 64 for wiring.

NOTE: Power must be cycled after changing the SW1-3 switch settings.

Refer to the *RTU Open v2 Integration Guide* (Catalog No. 11-808-434-01) for more detailed information on protocols, 3rd party wiring, and networking.

SW3 Protocol Selection

PROTOCOL	DS8	DS7	DS6	DS5	DS4	DS3	DS2	DS1
BACnet MS/TP (Master)	Unused	OFF	OFF	OFF	ON	OFF	Select Baud	Select Baud
Modbus (Slave)	Unused	OFF	OFF	ON	ON	OFF	Select Baud	Select Baud
N2 (Slave)	Unused	OFF	OFF	OFF	ON	ON	OFF	OFF
LonWorks	Unused	ON	ON	OFF	ON	OFF	OFF	ON


NOTE:

DS = Dip Switch

BACnet MS/TP SW3 example shown

Baud Rate Selections

BAUD RATE	DS2	DS1
9600	OFF	OFF
19,200	ON	OFF
38,400	OFF	ON
76,800	ON	ON



C07166

Fig. 62 - RTU Open SW3 Dip Switch Settings



C10815

Fig. 63 - RTU Open Address Switches




Fig. 64 - Network Wiring

C10816

Local Access

BACview⁶ Handheld: The BACview⁶ is a keypad/display interface used to connect to the RTU Open to access the control information, read sensor values, and test the RTU, see Fig. 65. This is an accessory interface that does not come with the RTU Open controller and can only be used at the unit. Connect the BACview⁶ to the RTU Open J12 local access port. There are two password protected levels in the display (User and Admin). The user password is defaulted to 0000 but can be changed. The Admin password is 1111 and cannot be changed. There is a 10 minute auto logout if a screen is idle. See Form 48-50HCTQ-02T (or later), Appendix A for navigation and screen content.

Virtual BACview: Virtual BACview is a freeware computer program that functions as the BACview⁶ Handheld. The USB Link interface (USB-L) is required to connect a

computer to the RTU Open board. The link cable connects a USB port to the J12 local access port. This program functions and operates identical to the handheld.

RTU Open Troubleshooting —

Communication LEDs The LEDs indicate if the controller is speaking to the devices on the network. The LEDs should reflect communication traffic based on the baud rate set. The higher the baud rate the more solid the LEDs will appear. See Table 4.

NOTE: Refer to Catalog No. 48-50HCTQ-02T (or later) for complete configuration of RTU Open, operating sequences and troubleshooting information. Refer to *RTU Open v2 Integration Guide* (Catalog No. 11-808-434-01) for details on configuration and troubleshooting of connected networks. Have a copy of these manuals available at unit start-up.

50LC




Fig. 65 - BACview⁶ Handheld Connections

C12749

Table 4 – LEDs

The LEDs on the RTU Open show the status of certain functions

If this LED is on...	Status is...
Power	RTU Open has power
Rx	RTU Open is receiving data from the network segment
Tx	RTU Open is transmitting data over the network segment
DO#	The digital output is active

The **Run** and **Error** LEDs indicate control module and network status

If Run LED shows...	And Error LED shows...	Status is...
2 flashes per second	Off	Normal
2 flashes per second	2 flashes, alternating with Run LED	Five minute auto–restart delay after system error
2 flashes per second	3 flashes, then off	Control module has just been formatted
2 flashes per second	4 flashes, then pause	Two or more devices on this network have the same ARC156 network address
2 flashes per second	On	Exec halted after frequent system errors or control programs halted
5 flashes per second	On	Exec start–up aborted, Boot is running
5 flashes per second	Off	Firmware transfer in progress, Boot is running
7 flashes per second	7 flashes per second, alternating with Run LED	Ten second recovery period after brownout
14 flashes per second	14 flashes per second, alternating with Run LED	Brownout
On	On	Failure. Try the following solutions: <ul style="list-style-type: none"> • Turn RTU Open off, then on. • Format RTU Open. • Download memory to RTU Open. • Replace RTU Open.

50LC

Outdoor Air Enthalpy Control (PNO 33CSENTHSW)

The enthalpy control (33CSENTHSW) is available as a field-installed accessory to be used with the EconoMi\$er2 damper system. The outdoor air enthalpy sensor is part of the enthalpy control. (The separate field-installed accessory return air enthalpy sensor (33SENTSEN) is required for differential enthalpy control. See Fig. 66.)

Locate the enthalpy control in the economizer next to the Actuator Motor. Locate two GRA leads in the factory harness and connect the gray lead labeled “ESL” to the terminal labeled “LOW”. See Fig. 66. Connect the enthalpy control power input terminals to economizer actuator power leads RED (connect to 24V) and BLK (connect to GND).

The outdoor enthalpy changeover setpoint is set at the enthalpy controller.




Fig. 66 - Enthalpy Switch (33CSENTHSW) Connections

C11160

Differential Enthalpy Control —

Differential enthalpy control is provided by sensing and comparing the outside air and return air enthalpy conditions. Install the outdoor air enthalpy control as described above. Add and install a return air enthalpy sensor.

Return Air Enthalpy Sensor —

Mount the return-air enthalpy sensor (33SENTSEN) in the return-air section of the economizer. The return air sensor is wired to the enthalpy controller (33CSENTHSW). See Fig. 67.




Fig. 67 - Outside and Return Air Enthalpy Sensor Wiring

C11161

To wire the return air enthalpy sensor, perform the following:

1. Use a 2-conductor, 18 or 20 AWG, twisted pair cable to connect the return air enthalpy sensor to the enthalpy controller.
2. Connect the field-supplied RED wire to (+) spade connector on the return air enthalpy sensor and the (+) terminal on the enthalpy controller. Connect the BLK wire to (-) spade connector on the return air enthalpy sensor and the (-) terminal on the enthalpy controller.

Smoke Detectors

Smoke detectors are available as factory-installed options on 48HC models. Smoke detectors may be specified for Supply Air only or for Return Air without or with economizer or in combination of Supply Air and Return Air. All components necessary for operation are factory-provided and mounted. The unit is factory-configured for immediate smoke detector shutdown operation; additional wiring or modifications to unit terminal board may be necessary to complete the unit and smoke detector configuration to meet project requirements.

Units equipped with factory-optional Return Air smoke detectors require a relocation of the sensor module at unit installation. See Fig. 68 for the as shipped location.

Completing Installation of Return Air Smoke Sensor:

1. Unscrew the two screws holding the Return Air Smoke Detector assembly. See Fig. 69, Step 1. Save the screws.
2. Turn the assembly 90 and then rotate end to end. Make sure that the elbow fitting is pointing down. See Fig. 69, Step 2.
3. Screw the sensor and detector plate into its operating position using screws from Step 1. See Fig. 69, Step 3.
4. Connect the flexible tube on the sampling inlet to the sampling tube on the basepan.





Fig. 69 - Completing Installation of Return Air Smoke Sensor



C12282

Fig. 68 - Return Air Smoke Detector, Shipping Position

Additional Application Data —

Refer to Catalog No. HKRNKA-1XA for discussions on additional control features of these smoke detectors including multiple unit coordination.

C12283

Table 5 – Unit Wire/Fuse or HACR Breaker Sizing Data (cont)

UNIT	NO M, V-PH-HZ	ELEC. HTR				NO C.O. or UNPWR C.O.										w/ PWR C.O.									
		CRHEATER***A00	Nom (kW)	FLA	MCA	NO PE.				w/ P.E. (pwrd fr/unit)				NO PE.				w/ P.E. (pwrd fr/unit)							
						MAX FUSE or BRKR	FLA	DISC. SIZE	MCA	MAX FUSE or BRKR	FLA	DISC. SIZE	MCA	MAX FUSE or BRKR	FLA	DISC. SIZE	MCA	MAX FUSE or BRKR	FLA	DISC. SIZE	MCA				
50LC-005	DD-STD	NONE	4.9/6.5	13.6/15.6	28.0	40	29	94	30.0	40	31	96	33.0	45	34	99	35.0	45	36	101	101/101				
			6.5/8.7	18.1/20.9	28/29	40/40	29/29	94/94	30/31	40/40	31/31	96/96	33/35	45/45	34/34	99/99	35/37	45/45	36/36	101/101	101/101				
			12.0/16.0	33.4/38.5	32/35	40/40	29/33	94/94	34/38	40/40	32/35	96/96	38/41	45/45	35/38	99/99	40/44	45/45	37/40	101/101	101/101				
			15.8/21.0	43.8/50.5	51/57	60/60	47/53	94/94	53/60	60/60	49/55	96/96	57/63	60/70	52/58	60/70	59/66	60/70	55/60	60/70	101/101	101/101			
			NONE	-	64/72	70/80	59/67	94/94	66/75	70/80	61/69	98/96	70/78	80/80	64/72	99/99	72/81	80/90	67/74	80/90	101/101	101/101			
			4.9/6.5	13.6/15.6	27/27	40/40	27/27	110	29/29	40/40	29/29	112	32/31	45/45	32/32	115	34/33	45/45	35/34	117	117/117	117/117			
			6.5/8.7	18.1/20.9	27/27	40/40	27/27	110/110	29/29	40/40	29/29	112/112	32/33	45/45	32/32	115/115	34/35	45/45	35/34	117/117	117/117	117/117			
			12.0/16.0	33.4/38.5	30/33	40/40	27/30	110/110	30/33	40/40	30/33	112/112	36/39	45/45	33/36	115/115	38/42	45/45	35/38	117/117	117/117	117/117			
			15.8/21.0	43.8/50.5	49/55	50/60	45/51	110/110	51/58	60/60	47/53	112/112	55/61	60/70	51/56	115/115	57/64	60/70	53/58	117/117	117/117	117/117			
			15.8/21.0	43.8/50.5	62/70	70/80	57/65	110/110	64/73	70/80	64/73	112/112	68/76	70/80	63/70	115/115	70/79	80/80	65/72	80/80	117/117	117/117			
460-3-60	DD-STD	NONE	4.9/6.5	13.6/15.6	30/29	40/40	30/29	140	32/31	45/40	32/31	142	34/34	45/45	36/35	145	36/36	50/45	38/37	147	147/147				
			6.5/8.7	18.1/20.9	30/29	40/40	30/29	140/140	32/32	45/40	32/31	142/142	34/35	45/45	36/35	145/145	36/38	50/45	38/37	147/147	147/147				
			12.0/16.0	33.4/38.5	33/36	40/40	31/33	140/140	36/38	45/40	33/35	142/142	39/42	45/45	36/39	145/145	42/44	50/45	38/41	147/147	147/147				
			15.8/21.0	43.8/50.5	53/58	60/60	48/53	140/140	55/60	60/70	50/55	142/142	59/64	60/70	54/59	145/145	61/66	70/70	56/61	147/147	147/147				
			NONE	-	68/73	70/80	60/67	140/140	68/75	70/80	62/69	142/142	72/79	80/80	66/73	145/145	74/81	80/90	68/75	147/147	147/147				
			6.0	7.2	13.0	20	14	46	14	20	15	47	16.0	20	16	48	17	20	20	17	49	49			
			11.5	13.8	22	25	24	46	15	20	15	47	17	20	16	48	18	20	20	17	49	49			
			14.0	16.8	26	30	24	46	27	30	25	47	25	25	26	48	26	30	30	24	49	49			
			23.0	27.7	40	40	36	46	41	45	38	47	42	45	39	48	44	45	45	40	49	49			
			6.0	7.2	12.0	15	12	53	13	15	13	54	15.0	20	15	55	16	20	20	16	56	56			
575-3-60	DD-STD	NONE	6.0	7.2	13	15	12	53	14	15	13	54	15	16	17	20	16	20	16	56	56				
			11.5	13.8	21	25	19	53	22	25	20	54	24	25	22	25	25	25	23	23	23				
			14.0	16.8	25	25	23	53	26	30	24	54	27	30	25	25	29	30	26	26	26				
			23.0	27.7	38	40	35	53	40	40	36	54	41	45	38	55	42	45	39	39	39				
			NONE	-	13.0	15	13	69	14	20	14	70	15.0	20	16	71	16	20	20	17	72	72			
			6.0	7.2	14	15	13	69	15	20	14	70	17	20	16	71	18	20	20	17	72	72			
			11.5	13.8	22	25	20	69	23	25	21	70	25	25	23	71	26	30	30	24	72	72			
			14.0	16.8	26	30	24	69	27	30	25	70	29	30	26	71	30	30	30	27	72	72			
			23.0	27.7	39	40	36	69	41	45	37	70	42	45	39	71	43	45	45	40	72	72			
			9.2	9.2	11.0	15	12	38	13	15	14	40	13.0	15	13	40	15	20	20	16	42	42			
575-3-60	MED	NONE	9.2	9.2	17	20	15	38	19	20	17	40	19	20	17	40	21	25	19	42	42				
			13.8	13.8	22	25	20	38	25	25	23	40	24	25	22	40	27	30	25	42	42				
			9.2	9.2	10.0	15	10	43	12	15	12	45	12.0	15	12	45	14	15	14	47	47				
			13.8	13.8	15	15	14	43	17	20	16	45	17	20	16	45	20	20	18	47	47				
			NONE	-	21	25	19	43	23	25	21	45	23	25	21	45	25	30	23	23	47	47			
			9.2	9.2	12.0	15	12	56	14	15	14	58	13.0	15	14	58	15	20	16	60	60				
13.8	13.8	17	20	16	56	20	20	18	58	19	20	18	58	22	25	20	20	60	60						
23	23	23	25	21	56	25	30	23	58	25	30	25	58	27	30	25	25	60	60						

See "Legend and Notes for Tables 5 and 6" on page 47.

Table 5 – Unit Wire/Fuse or HACR Breaker Sizing Data (cont)

UNIT	NO M. V-Ph-HZ	ELEC. HTR				NO C.O. or UNPWR C.O.								w/ PWRD C.O.							
		CRHEATER***A00	Nom (kW)	FLA	NO PE.	MCA	MAX FUSE or HACR BRKR	DISC. SIZE		MCA	MAX FUSE or HACR BRKR	DISC. SIZE		MCA	MAX FUSE or HACR BRKR	DISC. SIZE		MCA	MAX FUSE or HACR BRKR	DISC. SIZE	
				FLA				LRA	FLA			LRA	FLA			LRA	FLA			LRA	FLA
SOLC-006	DD-STD	NONE	-	-	31.0	45	31/30	121	33	33/33	45	33/33	123	36.0	50	37	126	38.0	50	39	128
		102A	4.9/6.5	13.6/15.6	31/31	45/45	31/30	121/121	33/33	33/33	45/45	33/33	123/123	36/36	50/50	37/37	126/126	38/38	50/50	39/39	128/128
		104B	7.9/10.5	21.9/25.3	37/41	45/45	33/37	121/121	36/40	39/43	45/45	39/43	123/123	43/47	50/50	39/43	126/126	45/49	50/50	41/45	128/128
		105A	12.0/16.0	33.4/38.5	51/57	60/60	47/53	121/121	49/55	53/60	60/60	60/60	123/123	57/63	60/70	52/58	126/126	59/66	60/70	55/60	128/128
		104B+104B	15.8/21.0	43.8/50.5	64/72	70/80	59/67	121/121	68/75	61/69	70/80	70/80	123/123	70/78	80/80	64/72	126/126	72/81	80/90	67/74	128/128
		104B+105A	19.9/26.5	55.2/63.8	78/89	80/90	72/81	121/121	81/91	74/84	90/100	90/100	123/123	84/95	90/100	78/87	126/126	87/97	90/100	80/90	128/128
	MED	NONE	-	-	-	31/31	45/45	31/30	141	33/33	45/45	33/33	143	36/35	50/50	36/36	146	38/37	50/50	39/38	148
		102A	4.9/6.5	13.6/15.6	31/31	45/45	31/30	141/141	33/33	33/33	45/45	33/33	143/143	36/35	50/50	36/36	146/146	38/37	50/50	39/38	148/148
		104B	7.9/10.5	21.9/25.3	36/40	45/45	33/37	141/141	39/43	39/43	45/45	36/39	143/143	42/46	50/50	39/42	146/146	45/49	50/50	41/45	148/148
		105A	12.0/16.0	33.4/38.5	51/57	60/60	47/52	141/141	53/59	53/59	60/60	60/60	143/143	57/63	60/70	52/58	146/146	59/65	60/70	54/60	148/148
		104B+104B	15.8/21.0	43.8/50.5	64/72	70/80	59/66	141/141	68/74	61/68	70/80	70/80	143/143	70/78	80/80	64/71	146/146	72/80	80/90	66/74	148/148
		104B+105A	19.9/26.5	55.2/63.8	78/88	80/90	72/81	141/141	80/91	74/83	90/100	90/100	143/143	84/94	90/100	77/87	146/146	86/97	90/100	79/89	148/148
HIGH	NONE	-	-	-	32/32	45/45	33/32	167	35/34	50/45	35/34	169	37/36	50/50	38/37	172	39/38	50/50	40/39	174	
	102A	4.9/6.5	13.6/15.6	32/32	45/45	33/32	167/167	34/34	34/34	50/45	35/34	169/169	37/36	50/50	38/37	172/172	39/38	50/50	40/39	174/174	
	104B	7.9/10.5	21.9/25.3	38/41	45/45	35/38	167/167	41/44	41/44	50/45	37/40	169/169	44/47	50/50	41/44	172/172	47/50	50/50	43/46	174/174	
	105A	12.0/16.0	33.4/38.5	53/58	60/60	48/53	167/167	55/60	55/60	60/70	60/70	169/169	59/64	60/70	54/59	172/172	61/66	70/70	56/61	174/174	
	104B+104B	15.8/21.0	43.8/50.5	66/73	70/80	60/67	167/167	68/75	62/69	70/80	70/80	169/169	72/79	80/80	66/73	172/172	74/81	80/90	68/75	174/174	
	104B+109A	19.9/26.5	55.2/63.8	80/89	80/90	73/82	167/167	82/92	76/85	90/100	90/100	169/169	86/96	90/100	79/88	172/172	88/98	90/100	81/90	174/174	
DD-STD	NONE	-	-	-	15.0	20	15	57	16	20	20	58	17.0	20	17	59	18.0	25	19	60	
	106A	6.0	7.2	15	15	20	15	57	16	20	20	58	17	20	17	59	18	25	19	60	
	108A	11.5	13.8	22	20	25	20	57	22	25	25	58	25	25	23	59	26	30	24	60	
	109A	14.0	16.8	26	30	30	24	57	27	30	30	58	29	30	26	59	30	30	28	60	
	108A+108A	23.0	27.7	40	40	40	36	57	41	45	45	58	42	45	39	59	44	45	40	60	
	108A+109A	25.5	30.7	43	45	40	57	45	45	45	45	58	46	50	42	59	47	50	44	60	
MED	NONE	-	-	-	15.0	20	15	66	16	20	20	67	17.0	20	17	68	18	25	18	69	
	106A	6.0	7.2	15	15	20	15	66	16	20	20	67	17	20	17	68	18	25	18	69	
	108A	11.5	13.8	22	20	25	20	66	23	25	25	67	25	25	23	68	26	30	24	69	
	109A	14.0	16.8	26	30	30	24	66	27	30	30	67	29	30	26	68	30	30	27	69	
	108A+108A	23.0	27.7	39	40	40	36	66	41	45	45	67	42	45	39	68	43	45	40	69	
	108A+109A	25.5	30.7	43	45	40	66	44	44	45	45	67	46	50	42	68	47	50	43	69	
HIGH	NONE	-	-	-	15.0	20	15	80	16	20	20	81	17.0	20	17	82	18.0	25	18	83	
	106A	6.0	7.2	15	15	20	15	80	16	20	20	81	17	20	17	82	18	25	18	83	
	108A	11.5	13.8	22	20	25	20	80	23	25	25	81	25	25	23	82	26	30	24	83	
	109A	14.0	16.8	26	30	30	24	80	27	30	30	81	29	30	26	82	30	30	27	83	
	108A+108A	23.0	27.7	39	40	40	36	80	41	45	45	81	42	45	39	82	43	45	40	83	
	108A+109A	25.5	30.7	43	45	40	80	44	44	45	45	81	46	50	42	82	47	50	43	83	
DD-STD	NONE	-	-	-	12.0	15	12	44	14	20	20	46	14.0	20	14	46	16.0	20	16	48	
	298A	13.8	13.8	22	20	25	20	44	25	25	25	46	24	25	22	46	27	30	25	48	
	301A	23.0	23.1	34	35	31	44	44	36	40	40	46	36	40	33	46	38	40	35	48	
	NONE	-	-	-	12.0	15	12	53	13	15	15	55	13.0	15	14	55	15	20	16	57	
	298A	13.8	13.8	22	20	25	20	53	24	25	25	55	25	25	22	55	26	30	24	57	
	301A	23.0	23.1	33	35	31	53	31	36	40	40	55	35	40	33	55	38	40	35	57	
MED	NONE	-	-	-	13.0	15	13	62	14.0	20	20	64	14.0	20	15	64	16.0	20	17	66	
	298A	13.8	13.8	23	25	21	62	25	25	30	30	64	25	25	23	64	27	30	25	66	
	301A	23.0	23.1	35	35	32	62	37	37	40	40	64	37	40	34	64	39	40	36	66	
	NONE	-	-	-	13.0	15	13	62	14.0	20	20	64	14.0	20	15	64	16.0	20	17	66	
	298A	13.8	13.8	23	25	21	62	25	25	30	30	64	25	25	23	64	27	30	25	66	
	301A	23.0	23.1	35	35	32	62	37	37	40	40	64	37	40	34	64	39	40	36	66	

See "Legend and Notes for Tables 5 and 6" on page 47.

Table 6 – Unit Wire/Factory Installed HACR Breaker Sizing Data (cont)

UNIT	NO M, V-Ph-HZ	ELEC. HTR				NO C.O. or UNPWR C.O.																	
		CRHEATER***400	Nom (kW)	FLA	NO PE.			w/ P.E. (pwrd fr/unit)			NO PE.			w/ PWR C.O.									
					MCA	HACR BRKR	DISC. SIZE FLA LRA	MCA	HACR BRKR	DISC. SIZE FLA LRA	MCA	HACR BRKR	DISC. SIZE FLA LRA	MCA	HACR BRKR	DISC. SIZE FLA LRA							
50LC-005	DD-STD	NONE	4.9/6.5	13.6/15.6	28.0	40	29/29	94	30.0	40	31/31	96	33.0	45	34	35.0	45	36/36	36	101			
					29/29	40/40	29/29	94/94	31/31	40/40	31/31	96/96	35/35	40/40	31/31	96/96	35/35	40/40	31/31	96/96	36/36	101/101	
					35/35	40/40	29/33	94/94	38/38	40/40	32/35	96/96	38/38	40/40	32/35	96/96	38/38	40/40	32/35	96/96	37/40	101/101	
					57/57	60/60	47/53	94/94	60/60	60/60	49/55	96/96	60/60	60/60	49/55	96/96	60/60	60/60	49/55	96/96	55/60	101/101	
					72/72	80/80	59/67	94/94	75/75	80/80	61/69	96/96	75/75	80/80	61/69	96/96	75/75	80/80	61/69	96/96	67/74	101/101	
					27/27	40/40	27/27	110	29/29	40/40	29/29	112	32/32	45/45	32/32	115	34/34	45/45	32/32	115	34/34	35/34	117
					27/27	40/40	27/27	110/110	29/29	40/40	29/29	112/112	33/33	45/45	33/32	115/115	35/35	45/45	33/32	115/115	35/35	35/34	117/117
					33/33	40/40	27/30	110/110	36/36	40/40	30/33	112/112	39/39	45/45	33/33	115/115	42/42	45/45	33/33	115/115	35/38	117/117	
					55/55	60/60	45/51	110/110	58/58	60/60	47/53	112/112	61/61	70/70	51/56	115/115	64/64	70/70	51/56	115/115	53/58	117/117	
					70/70	80/80	57/65	110/110	73/73	80/80	59/67	112/112	76/76	80/80	63/70	115/115	79/79	80/80	63/70	115/115	65/72	117/117	
50LC-005	DD-STD	NONE	6.0	7.2	12	15	14	46	14	20	15	47	16	20	16	17	20	17	49				
					14	20	14	46	15	20	15	47	17	20	16	18	20	17	20	17	49		
					22	25	24	46	24	25	22	47	25	25	23	48	26	30	24	24	49		
					26	30	24	46	27	30	25	47	29	30	26	48	30	30	28	28	49		
					40	40	36	46	41	45	47	47	42	45	39	48	44	45	44	45	49		
					30/30	40/40	30/29	140	32/32	45/45	32/31	142	34/34	45/45	32/31	142	36/36	50/50	38/37	50/50	38/37	147	
					30/30	40/40	30/29	140/140	32/32	45/45	32/31	142/142	35/35	45/45	32/31	142/142	36/35	50/50	38/38	50/50	38/37	147/147	
					36/36	40/40	31/33	140/140	38/38	45/45	33/35	142/142	42/42	45/45	33/35	142/142	44/44	50/50	44/44	50/50	38/41	147/147	
					58/58	60/60	48/53	140/140	60/60	60/60	50/55	142/142	64/64	70/70	54/59	145/145	66/66	70/70	54/59	145/145	56/61	147/147	
					73/73	80/80	60/67	140/140	75/75	80/80	62/69	142/142	79/79	80/80	66/73	145/145	81/81	90/90	66/73	145/145	68/75	147/147	
50LC-005	MED	NONE	6.0	7.2	12	15	12	53	13	15	13	54	15	20	15	20	16	20	56				
					13	15	12	53	14	15	13	54	15	15	17	17	20	16	20	56			
					21	25	19	53	22	25	20	54	24	25	22	55	25	25	23	25	56		
					25	25	23	53	26	26	24	54	27	30	25	55	29	30	26	26	56		
					38	40	35	53	40	40	36	54	41	45	38	55	42	45	39	45	56		
					13	15	13	69	14	15	14	70	15	20	16	71	16	20	17	20	72		
					14	15	13	69	15	20	14	70	17	20	16	71	18	20	17	20	72		
					22	25	20	69	23	25	21	70	25	25	23	71	26	30	24	24	72		
					26	30	24	69	27	30	25	70	29	30	26	71	30	30	27	27	72		
					39	40	36	69	41	45	37	70	42	45	39	71	43	45	40	40	72		
50LC-005	DD-STD	NONE	9.2	13.8	11	15	12	38	13	15	14	40	13	15	13	15	20	16	42				
					17	20	15	38	19	20	17	40	19	20	17	40	21	25	19	42			
					22	25	20	38	25	25	23	40	24	25	22	40	27	30	25	25	42		
					10	15	10	43	12	15	12	45	12	15	12	45	14	15	14	14	47		
					15	15	14	43	17	20	16	45	17	20	16	45	20	20	18	18	47		
					21	25	19	43	23	25	21	45	23	25	21	45	25	30	23	23	47		
					12	15	12	56	14	15	14	58	13	15	14	58	15	20	16	16	60		
					17	20	16	56	20	20	18	58	19	20	18	58	22	25	20	20	60		
					23	25	21	56	25	30	23	58	25	30	23	58	27	30	25	25	60		

See "Legend and Notes for Tables 5 and 6" on page 47.



Table 6 – Unit Wire/Factory Installed HACR Breaker Sizing Data (cont)

UNIT	IFM TYPE	ELEC. HTR			NO C.O. or UNPWR C.O.						w/ PWRD C.O.					
		CRHEATER***A00	Nom (kW)	FLA	NO PE.			w/ P.E. (pwrd fr/unit)			NO PE.			w/ P.E. (pwrd fr/unit)		
					MCA	HACR BRKR	DISC. SIZE FLA LRA	MCA	HACR BRKR	DISC. SIZE FLA LRA	MCA	HACR BRKR	DISC. SIZE FLA LRA	MCA	HACR BRKR	DISC. SIZE FLA LRA
50LC-006	DD - STD	NONE	-	-	31	121	33	123	36.0	50	37	126	38.0	50	39	128
		102A	4.9/6.5	13.6/15.6	31/31	121/121	33/33	123/123	33/33	45/45	33/33	123/123	36/36	50/50	39/39	128/128
		104B	7.9/10.5	21.9/25.3	41/41	121/121	43/43	123/123	47/47	50/50	39/43	126/126	49/49	50/50	41/45	128/128
		105A	12.0/16.0	33.4/38.5	47/53	121/121	60/60	123/123	63/63	70/70	52/58	126/126	66/66	70/70	55/60	128/128
		104B+104B	15.9/21.0	43.8/50.5	59/67	121/121	75/75	123/123	78/78	80/80	64/72	126/126	81/81	90/90	67/74	128/128
		104B+105A	19.9/26.5	55.2/63.8	72/82	121/121	91/91	123/123	95/95	100/100	78/87	126/126	97/97	100/100	80/90	128/128
	MED	NONE	-	-	31/30	141	33/33	143	36/36	50/50	36/36	146	38/38	50/50	39/38	148
		102A	4.9/6.5	13.6/15.6	31/30	141/141	33/33	143/143	36/36	45/45	33/33	143/143	36/36	50/50	39/38	148/148
		104B	7.9/10.5	21.9/25.3	33/37	141/141	43/43	143/143	46/46	50/50	39/42	146/146	49/49	50/50	41/45	148/148
		105A	12.0/16.0	33.4/38.5	47/52	141/141	59/59	143/143	63/63	70/70	52/58	146/146	65/65	70/70	54/60	148/148
		104B+104B	15.9/21.0	43.8/50.5	59/66	141/141	74/74	143/143	78/78	80/80	64/71	146/146	80/80	90/90	66/74	148/148
		104B+105A	19.9/26.5	55.2/63.8	72/81	141/141	91/91	143/143	94/94	100/100	77/87	146/146	97/97	100/100	79/89	148/148
460-3-60	DD - STD	NONE	-	-	15	57	16	58	17.0	20	17	59	18.0	25	19	60
		106A	6.0	7.2	15	57	16	58	17	20	16	58	18	25	19	60
		108A	11.5	13.8	22	57	24	58	25	25	22	58	26	30	24	60
		109A	14.0	16.8	26	57	27	58	29	30	25	58	30	30	28	60
		108A+108A	23.0	27.7	39	57	41	58	42	45	38	58	44	45	44	60
		108A+109A	25.5	30.7	43	57	45	58	46	45	41	58	47	50	44	60
	MED	NONE	-	-	15	66	16	67	17	20	16	67	18	25	18	69
		106A	6.0	7.2	15	66	16	67	17	20	16	67	18	25	18	69
		108A	11.5	13.8	22	66	23	67	25	25	23	68	26	30	24	69
		109A	14.0	16.8	26	66	27	67	29	30	25	68	30	30	27	69
		108A+108A	23.0	27.7	39	66	41	67	42	45	39	68	43	45	40	69
		108A+109A	25.5	30.7	43	66	44	67	46	45	41	68	47	50	43	69
575-3-60	DD - STD	NONE	-	-	15	80	16	81	17.0	20	17	82	18.0	25	18	83
		106A	6.0	7.2	15	80	16	81	17	20	16	81	18	25	18	83
		108A	11.5	13.8	22	80	23	81	25	25	23	82	26	30	24	83
		109A	14.0	16.8	26	80	27	81	29	30	25	82	30	30	27	83
		108A+108A	23.0	27.7	39	80	41	81	42	45	39	82	43	45	40	83
		108A+109A	25.5	30.7	43	80	44	81	46	45	41	82	47	50	43	83
	MED	NONE	-	-	12	44	13	45	14	20	14	46	16.0	20	16	48
		298A	13.8	13.8	22	44	25	46	24	25	23	46	27	30	25	48
		301A	23.0	23.1	34	44	36	46	36	40	33	46	38	40	35	48
		NONE	-	-	12	53	13	55	13	15	14	55	15	20	16	57
		298A	13.8	13.8	22	53	24	55	24	25	22	55	26	30	24	57
		301A	23.0	23.1	33	53	36	55	35	40	33	55	38	40	35	57
HIGH	NONE	-	-	13	62	14.0	64	14.0	20	15	64	16.0	20	17	66	
	298A	13.8	13.8	23	62	25	64	25	25	23	64	27	30	25	66	
	301A	23.0	23.1	35	62	37	64	37	40	34	64	39	40	36	66	

See "Legend and Notes for Tables 5 and 6" on page 47.

Legend and Notes for Tables 5 and 6

LEGEND:

BD	- Belt drive indoor fan motor
BRKR	- Circuit breaker
CO	- Convenient outlet
DD	- Direct drive indoor fan motor
DISC	- Disconnect
FLA	- Full load amps
IFM	- Indoor fan motor
LRA	- Locked rotor amps
MCA	- Minimum circuit amps
MOCP	- MAX FUSE or HACR Breaker
PE	- Power exhaust
PWRD CO	- Powered convenient outlet
UNPWR CO	- Unpowered convenient outlet

NOTES:

- In compliance with NEC requirements for multimotor and combination load equipment (refer to NEC Articles 430 and 440), the overcurrent protective device for the unit shall be fuse or HACR breaker. Canadian units may be fuse or circuit breaker.
- Unbalanced 3-Phase Supply Voltage**
Never operate a motor where a phase imbalance in supply voltage is greater than 2%. Use the following formula to determine the percentage of voltage imbalance.

$$\% \text{ Voltage Imbalance} = 100 \times \frac{\text{max voltage deviation from average voltage}}{\text{average voltage}}$$

Example: Supply voltage is 230-3-60



AB = 224 v
BC = 231 v
AC = 226 v

$$\begin{aligned} \text{Average Voltage} &= \frac{(224 + 231 + 226)}{3} = \frac{681}{3} \\ &= 227 \end{aligned}$$

Determine maximum deviation from average voltage.

(AB) 227 - 224 = 3 v

(BC) 231 - 227 = 4 v

(AC) 227 - 226 = 1 v

Maximum deviation is 4 v.

Determine percent of voltage imbalance.

$$\begin{aligned} \% \text{ Voltage Imbalance} &= 100 \times \frac{4}{227} \\ &= 1.76\% \end{aligned}$$

This amount of phase imbalance is satisfactory as it is below the maximum allowable 2%.

IMPORTANT: If the supply voltage phase imbalance is more than 2%, contact your local electric utility company immediately.

50LC

Step 12 — Adjust Factory-Installed Options

Smoke Detectors —

Smoke detector(s) will be connected at the Central Terminal Board (CTB), at terminals marked “Smoke Shutdown”. Remove jumper JMP 3 when ready to energize unit.

Step 13 — Install Accessories

Available accessories include:

- Curb
- Thru-base connection kit (must be installed before unit is set on curb)
- Electric heaters and single-point connection kits
- EconoMi\$er X (with control)
- EconoMi\$er2 (without control/for external signal)
- Power Exhaust
- Differential dry-bulb sensor (EconoMi\$er2)
- Outdoor enthalpy sensor
- Differential enthalpy sensor
- CO2 sensor
- Louvered hail guard
- Phase monitor control

Refer to separate installation instructions for information on installing these accessories.

Pre-Start and Start-Up —

This completes the mechanical installation of the unit. Refer to the unit’s Service Manual for detailed Pre-Start and Start-Up instructions. Download the latest versions from HVAC Partners (www.hvacpartners.com).

APPENDIX — VFD Operation with Remote Keypad

All 50LC size 04-06 units are equipped with a VFD (Variable Frequency Drive) to automatically adjust the indoor fan motor speed in sequence with the unit's ventilation, cooling and heating operation. The VFD keypad is included as standard on electro mechanical and RTU Open models. See Fig. 71 for location of the VFD and the VFD keypad in these units.

NOTE: *ComfortLink* models do not include the VFD keypad as VFD control operation is accessed through the *ComfortLink* controls.

The VFD keypad is shown in Fig. 70. The function of SOFT KEYS 1 and 2 change depending on what is displayed on the screen. The function of SOFT KEY 1 matches the word in the lower left-hand box on the display screen. The function of SOFT KEY 2 matches the word in the lower right-hand box on the display screen. If the box is empty, then the SOFT KEY does not have a function on that specific screen. The UP and DOWN keys are used to navigate through the menus. The OFF key is used to turn off the VFD. The AUTO key is used to change control of the drive to automatic control. The HAND key is used to change control of the drive to local (hand held) control. The HELP button is used to access the help screens.

For the VFD to operate on the units covered by this document, the drive must be set in AUTO mode. The word "AUTO" will appear in the upper left hand corner of the VFD display. Press the AUTO button to set the drive in AUTO mode.




Fig. 70 - VFD Keypad

C08675

Use the RJ-45 (CAT5) cable (bundled with the Control Harness - see Fig. 71) to provide easier access for using the VFD Remote Keypad. The cable's length is long enough to route it through to the unit's control box, if desired.

To Connect the VFD Keypad using the RJ-45 Cable —

1. Remove the Keypad from the front of the VFD.
2. Remove the RJ-45 adapter from the back of the Remote Keypad and insert the adapter into the RJ-45 port on the front of the VFD.
3. Separate the RJ-45 (CAT5) cable from the Control Harness.
4. Use the CAT5 cable to connect the Remote Keypad to the VFD.




Fig. 71 - Location of VFD in 50LC 04-06 Units

C13394

Start Up with Assistant

Initial start-up has been performed at the factory. Use of the start up assistant will override factory VFD configurations. **DO NOT USE THE START-UP ASSISTANT ON THESE LC UNITS!**

Start Up by Changing Parameters Individually

Initial start-up is performed at the factory. To start up the VFD by changing individual parameters, perform the following procedure:

1. Select MENU (SOFT KEY 2). The Main menu will be displayed.
2. Use the UP or DOWN keys to highlight PARAMETERS on the display screen and press ENTER (SOFT KEY 2).
3. Use the UP or DOWN keys to highlight the desired parameter group and press SEL (SOFT KEY 2).
4. Use the UP or DOWN keys to highlight the desired parameter and press EDIT (SOFT KEY 2).
5. Use the UP or DOWN keys to change the value of the parameter.
6. Press SAVE (SOFT KEY 2) to store the modified value. Press CANCEL (SOFT KEY 1) to keep the previous value. Any modifications that are not saved will not be changed.
7. Choose another parameter or press EXIT (SOFT KEY 1) to return to the listing of parameter groups. Continue until all the parameters have been configured and then press EXIT (SOFT KEY 1) to return to the main menu.

NOTE: The current parameter value appears above the highlight parameter. To view the default parameter value, press the UP and DOWN keys simultaneously. To restore the default factory settings, select the application macro “HVAC Default.”

VFD Modes

The VFD has several different modes for configuring, operating, and diagnosing the VFD. The modes are:

- Standard Display mode — shows drive status information and operates the drive
- Parameters mode — edits parameter values individually
- Start-up Assistant mode — guides the start up and configuration. **DO NOT USE THE START-UP ASSISTANT ON THESE LC UNITS!**
- Changed Parameters mode — shows all changed parameters
- Drive Parameter Backup mode — stores or uploads the parameters
- Clock Set mode — sets the time and date for the drive
- I/O Settings mode — checks and edits the I/O settings

Standard Display Mode

Use the standard display mode to read information on the drive status and operate the drive. To reach the standard display mode, press EXIT until the LCD display shows status information as described below. (See Fig. 72.)

The top line of the LCD display shows the basic status information of the drive. The HAND icon indicates that the drive control is local from the control panel. The AUTO icon indicates that the drive is in remote control mode, such as the basic I/O or field bus.

The arrow icon indicates the drive and motor rotation status. A rotating arrow (clockwise or counterclockwise) indicates that the drive is running and at set point and the shaft direction is forward or reverse. A rotating blinking arrow indicates that the drive is running but not at set point. A stationary arrow indicates that the drive is stopped. For the units covered in this manual, the correct display rotation is clockwise.

The upper right corner shows the frequency set point that the drive will maintain.

Using parameter group 34, the middle of the LCD display can be configured to display 3 parameter values. The default display shows parameters 0103 (OUTPUT FREQ) in percent speed, 0104 (CURRENT) in amperes, and 0120 (A11) in voltage DC.

The bottom corners of the LCD display show the functions currently assigned to the two soft keys. The lower middle displays the current time (if configured to show the time).

The first time the drive is powered up, it is in the OFF mode. To switch to local hand-held control and control the drive using the control panel, press and hold the HAND button. Pressing the HAND button switches the drive to hand control while keeping the drive running. Press the AUTO button to switch to remote input control. To start the drive press the HAND or AUTO buttons, to stop the drive press the OFF button.




Fig. 72 - Standard Display Example

C09249

To adjust the speed in HAND mode, press the UP or DOWN buttons (the reference changes immediately). The reference can be modified in the local control (HAND) mode, and can be parameterized (using Group 11 reference select) to also allow modification in the remote control mode.

Parameters Mode

The Parameters mode is used to change the parameters on the drive. To change parameters, perform the following procedure. See Table 7 for a listing of the VFD parameters per motor and VFD drive models:

1. Select MENU (SOFT KEY 2). The Main menu will be displayed.
2. Use the UP or DOWN keys to highlight PARAMETERS on the display screen and press ENTER (SOFT KEY 2).
3. Use the UP or DOWN keys to highlight the desired parameter group and press SEL (SOFT KEY 2).
4. Use the UP or DOWN keys to highlight the desired parameter and press EDIT (SOFT KEY 2).
5. Use the UP or DOWN keys to change the value of the parameter.
6. Press SAVE (SOFT KEY 2) to store the modified value. Press CANCEL (SOFT KEY 1) to keep the previous value. Any modifications that are not saved will not be changed.
7. Choose another parameter or press EXIT (SOFT KEY 1) to return to the listing of parameter groups. Continue until all the parameters have been configured and then press EXIT (SOFT KEY 1) to return to the main menu.

NOTE: The current parameter value appears above the highlight parameter. To view the default parameter value, press the UP and DOWN keys simultaneously. To restore the default factory settings, select the Carrier application macro.

Changed Parameters Mode

The Changed Parameters mode is used to view and edit recently changed parameters on the drive. To view the changed parameters, perform the following procedure:

1. Select MENU (SOFT KEY 2). The Main menu will be displayed.
2. Use the UP or DOWN keys to highlight CHANGED PAR on the display screen and press ENTER (SOFT KEY 2). A list of the recently changed parameters will be displayed.
3. Use the UP or DOWN keys to highlight the desired parameter group and press EDIT (SOFT KEY 2) to change the parameter if desired.
4. Press EXIT (SOFT KEY 1) to exit the Changed Parameters mode.

Drive Parameter Backup Mode

The drive parameter back up mode is used to export the parameters from one drive to another. The parameters can be uploaded from a VFD to the removable control panel. The control panel can then be transferred to another drive and the parameters downloaded into memory.

Depending on the motor and application, there are two options available. The first option is to download all parameters. This copies both application and motor parameters to the drive from the control panel. This is recommended when using the same application for drives of the same size. This can also be used to create a backup of the parameters group for the drive.

The second option downloads only the application parameters to the drive. This is recommended when using the same application for drives of different sizes.

Upload All Parameters —

To upload and store parameters in the control panel from the VFD, perform the following procedure:

1. Select MENU (SOFT KEY 2). The Main menu will be displayed.
2. Use the UP or DOWN keys to highlight PAR BACKUP on the display screen and press ENTER (SOFT KEY 2).
3. Use the UP or DOWN keys to highlight UPLOAD TO PANEL and press SEL (SOFT KEY 2).
4. The text “Copying Parameters” will be displayed with a progress indicator. To stop the process, select ABORT (SOFT KEY 1).
5. When the upload is complete, the text “Parameter upload successful” will be displayed.
6. The display will then return to the PAR BACKUP menu. Select EXIT (SOFT KEY 1) to return to the main menu.
7. The control panel can now be disconnected from the drive.

Download All Parameters —

To download all parameters from the control panel to the VFD, perform the following procedure:

1. Install the control panel with the correct parameters onto the VFD.
2. Select MENU (SOFT KEY 2). The Main menu will be displayed.
3. Use the UP or DOWN keys to highlight PAR BACKUP on the display screen and press ENTER (SOFT KEY 2).
4. Use the UP or DOWN keys to highlight DOWNLOAD TO DRIVE ALL and press SEL (SOFT KEY 2).
5. The text “Restoring Parameters” will be displayed with a progress indicator. To stop the process, select ABORT (SOFT KEY 1).
6. When the download is complete, the text “Parameter download successful” will be displayed.
7. The display will then return to the PAR BACKUP menu. Select EXIT (SOFT KEY 1) to return to the main menu.
8. The control panel can now be disconnected from the drive.

Download Application Parameters —

To download application parameters only to the control panel from the VFD, perform the following procedure:

1. Install the control panel with the correct parameters onto the VFD.
2. Select MENU (SOFT KEY 2). The Main menu will be displayed.
3. Use the UP or DOWN keys to highlight PAR BACKUP on the display screen and press ENTER (SOFT KEY 2).
4. Use the UP or DOWN keys to highlight DOWNLOAD APPLICATION and press SEL (SOFT KEY 2).
5. The text “Downloading Parameters (partial)” will be displayed with a progress indicator. To stop the process, select ABORT (SOFT KEY 1).
6. When the download is complete, the text “Parameter download successful” will be displayed.
7. The display will then return to the PAR BACKUP menu. Select EXIT (SOFT KEY 1) to return to the main menu.
8. The control panel can now be disconnected from the drive.

Clock Set Mode

The clock set mode is used for setting the date and time for the internal clock of the VFD. In order to use the timer functions of the VFD control, the internal clock must be set. The date is used to determine weekdays and is visible in the fault logs.

To set the clock, perform the following procedure:

1. Select MENU (SOFT KEY 2). The Main menu will be displayed.
2. Use the UP or DOWN keys to highlight CLOCK SET on the display screen and press ENTER (SOFT KEY 2). The clock set parameter list will be displayed.
3. Use the UP or DOWN keys to highlight CLOCK VISIBILITY and press SEL (SOFT KEY 2). This parameter is used to display or hide the clock on the screen. Use the UP or DOWN keys to change the parameter setting. Press OK (SOFT KEY 2) to save the configuration and return to the Clock Set menu.
4. Use the UP or DOWN keys to highlight SET TIME and press SEL (SOFT KEY 2). Use the UP or DOWN keys to change the hours and minutes. Press OK (SOFT KEY 2) to save the configuration and return to the Clock Set menu.

5. Use the UP or DOWN keys to highlight TIME FORMAT and press SEL (SOFT KEY 2). Use the UP or DOWN keys to change the parameter setting. Press OK (SOFT KEY 2) to save the configuration and return to the Clock Set menu.
6. Use the UP or DOWN keys to highlight SET DATE and press SEL (SOFT KEY 2). Use the UP or DOWN keys to change the day, month, and year. Press OK (SOFT KEY 2) to save the configuration and return to the Clock Set menu.
7. Use the UP or DOWN keys to highlight DATE FORMAT and press SEL (SOFT KEY 2). Use the UP or DOWN keys to change the parameter setting. Press OK (SOFT KEY 2) to save the configuration and return to the Clock Set menu.
8. Press EXIT (SOFT KEY 1) twice to return to the main menu.

I/O Settings Mode

The I/O Settings mode is used for viewing and editing the I/O settings.

To configure the I/O settings, perform the following procedure:

1. Select MENU (SOFT KEY 2). The Main menu will be displayed.
2. Use the UP or DOWN keys to highlight I/O SETTINGS on the display screen and press ENTER (SOFT KEY 2). The I/O Settings parameter list will be displayed.
3. Use the UP or DOWN keys to highlight the desired I/O setting and press SEL (SOFT KEY 2).
4. Use the UP or DOWN keys to select the parameter to view. Press OK (SOFT KEY 2).
5. Use the UP or DOWN keys to change the parameter setting. Press SAVE (SOFT KEY 2) to save the configuration. Press CANCEL (SOFT KEY 1) to keep the previous value. Any modifications that are not saved will not be changed.
6. Press EXIT (SOFT KEY 1) twice to return to the main menu.

Table 7 – 50LC 04-06 VFD Parameters

Parameter Group	Parameter Number	Unit Size	50LC 04				
		Motor Description	1.7 HP 575V	1.7 HP 208–230V	1.7 HP 460V	2.4 HP 575V	2.4 HP 208–230V
		Drive/Motor Voltage	575V	208–230V	460V	575V	208–230V
		Motor Part Number	HD56FR579	HD56FR233	HD56FR463	HD56FE577	HD56FE653
		VFD Part Number	HK30WA048	HK30WA045	HK30WA046	HK30WA048	HK30WA001
		ABB Part Number	ACH550–CARUH–03A9–6	ACH550–CARUH–07A5–2	ACH550–CARUH–04A1–4	ACH550–CARUH–03A9–6	ACH550–CARUH–012A–2
Start–Up Data	9902	Application Macro	(1) HVAC DEFAULT	(1) HVAC DEFAULT	(1) HVAC DEFAULT	(1) HVAC DEFAULT	(1) HVAC DEFAULT
	9905	Motor Nominal Voltage	575	230	460	575	230
	9906	Motor Nominal Current	3.1	5.8	2.9	3.4	7.9
	9907	Motor Nominal Frequency	60	60	60	60	60
	9908	Motor Nominal Speed	1725	1725	1725	1725	1725
	9909	Motor Nominal Power	1.7	1.7	1.7	2.4	2.4
Start/Stop/Dir	1001	EXT1 Commands	(1) DI1	(1) DI1	(1) DI1	(1) DI1	(1) DI1
	1003	Direction	(1) Forward	(1) Forward	(1) Forward	(1) Forward	(1) Forward
Reference Select	1103	REF1 Select	(1) AI1	(1) AI1	(1) AI1	(1) AI1	(1) AI1
	1104	REF1 Minimum	0 Hz	0 Hz	0 Hz	0 Hz	0 Hz
	1105	REF1 Maximum	60 Hz	60 Hz	60 Hz	60 Hz	60 Hz
Constant Speeds	1201	Constant Speed Select	(8) DI2,3	(8) DI2,3	(8) DI2,3	(8) DI2,3	(8) DI2,3
	1202	Constant Speed 1	52.4	52.4	52.4	52.4	52.4
	1203	Constant Speed 2	60Hz	60Hz	60Hz	60Hz	60Hz
	1204	Constant Speed 3	60Hz	60Hz	60Hz	60Hz	60Hz
Analog Inputs	1301	Minimum AI–1	20.00%	20.00%	20.00%	20.00%	20.00%
	1302	Maximum AI–1	100.00%	100.00%	100.00%	100.00%	100.00%
Relay Outputs	1401	Relay Output 1	(1) Ready	(1) Ready	(1) Ready	(1) Ready	(1) Ready
	1402	Relay Output 2	(2) Run	(2) Run	(2) Run	(2) Run	(2) Run
	1403	Relay Output 3	(16) FLT/ALARM	(16) FLT/ALARM	(16) FLT/ALARM	(16) FLT/ALARM	(16) FLT/ALARM
System Control	1604	Fault Reset Sel	(0) Keypad	(0) Keypad	(0) Keypad	(0) Keypad	(0) Keypad
	1608	Start Enable 1	(4) DI4	(4) DI4	(4) DI4	(4) DI4	(4) DI4
Override	1701	Override Sel	(0) NOT SEL	(0) NOT SEL	(0) NOT SEL	(0) NOT SEL	(0) NOT SEL
Limits	2003	Maximum Current	3.6	6.7	3.3	3.9	9.1
	2007	Minimum Frequency	0.0 Hz	0.0 Hz	0.0 Hz	0.0 Hz	0.0 Hz
	2008	Maximum Frequency	60Hz	60Hz	60Hz	60Hz	60Hz
Start/Stop	2101	Start Function	(1) AUTO	(1) AUTO	(1) AUTO	(1) AUTO	(1) AUTO
	2102	Stop Function	(1) Coast	(1) Coast	(1) Coast	(1) Coast	(1) Coast
	2109	EM STOP Sel	(0) NOT SEL	(0) NOT SEL	(0) NOT SEL	(0) NOT SEL	(0) NOT SEL
Accel/Decel	2201	Acc/Dec 1/2 Sel	(0) NOT SEL	(0) NOT SEL	(0) NOT SEL	(0) NOT SEL	(0) NOT SEL
	2202	Accelerate Time	30.0s	30.0s	30.0s	30.0s	30.0s
	2203	Decelerate Time	10.0s	10.0s	10.0s	10.0s	10.0s
Motor	2606	Switching Frequency	4 KHz	4 KHz	4 KHz	4 KHz	4 KHz
	2607	Switching Frequency Control	(1) ON	(1) ON	(1) ON	(1) ON	(1) ON
Fault Functions	3005	Motor Therm Prot	(1) Fault	(1) Fault	(1) Fault	(1) Fault	(1) Fault
	3006	Motor Thermal Time	1050s	1050s	1050s	1050s	1050s
	3007	Motor Load Curve	100%	100%	100%	100%	100%
	3008	Zero Speed Load	%00705	%00705	%00705	%00705	%00705
	3009	Break Point Frequency	35 Hz	35 Hz	35 Hz	35 Hz	35 Hz
Automatic Reset	3104	AR Overcurrent	(0) DISABLE	(0) DISABLE	(0) DISABLE	(0) DISABLE	(0) DISABLE
	3105	AR Overvoltage	(1) ENABLE	(1) ENABLE	(1) ENABLE	(1) ENABLE	(1) ENABLE
	3106	AR Undervoltage	(1) ENABLE	(1) ENABLE	(1) ENABLE	(1) ENABLE	(1) ENABLE
EFB Protocol	5301	EFB PROTOCOL ID	0601 (hex)	0601 (hex)	0601 (hex)	0601 (hex)	0601 (hex)
	5302	EFB STATION ID	41	41	41	41	41
	5303	EFB BAUD RATE	38400	38400	38400	38400	38400
	5304	EFB PARITY	8 NONE 1	8 NONE 1	8 NONE 1	8 NONE 1	8 NONE 1
	5305	EFB CTRL PROFILE	DCU PROFILE	DCU PROFILE	DCU PROFILE	DCU PROFILE	DCU PROFILE
Options	9802	COMM PROT SEL	6 (LEN)	6 (LEN)	6 (LEN)	6 (LEN)	6 (LEN)

50LC

Table 7 - 50LC 04-06 VFD Parameters (cont.)

		Unit Size	50LC 04	50LC 05			50LC 06
Parameter Group	Parameter Number	Motor Description	2.4 HP 460V	1.7 HP 575V	1.7 HP 208–230V	1.7 HP 460V	2.4 HP 575V
		Drive/Motor Voltage	460V	575V	208–230V	460V	575V
		Motor Part Number	HD56FE653	HD56FR579	HD56FR233	HD56FR463	HD56FE577
		VFD Part Number	HK30WA008	HK30WA048	HK30WA045	HK30WA046	HK30WA048
		ABB Part Number	ACH550–CARUH–06A9–4	ACH550–CARUH–03A9–6	ACH550–CARUH–07A5–2	ACH550–CARUH–04A1–4	ACH550–CARUH–03A9–6
Start–Up Data	9902	Application Macro	(1) HVAC DEFAULT	(1) HVAC DEFAULT	(1) HVAC DEFAULT	(1) HVAC DEFAULT	(1) HVAC DEFAULT
	9905	Motor Nominal Voltage	460	575	230	460	575
	9906	Motor Nominal Current	4.0	3.1	5.8	2.9	3.4
	9907	Motor Nominal Frequency	60	60	60	60	60
	9908	Motor Nominal Speed	1725	1725	1725	1725	1725
	9909	Motor Nominal Power	2.4	1.7	1.7	1.7	2.4
Start/Stop/Dir	1001	EXT1 Commands	(1) DI1	(1) DI1	(1) DI1	(1) DI1	(1) DI1
	1003	Direction	(1) Forward	(1) Forward	(1) Forward	(1) Forward	(1) Forward
Reference Select	1103	REF1 Select	(1) AI1	(1) AI1	(1) AI1	(1) AI1	(1) AI1
	1104	REF1 Minimum	0 Hz	0 Hz	0 Hz	0 Hz	0 Hz
	1105	REF1 Maximum	60 Hz	60 Hz	60 Hz	60 Hz	60 Hz
Constant Speeds	1201	Constant Speed Select	(8) DI2,3	(8) DI2,3	(8) DI2,3	(8) DI2,3	(8) DI2,3
	1202	Constant Speed 1	52.4	42.6	42.6	42.6	42.6
	1203	Constant Speed 2	60Hz	60Hz	60Hz	60Hz	60Hz
	1204	Constant Speed 3	60Hz	60Hz	60Hz	60Hz	60Hz
Analog Inputs	1301	Minimum AI–1	20.00%	20.00%	20.00%	20.00%	20.00%
	1302	Maximum AI–1	100.00%	100.00%	100.00%	100.00%	100.00%
Relay Outputs	1401	Relay Output 1	(1) Ready	(1) Ready	(1) Ready	(1) Ready	(1) Ready
	1402	Relay Output 2	(2) Run	(2) Run	(2) Run	(2) Run	(2) Run
	1403	Relay Output 3	(16) FLT/ALARM	(16) FLT/ALARM	(16) FLT/ALARM	(16) FLT/ALARM	(16) FLT/ALARM
System Control	1604	Fault Reset Sel	(0) Keypad	(0) Keypad	(0) Keypad	(0) Keypad	(0) Keypad
	1608	Start Enable 1	(4) DI4	(4) DI4	(4) DI4	(4) DI4	(4) DI4
Override	1701	Override Sel	(0) NOT SEL	(0) NOT SEL	(0) NOT SEL	(0) NOT SEL	(0) NOT SEL
Limits	2003	Maximum Current	4.6	3.6	6.7	3.3	3.9
	2007	Minimum Frequency	0.0 Hz	0.0 Hz	0.0 Hz	0.0 Hz	0.0 Hz
	2008	Maximum Frequency	60Hz	60Hz	60Hz	60Hz	60Hz
Start/Stop	2101	Start Function	(1) AUTO	(1) AUTO	(1) AUTO	(1) AUTO	(1) AUTO
	2102	Stop Function	(1) Coast	(1) Coast	(1) Coast	(1) Coast	(1) Coast
	2109	EM STOP Sel	(0) NOT SEL	(0) NOT SEL	(0) NOT SEL	(0) NOT SEL	(0) NOT SEL
Accel/Decel	2201	Acc/Dec 1/2 Sel	(0) NOT SEL	(0) NOT SEL	(0) NOT SEL	(0) NOT SEL	(0) NOT SEL
	2202	Accelerate Time	30.0s	30.0s	30.0s	30.0s	30.0s
	2203	Decelerate Time	10.0s	10.0s	10.0s	10.0s	10.0s
Motor	2606	Switching Frequency	4 KHz	4 KHz	4 KHz	4 KHz	4 KHz
	2607	Switching Frequency Control	(1) ON	(1) ON	(1) ON	(1) ON	(1) ON
Fault Functions	3005	Motor Therm Prot	(1) Fault	(1) Fault	(1) Fault	(1) Fault	(1) Fault
	3006	Motor Thermal Time	1050s	1050s	1050s	1050s	1050s
	3007	Motor Load Curve	100%	100%	100%	100%	100%
	3008	Zero Speed Load	%00705	%00705	%00705	%00705	%00705
	3009	Break Point Frequency	35 Hz	35 Hz	35 Hz	35 Hz	35 Hz
Automatic Reset	3104	AR Overcurrent	(0) DISABLE	(0) DISABLE	(0) DISABLE	(0) DISABLE	(0) DISABLE
	3105	AR Overvoltage	(1) ENABLE	(1) ENABLE	(1) ENABLE	(1) ENABLE	(1) ENABLE
	3106	AR Undervoltage	(1) ENABLE	(1) ENABLE	(1) ENABLE	(1) ENABLE	(1) ENABLE
EFB Protocol	5301	EFB PROTOCOL ID	0601 (hex)	0601 (hex)	0601 (hex)	0601 (hex)	0601 (hex)
	5302	EFB STATION ID	41	41	41	41	41
	5303	EFB BAUD RATE	38400	38400	38400	38400	38400
	5304	EFB PARITY	8 NONE 1	8 NONE 1	8 NONE 1	8 NONE 1	8 NONE 1
	5305	EFB CTRL PROFILE	DCU PROFILE	DCU PROFILE	DCU PROFILE	DCU PROFILE	DCU PROFILE
Options	9802	COMM PROT SEL	6 (LEN)	6 (LEN)	6 (LEN)	6 (LEN)	6 (LEN)

50LC

Table 7 - 50LC 04-06 VFD Parameters (cont.)

Parameter Group	Parameter Number	Unit Size	50LC 06		50LC 05/06		
		Motor Description	2.4 HP 208–230V	2.4 HP 460V	2.9 HP 208–230V	2.9 HP 460V	3.7 HP 575V
Parameter Group	Parameter Number	Drive/Motor Voltage	208–230V	460V	208–230V	460V	575V
		Motor Part Number	HD56FE653	HD56FE653	HD58FE654	HD58FE654	HD58FE577
		VFD Part Number	HK30WA001	HK30WA008	HK30WA001	HK30WA008	HK30WA021
		ABB Part Number	ACH550–CARUH–012A–2	ACH550–CARUH–06A9–4	ACH550–CARUH–012A–2	ACH550–CARUH–06A9–4	ACH550–CARUH–06A1–6
Start–Up Data	9902	Application Macro	(1) HVAC DEFAULT	(1) HVAC DEFAULT	(1) HVAC DEFAULT	(1) HVAC DEFAULT	(1) HVAC DEFAULT
	9905	Motor Nominal Voltage	230	460	230	460	575
	9906	Motor Nominal Current	7.9	4.0	9.2	4.6	4.2
	9907	Motor Nominal Frequency	60	60	60	60	60
	9908	Motor Nominal Speed	1725	1725	1725	1725	1725
	9909	Motor Nominal Power	2.4	2.4	2.9	2.9	3.7
Start/Stop/Dir	1001	EXT1 Commands	(1) DI1	(1) DI1	(1) DI1	(1) DI1	(1) DI1
	1003	Direction	(1) Forward	(1) Forward	(1) Forward	(1) Forward	(1) Forward
Reference Select	1103	REF1 Select	(1) AI1	(1) AI1	(1) AI1	(1) AI1	(1) AI1
	1104	REF1 Minimum	0 Hz	0 Hz	0 Hz	0 Hz	0 Hz
	1105	REF1 Maximum	60 Hz	60 Hz	60 Hz	60 Hz	60 Hz
Constant Speeds	1201	Constant Speed Select	(8) DI2,3	(8) DI2,3	(8) DI2,3	(8) DI2,3	(8) DI2,3
	1202	Constant Speed 1	42.6	42.6	41.2	41.2	41.2
	1203	Constant Speed 2	60Hz	60Hz	60Hz	60Hz	60Hz
	1204	Constant Speed 3	60Hz	60Hz	60Hz	60Hz	60Hz
Analog Inputs	1301	Minimum AI–1	20.00%	20.00%	20.00%	20.00%	20.00%
	1302	Maximum AI–1	100.00%	100.00%	100.00%	100.00%	100.00%
Relay Outputs	1401	Relay Output 1	(1) Ready	(1) Ready	(1) Ready	(1) Ready	(1) Ready
	1402	Relay Output 2	(2) Run	(2) Run	(2) Run	(2) Run	(2) Run
	1403	Relay Output 3	(16) FLT/ALARM	(16) FLT/ALARM	(16) FLT/ALARM	(16) FLT/ALARM	(16) FLT/ALARM
System Control	1604	Fault Reset Sel	(0) Keypad	(0) Keypad	(0) Keypad	(0) Keypad	(0) Keypad
	1608	Start Enable 1	(4) DI4	(4) DI4	(4) DI4	(4) DI4	(4) DI4
Override	1701	Override Sel	(0) NOT SEL	(0) NOT SEL	(0) NOT SEL	(0) NOT SEL	(0) NOT SEL
Limits	2003	Maximum Current	9.1	4.6	10.6	5.3	4.8
	2007	Minimum Frequency	0.0 Hz	0.0 Hz	0.0 Hz	0.0 Hz	0.0 Hz
	2008	Maximum Frequency	60Hz	60Hz	60Hz	60Hz	60Hz
Start/Stop	2101	Start Function	(1) AUTO	(1) AUTO	(1) AUTO	(1) AUTO	(1) AUTO
	2102	Stop Function	(1) Coast	(1) Coast	(1) Coast	(1) Coast	(1) Coast
	2109	EM STOP Sel	(0) NOT SEL	(0) NOT SEL	(0) NOT SEL	(0) NOT SEL	(0) NOT SEL
Accel/Decel	2201	Acc/Dec 1/2 Sel	(0) NOT SEL	(0) NOT SEL	(0) NOT SEL	(0) NOT SEL	(0) NOT SEL
	2202	Accelerate Time	30.0s	30.0s	30.0s	30.0s	30.0s
	2203	Decelerate Time	10.0s	10.0s	10.0s	10.0s	10.0s
Motor	2606	Switching Frequency	4 KHz	4 KHz	4 KHz	4 KHz	4 KHz
	2607	Switching Frequency Control	(1) ON	(1) ON	(1) ON	(1) ON	(1) ON
Fault Functions	3005	Motor Therm Prot	(1) Fault	(1) Fault	(1) Fault	(1) Fault	(1) Fault
	3006	Motor Thermal Time	1050s	1050s	1050s	1050s	1050s
	3007	Motor Load Curve	100%	100%	100%	100%	100%
	3008	Zero Speed Load	%00705	%00705	%00705	%00705	%00705
	3009	Break Point Frequency	35 Hz	35 Hz	35 Hz	35 Hz	35 Hz
Automatic Reset	3104	AR Overcurrent	(0) DISABLE	(0) DISABLE	(0) DISABLE	(0) DISABLE	(0) DISABLE
	3105	AR Overvoltage	(1) ENABLE	(1) ENABLE	(1) ENABLE	(1) ENABLE	(1) ENABLE
	3106	AR Undervoltage	(1) ENABLE	(1) ENABLE	(1) ENABLE	(1) ENABLE	(1) ENABLE
EFB Protocol	5301	EFB PROTOCOL ID	0601 (hex)	0601 (hex)	0601 (hex)	0601 (hex)	0601 (hex)
	5302	EFB STATION ID	41	41	41	41	41
	5303	EFB BAUD RATE	38400	38400	38400	38400	38400
	5304	EFB PARITY	8 NONE 1	8 NONE 1	8 NONE 1	8 NONE 1	8 NONE 1
	5305	EFB CTRL PROFILE	DCU PROFILE	DCU PROFILE	DCU PROFILE	DCU PROFILE	DCU PROFILE
Options	9802	COMM PROT SEL	6 (LEN)	6 (LEN)	6 (LEN)	6 (LEN)	6 (LEN)

50LC

VFD Diagnostics

The drive detects error situations and reports them using:

1. Green and red LEDs on the body of the drive (located under the keypad)
2. Status LED on the control panel
3. Control panel display
4. The Fault Word and Alarm Word parameter bits (parameters 0305 to 0309)

The form of the display depends on the severity of the error. The user can specify the severity for many errors by directing the drive to ignore the error situation, report the situation as an alarm, or report the situation as a fault.

Faults (Red LED Lit)

The VFD signals that it has detected a severe error, or fault, by:

1. Enabling the red LED on the drive (LED is either steady or flashing)
2. Setting an appropriate bit in a Fault Word parameter (0305 to 0307)
3. Overriding the control panel display with the display of a fault code
4. Stopping the motor (if it was on)
5. Sets an appropriate bit in Fault Word parameter 0305- 0307.

The fault code on the control panel display is temporary. Pressing the MENU, ENTER, UP button or DOWN buttons removes the fault message. The message reappears after a few seconds if the control panel is not touched and the fault is still active.

Alarms (Green LED Flashing)

For less severe errors, called alarms, the diagnostic display is advisory. For these situations, the drive is simply reporting that it had detected something unusual. In these situations, the drive:

1. Flashes the green LED on the drive (does not apply to alarms that arise from control panel operation errors)
2. Sets an appropriate bit in an Alarm Word parameter (0308 or 0309)
3. Overrides the control panel display with the display of an alarm code and/or name

Alarm messages disappear from the control panel display after a few seconds. The message returns periodically as long as the alarm condition exists.

Correcting Faults

The recommended corrective action for faults is shown in the Fault Listing Table 8. The VFD can also be reset to remove the fault. If an external source for a start command is selected and is active, the VFD may start immediately after fault reset.

To reset a fault indicated by a flashing red LED, turn off the power for 5 minutes. To reset a fault indicated by a red LED (not flashing), press RESET from the control panel or turn off the power for 5 minutes. Depending on the value of parameter 1604 (FAULT RESET SELECT), digital input or serial communication could also be used to reset the drive. When the fault has been corrected, the motor can be started.

History

For reference, the last three fault codes are stored into parameters 0401, 0412, 0413. For the most recent fault (identified by parameter 0401), the drive stores additional data (in parameters 0402 through 0411) to aid in troubleshooting a problem. For example, a parameter 0404 stores the motor speed at the time of the fault. To clear the fault history (all of Group 04, Fault History parameters), follow these steps:

1. In the control panel, Parameters mode, select parameter 0401.
2. Press EDIT.
3. Press the UP and DOWN buttons simultaneously.
4. Press SAVE.

Correcting Alarms

To correct alarms, first determine if the Alarm requires any corrective action (action is not always required). Use Table 9 to find and address the root cause of the problem.

If diagnostics troubleshooting has determined that the drive is defective during the warranty period, contact ABB Automation Inc., at 1-800-435-7365, option 4, option 3. A qualified technician will review the problem with the caller and make a determination regarding how to proceed. This may involve dispatching a designated service station (DSS) representative from an authorized station, dispatching a replacement unit, or advising return for repair.

Control Panel Cleaning

Use a soft damp cloth to clean the control panel. Avoid harsh cleaners which could scratch the display window.

Battery Replacement

A battery is only used in assistant control panels that have the clock function available and enabled. The battery keeps the clock operating in memory during power interruptions. The expected life for the battery is greater than ten years. To remove the battery, use a coin to rotate the battery holder on the back of the control panel. Replace the battery with type CR2032.

Table 8 – FAULT CODES

FAULT CODE	FAULT NAME IN PANEL	DESCRIPTION AND RECOMMENDED CORRECTIVE ACTION
1	OVERCURRENT	Output current is excessive. Check for excessive motor load, insufficient acceleration time (parameters 2202 ACCELER TIME 1, default 30 seconds), or faulty motor, motor cables or connections.
2	DC OVERVOLT	Intermediate circuit DC voltage is excessive. Check for static or transient over voltages in the input power supply, insufficient deceleration time (parameters 2203 DECELER TIME 1, default 30 seconds), or undersized brake chopper (if present).
3	DEV OVERTEMP	Drive heat sink is overheated. Temperature is at or above 115°C (239°F). Check for fan failure, obstructions in the air flow, dirt or dust coating on the heat sink, excessive ambient temperature, or excessive motor load.
4	SHORT CIRC	Fault current. Check for short-circuit in the motor cable(s) or motor or supply disturbances.
5	OVERLOAD	Inverter overload condition. The drive output current exceeds the ratings.
6	DC OVERVOLT	Intermediate circuit DC voltage is not sufficient. Check for missing phase in the input power supply, blown fuse, or under voltage on main circuit.
7	AI1 LOSS	Analog input 1 loss. Analog input value is less than AI1 FLT LIMIT (3021). Check source and connection for analog input and parameter settings for AI1 FLT LIMIT (3021) and 3001 AI<MIN FUNCTION.
8	AI2 LOSS	Analog input 2 loss. Analog input value is less than AI2 FLT LIMIT (3022). Check source and connection for analog input and parameter settings for AI2 FLT LIMIT (3022) and 3001 AI<MIN FUNCTION.
9	MOT OVERTEMP	Motor is too hot, as estimated by the drive. Check for overloaded motor. Adjust the parameters used for the estimate (3005 through 3009). Check the temperature sensors and Group 35 parameters.
10	PANEL LOSS	Panel communication is lost and either drive is in local control mode (the control panel displays LOC), or drive is in remote control mode (REM) and is parameterized to accept start/stop, direction or reference from the control panel. To correct check the communication lines and connections. Check parameter 3002 PANEL COMM ERROR, parameters in Group 10: Command Inputs and Group 11:Reference Select (if drive operation is REM).
11	ID RUN FAIL	The motor ID run was not completed successfully. Check motor connections.
12	MOTOR STALL	Motor or process stall. Motor is operating in the stall region. Check for excessive load or insufficient motor power. Check parameters 3010 through 3012.
13	RESERVED	Not used.
14	EXT FAULT 1	Digital input defined to report first external fault is active. See parameter 3003 EXTERNAL FAULT 1.
15	EXT FAULT 2	Digital input defined to report second external fault is active. See parameter 3004 EXTERNAL FAULT 2.
16	EARTH FAULT	The load on the input power system is out of balance. Check for faults in the motor or motor cable. Verify that motor cable does not exceed maximum specified length.
17	UNDERLOAD	Motor load is lower than expected. Check for disconnected load. Check parameters 3013 UNDERLOAD FUNCTION through 3015 UNDERLOAD CURVE.
18	THERM FAIL	Internal fault. The thermistor measuring the internal temperature of the drive is open or shorted. Contact Carrier.
19	OPEX LINK	Internal fault. A communication-related problem has been detected between the OMIO and OINT boards. Contact Carrier.
20	OPEX PWR	Internal fault. Low voltage condition detected on the OINT board. Contact Carrier.
21	CURR MEAS	Internal fault. Current measurement is out of range. Contact Carrier.
22	SUPPLY PHASE	Ripple voltage in the DC link is too high. Check for missing main phase or blown fuse.
23	RESERVED	Not used.
24	OVERSPEED	Motor speed is greater than 120% of the larger (in magnitude) of 2001 MINIMUM SPEED or 2002 MAXIMUM SPEED parameters. Check parameter settings for 2001 and 2002. Check adequacy of motor braking torque. Check applicability of torque control. Check brake chopper and resistor.
25	RESERVED	Not used.
26	DRIVE ID	Internal fault. Configuration block drive ID is not valid.
27	CONFIG FILE	Internal configuration file has an error. Contact Carrier.
28	SERIAL 1 ERR	Field bus communication has timed out. Check fault setup (3018 COMM FAULT FUNC and 3019 COMM FAULT TIME). Check communication settings (Group 51 or 53 as appropriate). Check for poor connections and/or noise on line.
29	EFB CON FILE	Error in reading the configuration file for the field bus adapter.
30	FORCE TRIP	Fault trip forced by the field bus. See the field bus reference literature.
31	EFB 1	Fault code reserved for the EFB protocol application. The meaning is protocol dependent.
32	EFB 2	Fault code reserved for the EFB protocol application. The meaning is protocol dependent.
33	EFB 3	Fault code reserved for the EFB protocol application. The meaning is protocol dependent.
34	MOTOR PHASE	Fault in the motor circuit. One of the motor phases is lost. Check for motor fault, motor cable fault, thermal relay fault, or internal fault.
35	OUTP WIRING	Error in power wiring suspected. Check that input power wired to drive output. Check for ground faults.
101–105	SYSTEM ERROR	Error internal to the drive. Contact Carrier and report the error number.
201–206	SYSTEM ERROR	Error internal to the drive. Contact Carrier and report the error number.

Table 8 — FAULT CODES (cont)

FAULT CODE	FAULT NAME IN PANEL	DESCRIPTION AND RECOMMENDED CORRECTIVE ACTION
1000	PAR HZRPM	Parameter values are inconsistent. Check for any of the following: 2001 MINIMUM SPEED > 2002 MAXIMUM SPEED 2007 MINIMUM FREQ > 2008 MAXIMUM FREQ 2001 MINIMUM SPEED / 9908 MOTOR NOM SPEED is outside of the range: -128/+128 2002 MAXIMUM SPEED / 9908 MOTOR NOM SPEED is outside of the range: -128/+128 2007 MINIMUM FREQ / 9907 MOTOR NOM FREQ is outside of the range: -128/+128 2008 MAXIMUM FREQ / 9907 MOTOR NOM FREQ is outside of the range: -128/+128
1001	PAR PFA REFNG	Parameter values are inconsistent. Check that 2007 MINIMUM FREQ is negative, when 8123 PFA ENABLE is active.
1002	PAR PFA IOCNF	Parameter values are inconsistent. The number of programmed PFA relays does not match with Interlock configuration, when 8123 PFA ENABLE is active. Check consistency of RELAY OUTPUT parameters 1401 through 1403, and 1410 through 1412. Check 8117 NR OF AUX MOTORS, 8118 AUTOCHANGE INTERV, and 8120 INTERLOCKS.
1003	PAR AI SCALE	Parameter values are inconsistent. Check that parameter 1301 AI 1 MIN > 1302 AI 1 MAX and that parameter 1304 AI 2 MIN > 1305 AI 2 MAX.
1004	PAR AO SCALE	Parameter values are inconsistent. Check that parameter 1504 AO 1 MIN > 1505 AO 1 MAX and that parameter 1510 AO 2 MIN > 1511 AO 2 MAX.
1005	PAR PCU 2	Parameter values for power control are inconsistent: Improper motor nominal kVA or motor nominal power. Check the following parameters: $1.1 < (9906 \text{ MOTOR NOM CURR} * 9905 \text{ MOTOR NOM VOLT} * 1.73 / \text{PN}) < 2.6$ Where: PN = $1000 * 9909 \text{ MOTOR NOM POWER}$ (if units are kW) or PN = $746 * 9909 \text{ MOTOR NOM POWER}$ (if units are HP, e.g., in US)
1006	PAR EXT RO	Parameter values are inconsistent. Check the extension relay module for connection and 1410 through 1412 RELAY OUTPUTS 4 through 6 have non-zero values.
1007	PAR FBUS	Parameter values are inconsistent. Check that a parameter is set for field bus control (e.g., 1001 EXT1 COMMANDS = 10 (COMM)), but 9802 COMM PROT SEL = 0.
1008	PAR PFA MODE	Parameter values are inconsistent. The 9904 MOTOR CTRL MODE must = 3 (SCALAR SPEED) when 8123 PFA ENABLE activated.
1009	PAR PCU 1	Parameter values for power control are inconsistent or improper motor nominal frequency or speed. Check for both of the following: $1 < (60 * 9907 \text{ MOTOR NOM FREQ} / 9908 \text{ MOTOR NOM SPEED}) < 16$ $0.8 < 9908 \text{ MOTOR NOM SPEED} / (120 * 9907 \text{ MOTOR NOM FREQ} / \text{Motor poles}) < 0.992$
1010	OVERRIDE/PFA CONFLICT	Override mode is enabled and PFA is activated at the same time. This cannot be done because PFA interlocks cannot be observed in the override mode.

50LC

Table 9 – ALARM CODES

ALARM CODE	ALARM NAME IN PANEL	DESCRIPTION AND RECOMMENDED CORRECTIVE ACTION
2001	–	Reserved
2002	–	Reserved
2003	–	Reserved
2004	DIR LOCK	The change in direction being attempted is not allowed. Do not attempt to change the direction of motor rotation, or Change parameter 1003 DIRECTION to allow direction change (if reverse operation is safe).
2005	I/O COMM	Field bus communication has timed out. Check fault setup (3018 COMM FAULT FUNC and 3019 COMM FAULT TIME). Check communication settings (Group 51 or 53 as appropriate). Check for poor connections and/or noise on line.
2006	AI1 LOSS	Analog input 1 is lost, or value is less than the minimum setting. Check input source and connections. Check the parameter that sets the minimum (3021) and the parameter that sets the Alarm/Fault operation (3001).
2007	AI2 LOSS	Analog input 2 is lost, or value is less than the minimum setting. Check input source and connections. Check parameter that sets the minimum (3022) and the parameter that sets the Alarm/Fault operation (3001).
2008	PANEL LOSS	Panel communication is lost and either the VFD is in local control mode (the control panel displays HAND), or the VFD is in remote control mode (AUTO) and is parameterized to accept start/stop, direction or reference from the control panel. To correct, check the communication lines and connections, Parameter 3002 PANEL LOSS, and parameters in groups 10 COMMAND INPUTS and 11 REFERENCE SELECT (if drive operation is REM).
2009	–	Reserved
2010	MOT OVERTEMP	Motor is hot, based on either the VFD estimate or on temperature feedback. This alarm warns that a Motor Overload fault trip may be near. Check for overloaded motor. Adjust the parameters used for the estimate (3005 through 3009). Check the temperature sensors and Group 35 parameters.
2011	UNDERLOAD	Motor load is lower than expected. This alarm warns that a Motor Underload fault trip may be near. Check that the motor and drive ratings match (motor is NOT undersized for the drive). Check the settings on parameters 3013 to 3015.
2012	MOTOR STALL	Motor is operating in the stall region. This alarm warns that a Motor Stall fault trip may be near.
2013*	AUTORESET	This alarm warns that the drive is about to perform an automatic fault reset, which may start the motor. To control automatic reset, use parameter group 31 (AUTOMATIC RESET).
2014	AUTOCHANGE	This alarm warns that the PFA autochange function is active. To control PFA, use parameter group 81 (PFA) and the Pump Alternation macro.
2015	PFA INTERLOCK	This alarm warns that the PFA interlocks are active, which means that the drive cannot start any motor (when Autochange is used), or a speed regulated motor (when Autochange is not used).
2016	–	Reserved
2017*	OFF BUTTON	This alarm indicates that the OFF button has been pressed.
2018	PID SLEEP	This alarm warns that the PID sleep function is active, which means that the motor could accelerate when the PID sleep function ends. To control PID sleep, use parameters 4022 through 4026 or 4122 through 4126.
2019	ID RUN	The VFD is performing an ID run.
2020	OVERRIDE	Override mode is activated.
2021	START ENABLE 1 MISSING	This alarm warns that the Start Enable 1 signal is missing. To control Start Enable 1 function, use parameter 1608. To correct, check the digital input configuration and the communication settings.
2022	START ENABLE 2 MISSING	This alarm warns that the Start Enable 2 signal is missing. To control Start Enable 2 function, use parameter 1609. To correct, check the digital input configuration and the communication settings.
2023	EMERGENCY STOP	Emergency stop is activated.

* This alarm is not indicated by a relay output, even when the relay output is configured to indicate alarm conditions, parameter 1401 RELAY OUTPUT = 5 (ALARM) or 16 (FLT/ALARM).

50LC

UNIT START-UP CHECKLIST

(Remove and Store in Job File)

MODEL NO.: _____

SERIAL NO.: _____

I. PRE-START-UP

- VERIFY THAT ALL PACKAGING MATERIALS HAVE BEEN REMOVED FROM UNIT
- VERIFY INSTALLATION OF OUTDOOR AIR HOOD
- VERIFY INSTALLATION OF FLUE EXHAUST AND INLET HOOD
- VERIFY THAT CONDENSATE CONNECTION IS INSTALLED PER INSTRUCTIONS
- VERIFY THAT ALL ELECTRICAL CONNECTIONS AND TERMINALS ARE TIGHT
- CHECK THAT INDOOR-AIR FILTERS ARE CLEAN AND IN PLACE
- CHECK THAT OUTDOOR AIR INLET SCREENS ARE IN PLACE
- VERIFY THAT UNIT IS LEVEL
- CHECK FAN WHEELS AND PROPELLER FOR LOCATION IN HOUSING/ORIFICE AND VERIFY SETSCREW IS TIGHT
- VERIFY THAT FAN SHEAVES ARE ALIGNED AND BELTS ARE PROPERLY TENSIONED
- VERIFY THAT SCROLL COMPRESSORS ARE ROTATING IN THE CORRECT DIRECTION
- VERIFY INSTALLATION OF THERMOSTAT

II. START-UP

ELECTRICAL

SUPPLY VOLTAGE	L1-L2 _____	L2-L3 _____	L3-L1 _____
COMPRESSOR AMPS 1	L1 _____	L2 _____	L3 _____
COMPRESSOR AMPS 2	L1 _____	L2 _____	L3 _____
SUPPLY FAN AMPS	L1 _____	L2 _____	L3 _____

TEMPERATURES

OUTDOOR-AIR TEMPERATURE	_____ °F DB (DRY BULB)
RETURN-AIR TEMPERATURE	_____ °F DB _____ °F WB (WET BULB)
COOLING SUPPLY AIR TEMPERATURE	_____ °F

PRESSURES

REFRIGERANT SUCTION	CIRCUIT A _____ PSIG
	CIRCUIT B _____ PSIG
REFRIGERANT DISCHARGE	CIRCUIT A _____ PSIG
	CIRCUIT B _____ PSIG

- VERIFY REFRIGERANT CHARGE USING CHARGING CHARTS

GENERAL

- ECONOMIZER MINIMUM VENT AND CHANGE OVER SETTINGS TO JOB REQUIREMENTS (IF EQUIPPED)
- VERIFY SMOKE DETECTOR UNIT SHUTDOWN BY UTILIZING MAGNET TEST

50LC

III. HUMIDIMIZER START-UP

STEPS

- 1. CHECK CTB FOR JUMPER 5, 6, 7
JUMPER 5, 6, 7 MUST BE CUT AND OPEN
- 2. OPEN HUMIDISTAT CONTACTS
- 3. START UNIT IN COOLING (CLOSE Y1)

OBSERVE AND RECORD

- A. SUCTION PRESSURE _____ PSIG
 - B. DISCHARGE PRESSURE _____ PSIG
 - C. ENTERING AIR TEMPERATURE _____ °F
 - D. LIQUID LINE TEMPERATURE
AT OUTLET OR REHEAT COIL _____ °F
 - E. CONFIRM CORRECT ROTATION FOR COMPRESSOR
 - F. CHECK FOR CORRECT RAMP-UP OF OUTDOOR FAN MOTOR AS CONDENSER COIL WARMS
- 4. CHECK UNIT CHARGE PER CHARGING CHART
 - 5. SWITCH UNIT TO HIGH-LATENT MODE (SUBCOOLER) BY CLOSING HUMIDISTAT WITH Y1 CLOSED

OBSERVE

- A. REDUCTION IN SUCTION PRESSURE (5 TO 7 PSI EXPECTED)
 - B. DISCHARGE PRESSURE UNCHANGED
 - C. LIQUID TEMPERATURE DROPS TO 50 TO 55°F RANGE
 - D. LSV SOLENOID ENERGIZED (VALVE CLOSSES)
- 6. SWITCH UNIT TO DEHUMID (REHEAT) BY OPENING Y1

OBSERVE

- A. SUCTION PRESSURE INCREASES TO NORMAL COOLING LEVEL
 - B. DISCHARGE PRESSURE DECREASES (35 TO 50 PSI)
 - C. LIQUID TEMPERATURE RETURNS TO NORMAL COOLING LEVEL
 - D. LSV SOLENOID ENERGIZED (VALVE CLOSSES)
 - E. DSV SOLENOID ENERGIZED, VALVE OPENS
- 7. WITH UNIT IN DEHUMID MODE CLOSE W1
COMPRESSOR AND OUTDOOR FAN STOP; LSV AND DSV SOLENOIDS DE-ENERGIZED
 - 8. OPEN W1 RESTORE UNIT TO DEHUMID MODE
 - 9. OPEN HUMIDISTAT INPUT
COMPRESSOR AND OUTDOOR FAN STOP; LSV AND DSV SOLENOIDS DE-ENERGIZED
 - 10. RESTORE SETPOINTS FOR THERMOSTAT AND HUMIDISTAT

REPEAT PROCESS FOR 2 COMPRESSOR SYSTEMS